


~ CHAMELEON ~

(Version No. USA-20130425)

TABLE OF CONTENTS


Interface	p. 04
Button Layout	p. 04
Data Setting List	p. 05
Setup Menu	p. 07
Input Password	p. 08
Information	p. 09
Data Setting	p. 10
Bookkeeping	p. 13
Audit Mode	p. 16
I/O Test	p. 17
History	p. 18
Touch screen adjust	p. 19
How To Play -- Main Game	p. 20
• Chameleon Time	p. 21
• Free Game	p. 22
Odds Table	p. 23
Double up Game	p. 24
Bonus Game	p. 25
Dragon ball jackpot	p. 26
Trouble Shooting	p. 28
Special Notice	p. 29
Pin Layout	p. 30

INTERFACE



1. 10 Pin.
2. 36 Pin.
3. SVGA signal port, Compatible to monitor resolution: 800 * 600.
4. RS232 port connected to “TOUCH SCREEN”.
5. RS232 port connected to “BILL ACCEPTOR”.
6. Caution: Please do not switch any item on this dipswitch in order any system disorder.

BUTTON LAYOUT




DATA SETTING LIST

NOTICE: If there is any credit in the game, the setting can not be changed, please make sure there is no any credit remaining before you enter the setting menu.

ITEM		VALUE
1	COIN IN UNIT	1,2,3,4,5,10,15,20, <u>25</u> ,30,40 50 60,75,80,100,200,250,400,500,1000
2	KEY IN UNIT	1,2 3,4,5,10,15,20,25,30,40,50,60,75,80,100,200,250,400, 500, 1000 ,OFF
3	BILL IN UNIT	<u>1</u> , 2, 3, 4, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 100, 200, 250, 400, 500, 1000,OFF
4	BILL ACCEPTOR	<u>RS232-JCM</u> , RS232-ICT(A7), RS232-ICT(J830)
	BILL IN METER	
5	KEY OUT UNIT	1,2,3,4,5,10,15,20,25,30,40,50,60,75,80,100,200,250,400,500, 1000 , CLEAR ALL(AS COIN IN), CLEAR ALL(AS KEY IN)
6	TICKET OUT UNIT	1,2,3,4,5,10,15,20,25,30,40,50,60,75,80,100,200,250,400,500, 1000
7	COIN OUT LIMIT	100,200,300, 500 ,1000,2000,3000,5000 ,OFF
8	MAX. TICKETS PER GAME	CONTINUOUS ,1,2,3,4,5,8,10
9	CREDIT LIMIT	1000,3000,5000,10000,20000, 30000 ,50000,100000,990000
10	MAX. PLAY / LINE	9(1), 18(2), 27(3), 36(4), 45(5), 54(6), 63(7), 72(8), 81(9), 90(10) , 135(15), 180(20), 225(25), 270(30)
11	MIN. PLAY / TOTAL	<u>1</u> , 3, 5, 7, 9, 18, 27, 36, 45, 54, 63, 72, 81, 90, 135, 180, 225, 270
12	JP MIN. PLAY	9, 18, 27, 36, 45 , 54, 63, 72, 81, 90, 135, 180, 225, 270
13	DOUBLE UP GAME	ON , OFF
14	LEVEL OF DIFFICULTY	LEVEL 1(EASIEST), LEVEL 2, LEVEL 3, LEVEL 4, LEVEL 5, LEVEL 6, LEVEL 7, LEVEL 8(HARDEST)
15	DEMO SOUND VOLUME	5,10,15,20,25,30,35,40,45,50,55,60,65, <u>70</u> ,75,80,85,90,95,100,OFF
16	GAME SOUND VOLUME	5,10,15,20,25,30,35,40,45,50,55,60,65, <u>70</u> ,75,80,85,90,95,100,OFF
17	WIN TO	CREDIT , SCORE
18	PLAY SCORE	YES, NO
19	10 TIMES FEATURE	ON, OFF
20	GAME COUNT	ON, OFF
21	AUTO PLAY	ON , OFF
22	CONTINUOUS SPIN	ON, OFF
23	ODDS TABLE	ON , OFF


ITEM		VALUE
24	BOOKKEEPING	ON , OFF
25	DEMO	ON , OFF
26	PASSWORD	OFF , 1, 2, 3, 4, 5, 6, 7
27	HOPPER SENSOR	NORMAL HIGH , NORMAL LOW
28	TOUCH SCREEN	ON, OFF , ON(3M STANDARD), ON(ADJUST EVERY TIME)
29	COLLECT BUTTON	DIRECT DRIVE(TICKET OUT) , INTERFACE BOARD, ATTENDANT, DIRECT DRIVE(COIN IN)

SETUP MENU



1. Turn on the **Account** switch to enter the **Setup Menu**.
2. The Main Menu contains: 《 INFORMATION 》、《 DATA SETTING 》、《 LINKING 》、《 BOOKKEEPING 》、《 I/O TEST 》、《 HISTORY 》 and 《 TOUCH SCREEN ADJUST 》.
3. Press **DOUBLE** or **PLAY** button to select the item.
4. Press **START** button to entry.
5. Press **TAKE** to exit **Setup Menu**.


INPUT PASSWORD



1. Press **DOUBLE** or **PLAY** to select the item to change.
2. Press **INFO** to change the digit.
3. Press **START** to enter the password, if the password is correct, will enter the Data Setting page.
4. Press **TAKE** to exit the Password page.

Password No.	OFF	1	2	3	4	5	6	7
Code	No use	649293	105113	302105	729157	133594	469097	116512

INFORMATION



1. Turn on the **Account** switch to enter the **Setup Menu**.
2. Select 《 INFORMATION 》 to enter the information.
3. Press **TAKE** to exit the information.


DATA SETTING




1. Turn on the **Account** switch to enter the **Setup Menu**.
2. Select 《 DATA SETTING 》 to enter the Data Setting.
3. Press **DOUBLE** or **PLAY** to choose the selection.
4. Press **START** to change the values.
5. Press **TAKE** to exit Data Setting.
6. Press **PLAY** + **AUTO** to load the factory default (Data Format).
7. Press **PLAY** + **INFO** to reset the bookkeeping data, but would not change the values in the setting.

There are total 2 pages in the data setting

LINE TYPE CHANGE




GAME RESET



The program will reconfirm the reset instruction.

BILL ACCEPTOR




1. Press **DOUBLE** or **PLAY** to choose the selection.
2. Press **START** to change the values.
3. Press **TAKE** to exit.


BOOKKEEPING




1. Turn on the **Account** switch to enter the **Setup Menu**.
2. Select 《 **BOOKKEEPING** 》 to enter the bookkeeping.
3. The Bookkeeping contains: 《 **AUDIT MODE** 》、《 **GAME SUMMARY** 》、《 **BASE GAME STATISTICS** 》、《 **DOUBLE UP STATISTICS** 》、《 **JACKPOT STATISTICS** 》、《 **BONUS GAME STATISTICS** 》、《 **COMBINATION STATISTICS** 》.
4. Press **DOUBLE** or **PLAY** button to select the item.
5. Press **TAKE** to exit Bookkeeping .




1/7



2/7




3/7




4/7



5/7




6/7




7/7

AUDIT MODE



1. Press **START** + **AUTO** button to shift record.
2. Press **TAKE** to exit.

I/O TEST




1. Turn on the **Account** switch to enter the **Setup Menu**.
2. Select 《 I/O TEST 》 to enter the I/O Test.
3. I/O test includes all keyboard functions testing.
4. Press **TAKE** button for 2 seconds to exit I/O Test.

HISTORY



1. Turn on the **Account** switch to enter the **Setup Menu**.
2. Select 《 HISTORY 》 to enter the History.
3. Press **DOUBLE** or **PLAY** button to select the page.
4. Press **TAKE** button to exit History.

TOUCH SCREEN ADJUST



1. Connect the touch screen to the main board and turn the power on.
(Please refer to P.4 INTERFACE)
2. Into the Data Setting page #28 “**TOUCH SCREEN**” to setting the touch screen.

ITEM	EXPLANATION
ON (3M STANDARD)	If your touch screen is “3M STANDARD” please select this item.(Don’t need adjust the touch screen)
ON (ADJUST EVERY TIME)	Every time you reset the game or restart the power, you need to adjust the touch screen again.
ON	Adjust the touch screen at the first time connected.
OFF	Turn the touch function off.

3. Select 《 TOUCH SCREEN ADJUST 》 to enter the Touch screen adjust.
4. Follow and touch the spot of the screen to adjust the touch screen.


HOW TO PLAY

- MAIN GAME



MULTI-LINER GAME

- WIN CHART



9 LINES WIN CHART

All line wins are paid while 3 or more winning symbols line up from left to right or right to left.

- CHAMELEON TIME



- When playing all 9 lines and the beads appearing on the fifth reel, the “Chameleon Time” is triggered
- The “Chameleon Time” is divided into four levels; player can play games for free maximum three times at each level.



- When the beads appear on the fifth reel, player will enter into the next level.
- 1-4 symbols will disappear randomly every time entered into the next level to increase the winning chance.
- If no beads appear during 3-time games at any level, the “Chameleon Time” ends.

- **FREE GAME**



- When 3 or more "FREE GAME" symbols appear, 10 to 20 times of free games will be triggered.



- When hitting any winning line in free game, the multiplier value will be upgraded to the next level, when next time hit the winning line, the prize will be multiplied by the value; there are total five levels.
- In level 5, the multiplier will stop upgrading. In the rest free games, hitting any winning line will be multiplied by the value of level 5.

ODDS TABLE

- ODDS TABLE

ODDS TABLE

CHAMELEON

WHEN PLAYING ALL 9 LINES AND THE BEADS APPEARING ON THE FIFTH REEL, THE "CHAMELEON TIME" IS TRIGGERED.

	5 2500 4 500 3 50		5 300 4 60 3 12
	5 1500 4 300 3 30		5 200 4 50 3 10
	5 750 4 150 3 20		5 120 4 35 3 7

3 OR MORE		
		
5 80 4 25 3 5	5 50 4 15 3 3	5 30 4 10 3 2

WINNING LINES ARE MULTIPLIED BY THE LINE PLAY.

MALFUNCTION Voids ALL PLAYS AND PAYS.

3 OR MORE SYMBOLS APPEAR, BONUS GAME WILL BE TRIGGERED.

3 OR MORE SYMBOLS APPEAR, 10 TO 20 TIMES OF FREE GAMES WILL BE TRIGGERED.

EXIT TAKE

NEXT INFO

WINNING LINES ARE MULTIPLIED BY THE LINE PLAY.

DOUBLE UP




- After a winning in the main game or bonus game, player can press the **DOUBLE** button to play the Double-up Game.
- Player can take prizes and finish Double Up Game by pressing the **TAKE** button.
- Press the **START** button to select a chameleon on the left or right side to start the Double-up Game.



- If the side selected eats the spider successfully, a winning will be awarded. On the contrary, the player will lose.
- Player can win the double up game five times consecutively at the most; the double up game comes to an end and exits to the main game automatically after the fifth winning.

BONUS GAME



- When 3 or more "  " symbols appear, bonus game will be triggered.



- The beads with multiply numbers will fly out from the pond; player presses start button to catch beads. There are total 5 chances.
- The total multiplying number of beads caught will be recorded on the upper right screen.
- Multiplying the total value of the beads caught for five times and the total bet is the total win.

DRAGON BALL JACKPOT







- There are three “RANDOM” jackpots.
- Play \geq JP MIN. PLAY to initiate “DRAGON BALL JACKPOT” and hit more than 3 symbols, will trigger the “JACKPOT CHANCE” game, in the “JACKPOT CHANCE” game play have chance to get “DRAGON BALL JACKPOT”.



- Select stone to collect dragon ball until match 3 same color of the dragon balls.



- If matching 3 **green**  dragon balls, their prize value will be added together and will be multiplied by the total play.
- Matching 3 **red**  dragon balls, player wins “DRAGON BALL JACKPOT 1”.
- Matching 3 **yellow**  dragon balls, player wins “DRAGON BALL JACKPOT 2”.
- Matching 3 **blue**  dragon balls, player wins “DRAGON BALL JACKPOT 3”.

TROUBLE SHOOTING

If the program detects an error, the corresponding message will be shown on the screen, please find the troubleshooting method as following.

Error Message	Procedure
ROM ERROR	1. Restart the machine.
	2. If step 1 does not solve the problem, please contact the supplier.
RAM ERROR	1. Restart the machine.
	2. Enter the "DATA SETTING" page and press PLAY + INFO to reset.
	3. If steps 1 and 2 do not solve the problem, please either replace the RAM or contact the supplier.
EEPROM ERROR	1. Restart the machine.
	2. If step 1 does not solve the problem, please contact the supplier.
COIN JAM	1. Check the coin acceptor for any jamming.
	2. Restart the machine and go to the main menu to exit.
HOPPER JAM	1. Check the Hopper for any jamming.
	2. Restart the machine and go to the main menu to exit.
HOPPER EMPTY	1. Fill up the coins in the hopper.
	2. Restart the machine and go to the main menu to exit.
CREDIT LIMIT	1. Key out or coin out.
	2. Increase the value of #8. CREDIT LIMIT in the main menu.
DOOR OPEN	Shut the machine door properly.
TICKET EMPTY	Ticket ran out, please replenish.

SPECIAL NOTICE

COIN-IN COUNTER, COIN-OUT COUNTER, KEY-IN COUNTER, AND KEY-OUT COUNTER.

COIN-IN COUNTER:

1. For each coin insert, the COIN-IN COUNTER clicks once.
2. The Coin-in counter unit goes according to the operator setting value.

Any remainder goes to the next counting in the counter.

(i.e. coin-in unit = 10 credits, if remainder= 5 credits, these 5 credits go to the next counting in the meter)

COIN-OUT COUNTER:

1. For each coin out, the COIN-OUT COUNTER clicks once.

KEY-IN COUNTER:

1. For each key in, the KEY-IN COUNTER clicks once.

KEY-OUT COUNTER: Follow the steps on point 4 of DATA SETTING LIST in the main menu.

1. Key out as Coin in.
2. Key out as Key in.

PIN LAYOUT

Connector (36 PIN)

Parts Side	Solder Side	
	1	
	2	
Speaker	3	Speaker Ground
	4	
	5	
	6	
Ticket Out Button	7	
Ticket Notch (Dispenser)	8	
Start/Stop Button	9	
Info/stop1 Button	10	
Play/stop5 Button	11	
Take/stop4 Button	12	
Select Line / Double/stop3 Button	13	
Game Count Pulse	14	
	15	
Auto/stop2 Button	16	
	17	
Coin In Switch	18	Key In Switch
Door Switch	19	
Account 1 Switch	20	Account 2 Switch
Collect Button	21	Key Out Switch
	22	Hopper Switch
Coin In Meter	23	
Key In Meter	24	Hopper SSR
	25	
	26	
Hopper Meter	27	Coin Inhibit
Key Out Meter	28	
Start/stop Lamp	29	Ticket SSR

Info/stop1 Lamp	30	Error Lamp
Play/stop5 Lamp	31	Win Lamp
Take/stop4 Lamp	32	Collect Lamp
Select line/Double /stop3 Lamp	33	Bill in Meter
Auto/stop2 Lamp	34	
	35	
GND	36	GND

Connector (10 PIN)

Parts Side	Solder Side	
GND	1	GND
GND	2	GND
(*1)+5V	3	+5V
+5V	4	+5V
(*1)+12V	5	+12V
+12V	6	+12V
Ticket Dispenser Enable	7	
(*2) Hopper SSR	8	
GND	9	GND
GND	10	GND

(*1) DC+5V 2A and DC + 12V 3A

(*2) This pin is connected with the solder side 24th pin of connector 36 pin.