

MODE

LATCH LOW

**Pop-Up Option Layout** 


EXIT 🖊

For configuration and calibration information please consult the operational manuals on the accompanying USB drive.

Front Layout

Fifth Issue July 2021

indicated by a key ? symbol.



3-Current 4-Relays

5-Current 2-Relays

Modbus 4-Relays

**ECS** 

DO

SS

Aux mA IP

**ECS** 

DO

SS

Aux mA IP

ECS

DO

SS

Aux mA IF