

BQN Installation Guide

Release: 4.9

Bequant, S.L.
Raimundo Fernández Villaverde 61, Planta 5
28003 Madrid
Spain

Copyright © 2009-2022 Bequant S.L.
All rights reserved.

This product or document is proprietary to and embodies the confidential technology of Bequant S.L., Spain. Possession, use, duplication or distribution of this product or document is authorized only pursuant to a valid written license from Bequant S.L.

Bequant assumes no responsibility for any inaccuracies in this document. Bequant reserves the right to change, modify, transfer, or otherwise revise this publication without notice.

End User License Agreement

The Bequant product that is the subject of this technical documentation consists of (or is intended for use with) Bequant software. Use of such software is subject to the terms and conditions of the *End User License Agreement* (EULA). By downloading, installing or using such software, you agree to the terms and conditions of that EULA.

Open Software

The Bequant product contains open source software. See credits and license terms in the *Open Source Licenses* appendix.

Contents

End User License Agreement	ii
Open Software	ii
Preface	v
Intended Audience	v
Conventions	v
1 Introduction	1
2 Installation	3
2.1 System Requirements	3
2.2 Bequant Installation Image	4
2.3 Console Access	4
2.3.1 Physical Console	4
2.3.2 Lights-Out Management (LOM) Interface	4
2.3.3 Serial Console Interface	7
2.4 BIOS Settings	7
2.4.1 Boot Options	7
2.4.2 System Clock	7
2.4.3 Performance Settings	8
2.4.4 Disk Setup	9
2.4.5 Console Redirection	11
2.5 Boot Bequant Installation ISO	12
2.6 Software Installation	13
2.7 LOM Final Configuration	16
3 Post-Installation Configuration	19
3.1 Prerequisites	19
3.2 Automatic Setup	19
3.3 Manual Setup	23
4 Troubleshooting	25
4.1 Overview	25
4.2 Problems Accessing the Management Interface	25
4.3 CPU Usage Issues	26
4.3.1 A process not part of BQN product	27
4.3.2 Not enough IO PKTENG processes	27
4.3.3 Overloaded PKTENG worker	28
4.3.4 CPUs running at lower than expected frequency	29
4.4 Disk Issues	30
4.4.1 Disk Usage Issue	30
4.4.2 Disk hardware issue	31
4.5 Wire Problems (Data Plane Interfaces)	32
4.5.1 Non-Intel Interfaces	34
4.5.2 SFP+ Modules	35

4.6	High Memory Usage	36
4.6.1	Unbalanced DPDK memory usage	37
4.7	License Unavailable Issues	38
4.8	License Expiration Issues	40
4.9	Traffic Above The License Limit	40
4.10	No Traffic in Uplink or Downlink Directions	40
4.11	Traffic Too Low	41
4.12	Traffic Inverted	42
4.13	Process Issues	43
4.14	Time Issues	44
4.14.1	NTP not configured	44
4.14.2	NTP Service not Synchronized	45
4.14.3	Server clock not set to UTC	46
4.15	Contacting Bequant Support	46
A	Virtual Machine Environment	47
A.1	Prerequisites	47
A.2	VMware	47
A.2.1	PCI Passthrough Option	47
A.2.2	VMXNET Option	48
A.3	KVM	48
A.3.1	Virtual Machine Creation	48
A.3.2	Virtual Disk	49
A.3.3	Network interfaces	49
B	Intel Ethernet Controller X710 Firmware Update	51
C	End User License Agreement	55
C.1	Bequant End User License Agreement	55
D	Open Source Licenses	61
D.1	Third Party Software	61

Preface

This guide describes the operation and management of the BQN product.

If the information included in the Release Notes is different from the information in this document, follow the information in the Release Notes.

Intended Audience

This guide is intended for network operators and administrators of a BQN. It assumes that the reader has basic knowledge of operation and management of network equipment.

Conventions

This document uses the following text format conventions:

- | | |
|-------------|--|
| Text | Fixed-width text represents text displayed on the screen. For example:
<code>root@bqn#</code> |
| Text | Fixed-width bold text represents text entered by the user in an interactive session. For example:
<code>root@bqn# show interface</code> |
| <i>Text</i> | Fixed-width italic text represents parameters passed to a command that requires the user to provide a specific value. For example:
<code>interface <i>iface-name</i></code> |

The following syntax conventions are used throughout the document:

- | | |
|-----|---|
| [] | Square brackets enclose optional parameters or keywords. For example, the keyword <code>validate</code> is optional:
<code>commit [validate]</code> |
| { } | Braces enclose required parameters or keywords, and they are used together with pipe symbols to indicate different required keyword choices. For example:
<code>clear config {all candidate}</code> |
| | Pipe symbols separate different keyword choices. They are used together with square brackets and braces to present optional or required keywords. For example:
<code>clear config {all candidate}</code> |
| ... | Ellipses indicate that the previous keyword may be repeated. For example:
<code>ls <i>FILE</i> ...</code> |

Several sections of the guide contain instructions for a specific server type, and those instructions are included inside a shaded box indicating the server type at the top of the box.

 **Dell PowerEdge R230 / R330 / R440**

...

Introduction

The BQN product is a network element that can optimize data traffic applying traffic policies. Policies include acceleration of TCP connections and shaping and rate limits. The BQN product also provides reporting capabilities (e.g. traffic usage per client IP address).

A BQN consists of a physical Intel-based server with a Linux-based operating system that has been customized to run the Bequant software. The BQN is managed through a CLI (Command Line Interface) shell. The CLI provides all the system administration functionality required by a telco-grade network element, including interface and service configuration, logging, monitoring, and software management. A web interface (GUI) is also available over HTTPS to provide basic configuration and monitoring of the system. The GUI is described in the *BQN Quick Start Guide* document.

Installation

2.1 System Requirements

The minimum hardware requirements for a BQN installation are:

- Dual-core AMD64/x86_64 based processor.
- 8 GB of physical RAM memory.
- 50 GB hard drive.
- At least 3 network interfaces: one dedicated interface for management, and the other 2 interfaces for the data plane (for optimal performance, use Intel cards in data plane interfaces of the models listed below).

Depending on the required capacity and performance of the BQN, the following servers are supported:

- HPE ProLiant DL360 Gen9 and Gen10.
- Dell PowerEdge R230 / R330 / R440
- Supermicro SYS-5018D-FN8T / SYS-1029P-WTR

Other servers with similar hardware characteristics may be used as well, although the installation and hardware support may be limited (consult Bequant for approval).

For storage, SSDs (Solid State Drive) are recommended for performance and reliability reasons. Disks which use SATA and SAS interfaces are supported, but currently NVMe (Non-Volatile Memory Express) based disks are not supported.

The BQN supports ethernet for the management and data-plane network interfaces. For the management interface, any ethernet card supported by the *Linux* operating system is valid. For the data-plane side, due to integration and performance reasons, the network interfaces based on the following chipsets are recommended and supported:

- Intel Ethernet Controller I210
- Intel Ethernet Controller I350
- Intel Ethernet Converged Network Adapter X520
- Intel Ethernet Controller X540
- Intel Ethernet Controller X550
- Intel Ethernet Controller X710/XL710/XXV710

The following connectors are supported depending on the network card:

- Copper 1G RJ-45: 1000BASE-T
- Optical 1G SFP: 1000BASE-SX
- Optical 10G SFP+: 10GBASE-SR/1000BASE-SX and 10GBASE-LR/1000BASE-LX
- Optical 40G QSFP+: 40GBASE-SR4 and 40GBASE-LR4

More information about the supported Intel network cards can be found in their web page:

<https://www.intel.com/>

⚠ Please follow all the sections in this chapter in order to install the BQN system correctly.

2.2 Bequant Installation Image

A new installation requires the server to boot an ISO image, the Bequant Installation Image. The ISO image contains the installation programs, operating system and product software.

The integrity of the ISO file should be checked, by comparing the MD5 checksum of the file with the MD5 checksum provided by Bequant. In a UNIX-like operating system the `md5sum` program can be used to compute the MD5 checksum of a file:

```
# md5sum bqnos-R2.0.7-20170410.iso
2b1c3585c58675cf5e4d76b9a85aa8d1  bqnos-R2.0.7-20170410.iso
```

The Bequant Installation Image must be burned into a CD/DVD or a USB flash drive, depending on the device used to boot the installation software. In either case, the ISO image is bootable ready and does not need to be modified.

In a UNIX-like operating system, to burn the ISO file to a USB drive the `dd` standard UNIX tool may be used.

```
# dd if=bqn.iso of=/dev/sdg
```

where `bqn.iso` is the Bequant Installation Image file and `/dev/sdg` is the block device of the USB flash drive. Make sure that you use the correct block device name where the USB flash drive is located in your system. Note that permission to write into the block device is required.

To burn the ISO file to a CD/DVD, any burning software that allows burning an ISO image may be used.

⚠ The ISO file is already a bootable ISO, so it should be burned directly as is.

If *Rufus* (<https://rufus.ie>) is used to burn the ISO, use the following settings:

- Partition scheme: *MBR*
- Target system: *BIOS or UEFI*

The rest of the settings should be left in their default values. Once **START** is clicked, select the *Write in DD Image mode* option to write the ISOHybrid image.

Servers with a lights-out management (LOM) interface, such as the HPE iLO, Dell iDRAC or Supermicro IPMI, allow mounting and booting the ISO file as a virtual drive.

2.3 Console Access

For the installation process, access to the system console is required, which can be performed with one of the methods described in the following subsections.

2.3.1 Physical Console

If the system is connected to a monitor and a keyboard, then restart or power on the server and continue with the instructions in the next section.

2.3.2 Lights-Out Management (LOM) Interface

A system with a lights-out management (LOM) interface that provides system console access may be used (e.g. Dell iDRAC, HPE iLO, IBM IMM).

In general, to access the LOM interface in the server you need a laptop or other PC with a browser that supports Java, such as *Chrome* or *Firefox*. Make sure that the laptop has the latest version of Java installed; otherwise, install it from

<http://www.java.com>

Dell PowerEdge R230 / R330 / R440

The iDRAC network port may be a dedicated ethernet port or shared with the server embedded NIC, depending on the purchased server. In order to use the virtual console feature the *iDRAC Enterprise* license must be installed in the server.

The iDRAC interface is factory pre configured with the **192.168.0.120/24** static IP address and **192.168.0.1** gateway. You may modify it through the LCD panel on the front of the server, using the arrow and select keys and following the instructions provided.

By default the iLO uses the following TCP ports:

- Web server SSL port: 443
- Remote virtual console port: 5900

Launch the virtual console by following these steps:

1. Log into the iDRAC web page using the *root* user name and *calvin* default password (if the server was shipped from Bequant or one of its integrators, the default password is the Service Tag, which is available on the front of the server by pulling out the information tag).
2. If the Dell default password is still set, an option is available to change it to whatever value you want.
3. Navigate to the *Overview*→*Server*→*Virtual Console* page.
4. Click *Virtual Console Viewer* to launch the virtual console window.
5. If one of more Security Alert windows appear while launching the viewer click *Yes* to continue.

Visit the following Dell page to get more information about the iDRAC:

<http://www.dell.com/idracmanuals>

Reboot or power on the server to proceed with the installation and follow the instructions in the next section.

HPE ProLiant DL360 Gen9 / Gen10

The iLO port is a standard 1GbE RJ45 Ethernet port located in the back of the server. In order to use the virtual console feature the *iLO Advanced* license must be installed in the server.

By default the iLO uses the following TCP ports:

- Web server SSL port: 443
- Remote virtual console port: 17990
- Virtual media port: 17988

By default the iLO is setup with a DHCP client to get the network configuration. If the server is connected to a network where a DHCP server supplies the IP configuration, then connect the installation laptop (or any other system) to the same network to access the server; otherwise, follow the steps below to setup a network connection with the server:

1. Connect with an ethernet cable the server directly to the installation laptop to access the server.
2. Start a DHCP server program in the laptop to supply the network configuration to the server.
For Windows systems, the TFTP32 opensource software may be used as the DHCP server.
 - a) Download the latest version of the TFTP64 portable edition from:
http://tftpd32.jounin.net/tftpd32_download.html
 - b) Extract the contents of the ZIP file downloaded.
 - c) Execute the program **tftpd64.exe** as an Administrator user.

- d) If Windows Firewall is enabled, allow the `tftpd64.exe` program to access the public network if a windows asking for permission is displayed.
 - e) In the TFTP32 window press the **Settings** button.
 - i. Under the *GLOBAL* tab, clear all the selections and enable *DHCP*.
 - ii. Under the *DHCP* tab, enter the following information:
 - IP pool start address: `192.168.0.10`
 - Size of pool: `10`
 - Def. router: `192.168.0.1`
 - Mask: `255.255.255.0`
 - iii. Press **OK** in order to apply the settings.
 - f) Restart the program if requested in order to apply the settings.
 - g) Verify that the *Software Loopback Interface* is selected as the *Server Interface*.
 - h) Both the laptop and the server are supplied an IP address, which is shown in the main window (usually the second address is supplied to the server).
3. Verify that the server IP address may be reached from the laptop.

Once the server is connected to the laptop, start a web browser to access the iLO web interface and enter the following URL (where 192.168.0.11 in this example is the IP address assigned to the server):

`https://192.168.0.11`

In some cases the browser shows an unsafe warning indicating that its security certificate may not be installed, but it can be ignored and you may proceed to the web page.

Get the virtual console by following these steps:

1. Log into the iLO web page using the *Administrator* user and password (the default password is printed on a label on top of the server).
2. Navigate to the *Remote Console*→*Remote Console* page.
3. Click the *Web Start* button. Depending on the web browser, accept that Java Web Start Launcher executes the Java IRC JNLP file.
4. If prompted, confirm by pressing *Run* that you want to run the application, and click *Continue* if a security warning is displayed.

The iLO Integrated Remote Console should be displayed.

Reboot or power on the server by selecting *Power Switch* and *Momentary Press* and follow the instructions in the next section.

Supermicro

The dedicated IPMI LAN port is the one located on the top-left side (front or back, depending on the model). Servers shipped by Bequant are configured so the IPMI port is also sharing the BQN management port (the integrated port on the bottom-left side).

By default IPMI uses the following TCP ports:

- Web server SSL port: 443
- Remote virtual console port: 5900
- Virtual media port: 623

Launch the virtual console by following these steps:

1. Log into the IPMI web page using the *ADMIN* user name and *ADMIN* default password (if the server was shipped from Bequant or one of its integrators, the username is *root* and the password is the serial number, which is available on the back of the server).
2. Navigate to the *Remote Control*→*Console Redirection* page.
3. Click *Launch Console* to launch the virtual console window.
4. If one of more Security Alert windows appear while launching the viewer click *Yes* to continue.

Visit the following page to get more information about the IPMI console:

<https://www.supermicro.com/support/resources/>

Reboot or power on the server to proceed with the installation and follow the instructions in the next section.

2.3.3 Serial Console Interface

A system with a serial port may use the serial console interface for installation.

Cambium Networks cnMaestro-Advantech / Allot ATCA Blade

These servers have a console port in the front panel that provides a serial console to access the system. Follow these steps to setup the console:

1. Connect a serial cable to the serial port in the front panel (marked as **CONSOLE**). Note that the serial cable must have an RJ45 connector to plug it into the server.
2. Start a terminal communication program (such as *miricom* or *screen*) in the system connected to the server over the serial cable. Make sure that the serial device is recognized and install the appropriate drivers if needed.
Under Linux, if a USB serial adapter is connected to the system, usually the device used is `/dev/ttyUSB0`, and the device should be automatically supported by the kernel without having to install additional drivers.
3. Configure the terminal software with the following parameters for the serial device:
 - 115200 baud
 - 8 data bits
 - no parity
 - 1 stop bit
 - no flow control

Wait for activity in the terminal or press **ENTER** several times to verify that the serial connection has been established.

Restart or power on the system. On the Allot ATCA blade, unlatching the 2 handles and reinserting them reboots the system, and follow the instructions in the next section

2.4 BIOS Settings

2.4.1 Boot Options

The ISO supports both *legacy/MBR/BIOS* mode or *UEFI* mode. Many modern servers only support *UEFI* boot mode, but for the rest, either mode is available.

The boot mode is selected in the BIOS/System settings under the *Boot Mode* or *Boot Options* section. In order to access the BIOS/System settings you may have to press a special key during the Power-On Self Test (POST) sequence (it may be **F2**, **F9**, **DEL** or some other key displayed on the screen).

⚠ If UEFI mode is selected as the boot mode make sure that *Secure Boot* is **disabled** in the BIOS/System settings (under the *Boot Mode* or *Boot Options* section).

2.4.2 System Clock

It is necessary that the system clock is set with the correct time and date before proceeding with the installation. The system clock will most likely be set in the BIOS menu.

▲ The system time must be set to Coordinated Universal Time (UTC).

The current UTC time can be obtained at this page:

<https://www.timeanddate.com/worldclock/timezone/utc>

Dell PowerEdge R230 / R330 / R440

Follow the next instructions to verify and change the system clock.

1. Enter the *System Setup* screen during the server Power-On Self Test (POST) sequence by pressing **F2**.
2. Then select *System BIOS*→*Miscellaneous Settings*, and change the time under *System Time* and the date under *System Date*.
3. Click **Exit** to save the changes.

HPE ProLiant DL360 Gen9 / Gen10

Follow the next instructions to verify and change the system clock.

1. Enter the *System Utilities* screen during the server Power-On Self Test (POST) sequence by pressing **F9**.
2. Then select *System Configuration*→*BIOS/Platform Configuration*→*Date and Time* option.
3. Change the time and date and set the *Time Zone* to *UTC-00:00* and disable *Daylight Savings Time*.
4. Press **F10** to save the changes.

Supermicro

Follow the next instructions to verify and change the system clock.

1. Enter the *BIOS Setup* screen during the server Power-On Self Test (POST) sequence by pressing the **DEL** key.
2. On the *Main* tab, go to the *System Date* option and select each date field to modify its value with the **-** or **+** keys. Use the **TAB** key to switch from one field to the other.
3. On the *Main* tab, go to the *System Time* option and select each time field to modify its value with the **-** or **+** keys. Use the **TAB** key to switch from one field to the other.
4. Press **F4** to confirm and save the changes.

2.4.3 Performance Settings

The BIOS provides several settings that improve system performance.

Dell PowerEdge R230 / R330 / R440

Follow the next instructions to activate some high-performance settings:

1. Enter the *System Setup* screen during the server POST sequence by pressing **F2**.
2. Then select *System BIOS*→*System Profile*, and ensure that the power profile selected is *Performance*.
3. Click **Exit** to save the changes.

HPE ProLiant DL360 Gen9

Follow the next instructions to activate some high-performance settings:

1. Enter the *System Utilities* screen during the server POST sequence by pressing **F9**.
2. Then select *System Configuration*→*BIOS/Platform Configuration*→*Power Management* option.
3. Change the *Power Profile* to *Maximum Performance*.
4. Press **ESC** to go back to the *BIOS/Platform Configuration* menu.
5. Select *Performance Options*→*Advanced Performance Tuning Options*.
6. Change the *QPI Bandwidth Optimization (RTID)* option to *Optimized for I/O (Alternate RTID)*.
7. Disable the *I/O Non-posted Prefetching* option.
8. Press **F10** to save the changes.
9. Press **ESC** several times to get to the top of the *System Utilities* menu and select *Reboot the System* to apply the changes.

HPE ProLiant DL360 Gen10

Follow the next instructions to activate some high-performance settings:

1. Enter the *System Utilities* screen during the server POST sequence by pressing **F9**.
2. Then select *System Configuration*→*BIOS/Platform Configuration* option.
3. Change the *Workload Profile* to *I/O Throughput*.
4. Press **F10** to save the changes.
5. Press **ESC** several times to get to the top of the *System Utilities* menu and select *Reboot the System* to apply the changes.

2.4.4 Disk Setup

Multiple hard drives together with hardware RAID (Redundant Array of Independent Disks) support should be used for redundancy. If no RAID controller is available, then skip this section.

Note that in most cases, the RAID controllers require that the disks available to the operating system must be defined in the RAID controller configuration, even if there is only one disk or if no RAID redundancy scheme is used. Therefore, it is necessary to create a logical or virtual drive inside the RAID controller. In addition, the logical or virtual drive must be marked as a bootable disk.

The RAID controller configuration is usually available during the server Power-On Self Test (POST) sequence. If there is only one physical disk, then configure RAID 0; otherwise, the preferred RAID level is RAID 1 (mirroring), and if several disks are available, then RAID 1+0 (stripe of mirrors) should be used. If there is an odd number of hard drives, the remaining disk may be used as a spare.

Dell PowerEdge R230 / R330 / R440

By default the Dell PowerEdge R230 and R330 have one disk and RAID pass-through is enabled, which means that no configuration is required and the disk is already visible by the operating system.

If several disks are available and RAID is required, follow these instructions to enable RAID and setup a virtual drive (note that all the information stored in the disks will be erased):

1. Enter the *System Setup* screen during the server POST sequence by pressing **F2**.
2. Select the *Device Settings*→*Integrated RAID Controller* option to enter the controller Main Menu. Note that the RAID model number is also displayed (*Dell PERC H330 Adapter* in the PowerEdge R330).

3. Select the *Configuration Management*→*Convert to RAID Capable* option to convert a non-RAID disk to RAID capable, and select all the physical disks and press *OK*, and confirm the conversion and press *Yes*. Once the disks have been converted to RAID go back to the main menu.
4. Select the *Configuration Management*→*Create Profile Based Virtual Disk* option, and then select the RAID level: *Generic RAID0* if there is only one disk or *Generic RAID1* if multiple disks are available.
5. Accept all the parameters by default and at the bottom of the page select *Create Virtual Disk*, mark the *Confirm* option and press *Yes* to create the virtual disk.
6. Verify that the Virtual disk is bootable by selecting *Controller Management* from the Main Menu, and that the *Select Boot Device* field contains the virtual disk recently created.
7. Exit the *System Setup* menu to continue with the setup.

In case you choose to convert a RAID enabled setup to a non-RAID setup, follow this instructions (note that all the information stored in the disks will be erased):

1. Enter the *System Setup* screen during the server POST sequence by pressing **F2**.
2. Select the *Device Settings*→*Integrated RAID Controller* option to enter the controller Main Menu. Note that the RAID model number is also displayed (*Dell PERC H330 Adapter* in the PowerEdge R330).
3. Select the *Configuration Management*→*Clear Configuration* option, mark the *Confirm* option and press *Yes*.
4. From the Main Menu, select the *Configuration Management*→*Convert to Non-RAID Disk* option, and select the physical disks, and press *OK*, and confirm the conversion and press *Yes*.
5. Verify that the physical disk where the operating system will be installed is bootable by selecting *Controller Management* from the Main Menu, and that the *Select Boot Device* field contains the desired physical disk.
6. Exit the *System Setup* menu to continue with the setup.

HPE ProLiant DL360 Gen9 / Gen10

Follow the appropriate instructions depending on whether the server has a physical controller card or a software RAID.

• Smart Array Controller

On the HPE ProLiant DL360 server with a Smart Array Controller (a physical hardware controller, not a software RAID which is not supported and is handled below), such as the *HPE Smart Array P408i-a*, follow these steps to verify and setup the disk configuration:

1. Enter the *Intelligent Provisioning* menu during the server POST sequence by pressing **F10**. Note that it may be necessary to reboot the server first to reach this menu or if there were pending changes to be applied.
2. Select the *HPE Smart Storage Administrator* option.
3. Create an Array (if it does not exist already).
4. Assign the physical disks to create the logical drive.
5. Depending on the number of disks available, the appropriate RAID level should be selected as explained above.
6. Once the logical drive has been created, assign it as the primary bootable disk.

Once the disk array has been configured, exit the setup menu and reboot the server.

• Smart Array Software RAID

On HPE ProLiant servers with a Smart Array software RAID, such as the *Smart Array S100i SR Gen10 RAID*, the legacy boot mode is not supported and the Smart Array software RAID must be disabled following these steps:

1. Enter the *System Utilities* screen during the server Power-On Self Test (POST) sequence by pressing **F9**.

2. Then select *System Configuration*→*BIOS/Platform Configuration*→*Storage Options*→*SATA Controller Options* option.
3. Change the *Embedded SATA Configuration* option to *SATA AHCI Support*.
4. Press **F10** to save the changes.
5. Press **ESC** several times to get to the top of the *System Utilities* menu and select *Reboot the System* to apply the changes.

2.4.5 Console Redirection

Enable console redirection after the BIOS POST sequence.

Dell PowerEdge R230 / R330 / R440

Follow the next instructions to enable console redirection:

1. Enter the *System Setup* screen during the server POST sequence by pressing **F2**.
2. Then select *Network* and press **ENTER**.
3. Find the *Enable NIC* option and ensure it is set to *Enabled*.
4. On the *NIC Selection* option, check that the current NIC used to communicate with IPMI is selected.
5. Then, locate the *IPV4 SETTINGS* tab, and ensure that the *Enable IPV4* option is set to *Enabled*. The IP address, netmask and other network parameters will be set later on during the installation.
6. Click **Exit** to save the changes.

HPE ProLiant DL360 Gen9 / Gen10

Follow the next instructions to enable console redirection:

1. Enter the *System Utilities* screen during the server POST sequence by pressing **F9**.
2. Then select *System Configuration*→*iLO Configuration Utility*→*Network Options* option.
3. Ensure that the current port used to reach IPMI is selected in the *Network Interface Adapter* option.
4. Press **ESC** to go back one level to the *iLO Configuration Utility* menu.
5. Select *Setting Options* and press **ENTER**.
6. Ensure both *iLO Functionality* and *iLO Configuration Utility* are enabled.
7. Press **F10** to save the changes.
8. Press **ESC** several times to get to the top of the *System Utilities* menu and select *Reboot the System* to apply the changes.

Supermicro

Follow the next instructions to enable console redirection:

1. Enter the *BIOS Setup* screen during the server Power-On Self Test (POST) sequence by pressing the **DEL** key.
2. On the *Advanced* tab, go to the *Serial Port Console Redirection* option and enter it.
3. Ensure that the *SOL Console Redirection* option is set to *Enabled* (press **ENTER** to change it in a submenu).
4. Press **F4** to confirm and save the changes.

2.5 Boot Bequant Installation ISO

If physical access to the system is available, insert the USB drive or CD/DVD containing the Bequant Installation ISO, as described in the *Bequant Installation Image* section.

HPE ProLiant DL360 Gen9 / Gen10

On the HPE ProLiant DL360 server, if the remote console iLO is used for installation and the server is not accessible, follow these instructions to create a virtual DVD with the BQN ISO:

1. Select the *Virtual Drives* menu on the remote console window and select the *Image File CD/DVD-ROM* option.
2. In the dialog window, select the ISO file containing the BQN installation software image.

Supermicro

On the Supermicro server, if the remote console is used for installation and the server is not accessible, follow these instructions to create a virtual DVD with the BQN ISO:

1. Select the *Virtual Media* menu on the remote console window and select the *Virtual Storage* option.
2. Under the *Logical Drive Type* the pull-down selector choose the *ISO File* option.
3. Press the *Open Image* button and browse for the ISO file containing the BQN installation software image.
4. Press the *Plug in* button to enable the virtual drive.
5. Press **OK** to create the virtual drive.

Start or reboot the system to boot the Bequant Installation image. Make sure that the USB or CD/DVD is selected for booting. The device boot order is permanently configured in the BIOS settings, but it may also be possible to select a one-time boot device.

Dell PowerEdge R230 / R330 / R440

On the Dell PowerEdge server, follow these steps to boot the BQN ISO:

1. Enter the *Boot Manager* screen during the server POST sequence by pressing **F11**.
2. Then enter *One-shot Boot Menu*, and select the removable device holding the BQN ISO.

HPE ProLiant DL360 Gen9 / Gen10

On the HPE ProLiant DL360 server, to boot the BQN ISO:

1. After the POST sequence, press **F11** to enter into the *One-Time Boot Menu*.
2. If the Bequant image was burned to a CD/DVD or the ILO Virtual Media was used, enter **1** to select *One Time Boot to CD-ROM*.
3. If the Bequant image was burned to a USB drive, enter **3** to select *One Time Boot to USB DriveKey*.

Supermicro

On the Supermicro server, to boot the BQN ISO:

1. After the POST sequence, press **F11** to enter into the one-time *Boot Menu*.
2. If the Bequant image was burned to a USB drive select it from the list of devices.
3. If a virtual drive was created with the ISO image, then select the *Virtual CDRom* entry from the list of devices.

Allot ATCA Blade

On the Allot ATCA blade, the USB drive is automatically booted by default.

2.6 Software Installation

Once the Bequant Installation image loads the bootloader, it presents several boot options (shown in Figure 2.1):




Figure 2.1 Boot menu.

- *BQN OS installation*: This is the default option for all installations except when a serial console is used. Note that this option will boot after 10 seconds if no keys are pressed, or press **ENTER** to proceed.
- *BQN OS installation (serial)*: This option should be selected on systems with a serial console, such as the Cambium Networks cnMaestro. Use the **UP** and **DOWN** arrow keys to select this option and press **ENTER** to proceed.
- The rest of the options should only be used if indicated by Bequant engineers.

After the operating system boots, the Bequant installation program is started automatically.

Allot ATCA Blade

On the Allot ATCA Blade, the Bequant installation program must be started manually:

1. As indicated on the screen, press **CTRL-D**.
2. Enter the following command to reset the terminal:


```

Welcome to rescuPress enter for maintenance(or type Control-D to continue):
linux:~ # stty sane
linux:~ #
      
```
3. Execute the installation program at the prompt:


```

linux:~ # /bqn/sbin/bqninstall -f
      
```

Follow these steps to install the BQN software in a server:

1. Select *Install* at the main *BQN Installation* screen.
2. If the system only has one disk, then proceed to the next step; otherwise, the installation program shows all the available disks and asks the user to select where the BQN software should be installed, as shown in Figure 2.2. The disk type and size is displayed for each disk for better identification.

⚠ Note that if a USB drive is used as the installation medium it may be displayed in the list of available disks, sometimes selected by default in first position. If that happens, scroll down the list to select the right hard disk.




Figure 2.2 Disk selection menu.

3. Select whether to perform a default or a custom partition of the disk.

The default partition scheme uses the whole disk and erases all the existing data. This partition scheme creates a swap partition with a size equal to the amount of physical RAM memory, and the rest of the disk space is reserved for the *BQN OS* linux partition.

Select the *default* partition scheme unless the server is shared with another operating system, it is requested by Bequant or you need to change the disk label format or the swap size (see boxes below).

⚠ Note that the disk must use the DOS or MBR disk label format. If the server is being reused from a previous installation, it may not have either of those formats. The format can be changed using the `fdisk` command as indicated below in the *Advanced* box.

⚠ If the server has more than 64 GB of RAM (e.g. 128 GB), the swap should be set to a maximum of 64 GB, using the `fdisk` command as indicated below in the *Advanced* box.

⚙ **Advanced (optional)**

The *custom* partition scheme allows the user to manually create and select the partitions to be used, without modifying any other existing partitions. The installation program will show all the available swap and linux partitions (type 82 and 83 respectively), as shown in Figure 2.3, and will allow the user to modify the partition table with the *fdisk* utility.

The installation requires 2 partitions:

- a) Linux swap: `fdisk` type 82
- b) Linux partition: `fdisk` type 83

If a partition type does not exist, a new one must be created using the *fdisk* utility. The following *fdisk* commands are used to modify the partition table:

- `n`: Create a new partition, either a primary of a logical partition (inside an extended partition).
- `p`: Print the partition table.
- `d`: Delete a partition.
- `t`: Change the partition system ID, which is set to *Linux* (83) by default. For a *Linux swap* partition the system code is 82.

- o: Create an empty DOS partition table. This command is required if the disk was previously partitioned with a different partition table type, such as GPT (if UEFI was used).
- w: Write partition table to disk and exit.
- q: Quit without saving changes.




Figure 2.3 Linux partition selection menu.

4. Confirm the partition selections to proceed with the installation of the BQN operating system. This process step may last for a few minutes while the progress percentage is displayed.
5. After the BQN software as been installed, select the console keyboard mapping. Note that the United States (*us*) keymap is selected by default. Scroll the different options with the UP and DOWN arrow keys, press SPACE to select a keymap and finally press ENTER to accept the selection.
6. Enter a hostname for the BQN or press ENTER to accept the default value.

☰ All Servers

Note that pre configured BQNs usually use the following naming convention:

`bqnclient`

where *client* is the name or some abbreviation where the BQN will be deployed (e.g. `bqnref` at Telefonica). If several BQNs may be deployed at the same client, use a number at the end of the name to differentiate all the BQNs (e.g. `bqnref1`).

7. Select the timezone to use in the BQN. Note that *Europe/Madrid* is selected by default. Scroll the different options with the UP and DOWN arrow keys, press SPACE to select a timezone and finally press ENTER to accept the selection.

⚠ Make sure you select the right timezone corresponding to the server's location.

Note that the timezone may be changed at any time using the `system date timezone` command.

8. Enter the *root* user password twice.
Note that a user password can be changed at any time using the `system users passwd` command.

☰ Dell PowerEdge R230 / R330 / R440

Pre configured Dell PowerEdge servers should use the Service Tag as the default password.

☰ HPE ProLiant DL360 Gen9 / Gen10

Pre configured HPE ProLiant servers should use the HPE server serial number as the root password. The serial number is printed on a label on top of the server.

Supermicro

Pre configured Supermicro servers should use the serial number as the default password. The serial number is printed on a label on the back of the server.

9. Install the bootloader at the Master Boot Record (MBR). If more than one disk is available, indicate whether the other disks are removable or not.
10. If the installation process detects that there was a working BQN OS installed in the same operating system partition being used now, then it is possible to restore the old BQN configuration. If the configuration is restored, skip the rest of steps. Note that only the configuration is restored, users such as `bqnadm` and `bqnop` will have to be created using the `system users add` command.
11. The installation process may setup the BQN management interface of the BQN by pressing **YES**; otherwise, press **NO** and skip the rest of the steps.
12. Select the network interface used for management if multiple interfaces are available (see the *Locating Network Interfaces* section in the *User Guide* to select the desired management interface) and enter the management IP address used by the BQN. In addition, enter the gateway used to set the default route if required.

Dell PowerEdge / HPE ProLiant / Supermicro

On pre configured Dell PowerEdge and HPE ProLiant servers, the first embedded network interface should be used as the management interface: `en001`.

In addition, pre configured servers use the `192.168.0.121/24` management IP address and the `192.168.0.1` gateway IP address.

At this point the BQN OS has been installed successfully.

Confirm the system reboot to apply the changes and remove the installation media so that the BQN boots the installed operating system.

⚠ If the system does not reboot after one minute, manually reset the system to boot the operating system.

2.7 LOM Final Configuration

To access the lights-out management (LOM) interface from the management network, it is recommended to configure an IPv4 static address.

Dell PowerEdge R230 / R330 / R440

The iDRAC interface is factory pre configured with the `192.168.0.120/24` static IP address and `192.168.0.1` gateway. You may modify it through the LCD panel on the front of the server, using the arrow and select keys and following the instructions provided.

The iDRAC settings can also be modified through the web page:

1. Log into the iDRAC web page using the `root` user and password (if the server was shipped from Bequant or one of its integrators, the default password is the Service Tag, which is available on the front of the server by pulling out the information tag).
2. Navigate to the *Overview*→*iDRAC Settings*→*Network* page.
3. Under the *IPv4 Settings* section enter the required network configuration.
4. Click *Apply* to commit the changes.

The factory default password for the `root` user is `calvin`. If the server has to be shipped to a customer, change the password to the Service Tag value (available on the front of the server by pulling out the information tag).

If access to the system console is available, follow these instructions to change the iDRAC password:

1. Enter the *System Setup* screen during the server Power-On Self Test (POST) sequence by pressing F2.
2. Select the *iDRAC Settings*→*User Configuration* option
3. Enter the *root* password in the *Change Password* field and confirm it.
4. Go back to the *System Setup* screen and confirm that the settings must be saved.
5. Exit the *System Setup* menu to continue with the setup.

If the iDRAC is accessible through the internet, follow these instructions to change the iDRAC password:

1. Log into the iDRAC web page using the *root* user and password.
2. Select the *Change Default Password* option and enter and confirm the new password.
3. Click *Continue* to commit the changes.

HPE ProLiant DL360 Gen9 / Gen10

On the HPE ProLiant DL360 there is an iLO dedicated ethernet port on the back of the server. If the iLO dedicated network port is used then follow these steps to configure a static IP address (skip this set of instructions if the shared network port will be used instead):

1. Log into the iLO web page using the *Administrator* user and password (the default password is printed on a label on top of the server).
2. Navigate to the *Network*→*iLO Dedicated Network Port* page.
3. Click the *IPv4* tab.
4. Disable DHCP by clicking the *Enable DHCPv4* check box to deselect the option.
5. Enter the IP address in the *IPv4 Address* field (e.g. 192.168.0.120).
6. Enter the IP address mask in the *Subnet Mask* field (e.g. 255.255.255.0).
7. Enter the gateway IP address in the *Gateway IPv4 Address* field (e.g. 192.168.0.1).
8. Apply the configuration by pressing the *Submit* button.

In deployments where there is only one physical cable for the management network, it is possible to configure both the iLO and the server operating system to share the same LAN port. Follow these steps to share the network port:

1. Log into the iLO web page using the *Administrator* user and password (the default password is printed on a label on top of the server).
2. Navigate to the *Network*→*Shared Network Port* page.
3. Click the *General* tab.
4. Select the *Use Shared Network Port* check box.
5. Depending on the server configuration, select LOM, or FlexibleLOM.
6. Select a value from the *Port* menu.
7. To use a VLAN, select the *Enable VLAN* check box and enter VLAN tag.
8. Click *Submit* to apply the changes.

Note that the IPv4 settings for the shared network port are different than the settings for the iLO dedicated network port. Therefore, to set an IPv4 static address using the shared network port follow these instructions:

1. Navigate to the *Network*→*Shared Network Port* page.
2. Click the *IPv4* tab.
3. Disable DHCP by clicking the *Enable DHCPv4* check box to deselect the option.
4. Enter the IP address in the *IPv4 Address* field (e.g. 192.168.0.120).
5. Enter the IP address mask in the *Subnet Mask* field (e.g. 255.255.255.0).

6. Enter the gateway IP address in the *Gateway IPv4 Address* field (e.g. 192.168.0.1).
7. Apply the configuration by pressing the *Submit* button.

Note that the iLO may need to be reset in order to apply the changes:

1. Navigate to the *Network→iLO Dedicated Network Port* or the *Network→Shared Network Port* page, depending on the configuration used.
2. Click the *General* tab.
3. Press the *Reset* button and confirm that the changes will be applied.

The iLO reset may take a few minutes until access to the server is restored with the new settings. After the IP address has changed, it may be necessary to login again using the new static IP address. If the shared network port was configured, the cable connecting to the management network can be plugged into the selected LAN port.

Supermicro

The IPMI interface is factory pre configured with the 192.168.0.120/24 static IP address and 192.168.0.1 gateway.

The IPMI network settings can be modified through the web page:

1. Log into the IPMI web page using the *root* user and password (if the server was shipped from Bequant or one of its integrators, the default password is the serial number, which is available on the back of the server).
2. Navigate to the *Configuration→Network* page.
3. Select the *Use the following IP address* toggle.
4. Under the *IPv4 Setting* section enter the required network configuration.
5. Click *Save* to commit the changes.

If access to the system console is available, the IPMI network settings can be modified using these instructions:

1. Enter the *BIOS Setup* screen during the server Power-On Self Test (POST) sequence by pressing the **DEL** key.
2. On the *IPMI* tab, go to the *BMC Network Configuration* option and press **ENTER**.
3. Make sure that *Update IPMI LAN Configuration* is set to *Yes*.
4. Set the *Configuration Address Source* option to *Static*.
5. Enter the correct IP address, subnet mask and gateway IP address. If a VLAN is required, enable the *VLAN* option and enter the *VLAN ID* tag.
6. Press **F4** to confirm and save the changes.

If the server has to be shipped to a customer, change the password to the serial number value (available on the back of the server or under the *System→Hardware Information* page).

1. Log into the IPMI web page using the *ADMIN* user and the default *ADMIN* password.
2. Navigate to the *Configuration→Users* page.
3. Select the existing *ADMIN* user click the *Modify User* button.
4. Select the *Change Password* toggle and enter the new password.
5. Click the *Modify* button.
6. Select the next available user entry and click the *Add User* button.
7. Enter *root* as the user name and the server's serial number as the password. Make sure that the *Network Privileges* option is set to *Administrator*.
8. Click the *Add* button.

Post-Installation Configuration

This chapter provides a quick guide to configure a BQN with the Bequant TCP Acceleration (BTA) service.

3.1 Prerequisites

This section describes the information needed to configure a BQN. It assumes that the BQN has been successfully installed following the instructions in the *Installation* chapter.

Basic IP information for the management interface:

- IP address and network prefix length of the assigned BQN management interface.
- Gateway IP address in the management network.
- Interface and VLAN ID, if any, for the BQN management interface.
- IP address of Network Time Protocol (NTP) server.

Other optional information:

- IP address, network prefix length and gateway for the server lights-out management (LOM) interface.
- If SNMP is configured, the IP address of the SNMP Network Management System (NMS) is needed, together with its SNMP community string.

In addition, the network where the BQN is being deployed will need steering of user traffic through the Bequant data interfaces (those used to process traffic). Traffic routing should be symmetrical (uplink and downlink directions). Also, it is necessary the appropriate routing of management traffic to reach the OAM and LOM IP addresses.

3.2 Automatic Setup

This section describes how to configure a BQN. The BQN will be configured to optimize traffic between an access network and the internet using the network configuration shown in Figure 3.1. Note that the BQN may be directly connected to the routers or through switches. BQN data interfaces are associated in pairs called *wires*. A wire behaves as a 2-port transparent bridge (a *bump-in-the-wire*), with traffic coming into one interface going out the other interface and vice versa. Wires are directional: the first interface in the pair must be connected to the access side router/switch and the second port to the Internet side.

References to the different sections in the user guide are indicated for further information.

Step 1: Installation

If the server does not have the BQN Software installed, follow the *Installation* chapter instructions to install the software. Make sure you configure a management IP address and default gateway during the process.

As instructed, reboot the system after the software has been installed and the installation media has been removed.




Figure 3.1 Network topology in wire mode.

Step 2: Update to latest BQN version

The ISO many not contain the latest BQN package (BPKG). To transfer the BPKG package you will need an scp client, and a ssh client to access the server shell. Linux and OSX have `ssh` and `scp` by default, as well as Windows PowerShell starting at Windows 10. For older Windows versions, one example of popular clients are *putty* and *pscp* respectively (see <https://www.putty.org>). In this example, we will install a BQN package `bqn-R3.1.17.bpkg` in a BQN server with OAM IP address 192.168.0.121. First, we transfer the BPKG to the BQN server:

```
mylaptop$ scp ./bqn-R3.1.17.bpkg root@192.168.0.121:
Password:
bqn-R3.1.17.bpkg                               100%  18MB  1.3MB/s   00:13
```

Log in as `root` via SSH and start the BQNSH shell.

```
mylaptop$ ssh root@192.168.0.121
bqn0:/ # bqnsb
Copyright (c) 2009-2015 Bequant S.L.
root@bqn0#
```

Install the latest BQN package and activate it (reload):

```
root@bqn0# system software install /root/bqn-R3.1.17.bpkg
Name:      bqn
Version:   R3.1.17
Priority:   50
Size:      18585542
Reload:    1
Files:     2
```

Install package "bqn-R3.1.17"

Enable boot flag

```
root@bqn0# system software reload bqn R3.1.17
Package "bqn-R3.1.2" must be stopped first.
```

WARNING: Service may be interrupted during the reload

```
Continue? (yes/no): yes
root@bqn0#
%ERR-EI0: Process terminated
bqn0:/ #
```

Start the BQNSH shell again (it may take a few seconds while the software is reloading).

```

bqn0:/ # bqnsb
Copyright (c) 2009-2015 Bequant S.L.
root@bqn0#

```

Step 3: Execute the BTA wizard tool.

The `wizard bta` command will collect system information about the server and will perform the following tasks:

- Obtain server vendor and model, CPU information and network interfaces available.
- Create default operator and administrator users.
- Configure the NTP service and set several public NTP servers.
- Configure the management network interface and enable the SSH service.
- Enable the WEB service.
- Create one or more *wires* (depending on the number of available network interfaces and their physical location).
- Configure the packet engine feature to forward traffic.
- Configure the BTA feature to accelerate 99% of the TCP connections randomly and to measure the acceleration.
- Configure the generation of SDRs to have metrics of traffic consumption per client IP address.
- UDR generation is left disabled by the wizard.

Execute the BTA wizard command.

```

root@bqn0# wizard bta
System vendor: Dell Inc.
System name: PowerEdge R230
System serial: M9PJML5
System supported: yes
CPU model: Intel(R) Xeon(R) CPU E3-1220 v6 @ 3.00GHz
CPU cores: 4

```

```

Management interface: en0o1
Management IP: 192.168.0.121/24
Management gateway: 192.168.0.1

```

```

Wire 1: en0p2s0f0-en0p2s0f1

```

```

BTA random acceleration: 99%

```

If the proposed configuration is not valid execute the command
`wizard bta interactive`
to manually enter the configuration.

```

Proceed with configuration? (yes/no) [yes]: yes

```

Step 4: Confirm configuration parameters.

If any of the configured parameters are not correct, abort the execution of the wizard command (i.e. say **no** to proceed with the installation) and execute it interactively to select individual parameters with `wizard bta`. In any case, note that the generated configuration can be changed at any time. Confirm that the configuration is correct and proceed with the setup (press **ENTER** to continue):

```

Proceed with configuration? (yes/no) [yes]: yes
Set "bqnadm" user password to "M9PJML5"
Set "bqnop" user password to "M9PJML5"
root@bqn0#

```

Note that the passwords for the *bqnadm* and *bqnop* users can be changed with the `system users passwd` command.

Dell PowerEdge R230 / R330 / R440

For pre configured Dell PowerEdge servers use the Service Tag as the default password.

HPE ProLiant DL360 Gen9 / Gen10

For pre configured HPE ProLiant servers use the serial number as the default password. The serial number is printed on a label on top of the server.

Supermicro

For pre configured Supermicro servers use the serial number as the default password. The serial number is printed on the back of the server.

The rest of the setup will be done as the *bqnadm* user. Log out (typing the **exit** command twice) and log in again using the *bqnadm* user.

```
root@bqn0# exit
bqn0:~ #
```

Now the BQN web interface is enabled and it is possible to perform the test of steps using the web interface. See the *BQN Quick Start Guide* for more details.

Step 5: Remove unused wires.

This step can be performed using the web interface. See the *BQN Quick Start Guide* for more details.

If the server has several data plane network interfaces, then multiple wires may be configured. If the final BQN deployment is known, then remove the unused wires; otherwise, proceed with the next step.

In this example, 2 wires have been created, but only the one containing the *en0p0s8* and *en0p0s9* will be used, so the other one will be removed.

```
root@bqn0# show config running | match wire
wire en0p0s10 en0p0s16 directed
wire en0p0s8 en0p0s9 directed
root@bqn0# configure
root@bqn0(config)# pkteng
root@bqn0(config-pkteng)# no wire en0p0s10 en0p0s16 directed
root@bqn0(config-pkteng)# commit
root@bqn0(config-pkteng)# end
root@bqn0# show config running | match wire
wire en0p0s8 en0p0s9 directed
```

Step 6: Generate diagnostic.

This step can be performed using the web interface. See the *BQN Quick Start Guide* for more details.

A diagnostic file will be used by Bequant to validate the configuration and to generate a license for this BQN. To generate a diagnostic file:

```
bqnadm@bqn0# system diagnostic
Get OS information...done
Get system information...done
Get network information...done
Get BQN information...done
Get PKTENG information...done
Get files...done

Created diagnostic file: /home/bqnadm/diagnostic-20200121161004

bqnadm@bqn0# file ls -l
total 1108
drwxr-xr-x 2 bqnadm users 4096 Sep 27 2013 bin
-rw-r--r-- 1 root users 1673430 Jan 21 16:10 diagnostic-20200121161004
```

Note that the diagnostic file is generated in the *home* directory of the user executing the command. The file can be retrieved from the BQN through an SCP (secure copy) connection to the *bqnadm* account via the management interface IP address.

```
mylaptop$ scp bqnadm@192.168.0.121:diagnostic-20200121161004 .
```

```

Password:
diagnostic-20200121161004          100% 1634KB  16.1MB/s   00:00

```

Step 7: License installation.

This step can be performed using the web interface. See the *BQN Quick Start Guide* for more details.

Upon reception of the diagnostic file generated in the previous step, Bequant will provide a valid license, which must be installed in the BQN.

```

bqnadm@bqn0# set license load file://bqn0.lic
bqnadm@bqn0# show license

```

FEATURE	EXPIRATION	VALID	USAGE
bta	2018-12-31T00:00:00+0100	yes	1000

More detailed information about this procedure is available in the *License Management* section in the *User Guide*.

Step 8: Verify status.

This step can be performed using the web interface. See the *BQN Quick Start Guide* for more details.

After the license has been installed, the global status of the BQN should indicate that it is ready to process traffic.

```

bqnadm@bqn0# show system status
CPU usage:          normal
Disk usage:         normal
Network interfaces: down
PKTENG status:      ready
BTA status:         ready
BTC status:         disabled
SSH service status: ready
WEB service status: ready
NTP service status: ready

```

Note that the status of the network interfaces may be *down* because the data plane network interfaces are not connected (for more information see the *Troubleshooting* chapter).

3.3 Manual Setup

To manually setup the BQN, follow all the steps described in the *Automatic Setup* section, but when *step 3* is reached, instead of entering the `wizard bta` command, enter the `wizard bta interactive` command. When executing the interactive wizard, all the parameters may be validated first and the wire configuration can be specified manually. Note that the value of some parameters could be presented with a default value between square brackets [], and in that case the value is accepted by pressing **ENTER**.

In the following example, one single wire will be created using the `en0p0s8` and `en0p0s9` network interfaces (note that if the wizard was not executed interactively, 2 wires would be created using the other 2 interfaces).

```

root@bqn0# wizard bta interactive
Available network interfaces:
en0p0s8
en0p0s9
en0p0s17
en0p0s10
en0p0s16
Enter management interface [en0p0s17]:
Enable VLAN on management interface? (yes/no) [no]:
Enter management IP address and prefix [192.168.1.77/24]:
Enter default gateway IP address [192.168.1.1]:
Configure a nameserver? (yes/no) [no]:

Available network interfaces:
en0p0s8
en0p0s9
en0p0s10
en0p0s16

```

Select access-side interface for wire: **en0p0s8**
Select internet-side interface for wire: **en0p0s9**
Create another wire? (yes/no): **no**
Enable SDR generation? (yes/no) [yes]: **yes**
Enter random acceleration percentage [99]:
System vendor: innotek GmbH
System name: VirtualBox
System serial: 0
System supported: no
CPU model: Intel(R) Core(TM) i7-4790S CPU @ 3.20GHz
CPU cores: 4

Management interface: en0p0s17
Management IP: 192.168.1.77/24
Management gateway: 192.168.1.1

Wire 1: en0p0s8(access)-en0p0s9(internet)

BTA random acceleration: 99%

If the proposed configuration is not valid execute the command
 wizard bta interactive
to manually enter the configuration.

Proceed with configuration? (yes/no) [yes]: **yes**

Troubleshooting

4.1 Overview

This chapter provides general information to conduct troubleshooting on the BQN.

4.2 Problems Accessing the Management Interface

As indicated in the *Network Management Interface* section in the *User Guide*, the BQN uses a dedicated network interface for management. The management interface supports both the SSH and WEB (HTTPs) services.

In case of problems accessing the configured management IP check the following:

- Ensure that the management network interface port is connected to the appropriate network.
- Verify that the link state of the management network interface is up (see the *Network Interface* section in the *User Guide*). If the management interface is connected to a network switch, verify that the port in the switch is up and its attributes match the properties shown by the **show interface** command.
- Verify using the system console that the management IP address and network prefix are correct. If accessing the management IP address from a different network, make sure that static routing is configured to the access network, as explained in the *Network Interface* section in the *User Guide*.
- Verify, using the system console, that the SSH service is up and running and its status is *active (running)*.

```
bqnadm@bqn0# show service ssh
sshd.service - OpenSSH Daemon
    Loaded: loaded (/bqn/img/linux/usr/lib/systemd/system/sshd.service; disabled)
    Active: active (running) since Tue 2021-06-29 12:22:20 VET; 1 day 21h ago
    . . .
```

If the WEB service is used, also verify that it is up and running and its status is *active (running)*.

```
bqnadm@bqn0# show service web
bqnadm@bqn-inter_brm# show service web
bqnweb.service - BQN WEB Service
    Loaded: loaded (/bqn/img/bqn/usr/lib/systemd/system/bqnweb.service; disabled)
    Active: active (running) since Wed 2021-06-30 04:33:48 VET; 1 day 4h ago
    . . .
```

- If there are firewalls in the management network, allow access to TCP port 22 for the SSH service and TCP port 443 for the WEB service.
- If you suspect the OAM IP settings are incorrect or unknown, connect a monitor and a keyboard to the server and login as root to change it. For example, to change to OAM IP 10.10.10.12/24:

```
bqn0:~ # bqnsb
root@bqn0# show interface management detail
Interface: en0o1
IP address: 192.168.0.121/24
Default gateway: 192.168.0.1
Nameserver: n/a
```

```

root@bqn0# set interface en0o1 management 0 10.10.10.12/24 gateway 10.10.10.1
root@bqn0# show interface management detail
Interface: en0o1
IP address: 10.10.10.12/24
Default gateway: 10.10.10.1
Nameserver: n/a

```

- The BQN management interface may be protected by its own firewall. The problem could be that your source IP address is not included in that firewall white list. This could happen even for addresses from the same subnet of the BQN management IP, if the subnet is not part of the firewall rules. You can disable the firewall temporarily until the connection to the management port is restored. Connect a monitor and a keyboard to the server and login as root:

```

bqn0:~ # bqns
root@bqn0# show interface firewall
IFACE          CHAIN    RANGE
en0o1          input    10.0.0.0/8
en0o1          input    172.16.0.0/12
en0o1          input    192.168.0.0/16
root@bqn0# clear interface en0o1 firewall input
root@bqn0# show interface firewall
IFACE          CHAIN    RANGE

```

Once the management IP is reachable, you can define the new white list of allowed source IP ranges.

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.3 CPU Usage Issues

The system management process monitors the global CPU usage status and detects when a CPU usage is higher than normal. When the CPU usage level is different than *normal*, it is necessary to analyze which CPU core has the high load and why.

```

bqnadm@bqn0# show system alarms
TYPE          STATUS    UPDATES TIME
cpu           critical  1 2021-06-29T15:56:56+0200
disk          normal    1 2021-06-09T11:27:41+0200
license-available normal    1 2021-06-09T11:27:41+0200
license-expiration normal    1 2021-06-09T11:27:41+0200
license-usage normal    1 2021-06-09T11:27:41+0200
memory-dpdk   normal    1 2021-06-29T10:48:18+0200
memory-pool   normal    1 2021-06-29T10:48:18+0200
process       normal    3 2021-07-01T15:37:58+0200
time          normal    2 2021-07-01T15:37:58+0200
traffic-uplink normal    2 2021-07-01T15:37:58+0200
traffic-downlink normal    2 2021-07-01T15:37:58+0200
traffic-low   normal    2 2021-07-01T15:37:58+0200
traffic-inverted normal    2 2021-07-01T15:37:58+0200
wire          normal    4 2021-07-01T15:38:33+0200

bqnadm@bqn0# show system cpu
CPU  USER  NICE  SYS  IO-WA  IRQ  SOFT  STEAL  GUEST  IDLE
all  12.91  0.00  0.41  0.00  0.00  0.12  0.00  0.00  86.56
 0   0.00  0.00  0.00  0.00  0.00  0.00  0.00  0.00 100.00
 1  97.77  0.00  2.23  0.00  0.00  0.00  0.00  0.00  0.00
 2   0.00  0.00  0.41  0.00  0.00  0.41  0.00  0.00 99.19
 3   0.00  0.00  0.00  0.00  0.00  0.00  0.00  0.00 100.00

bqnadm@bqn0# show system cpu level
CPU  LEVEL
 0  normal
 1  high
 2  normal
 3  normal

```

There are several possible causes of high CPU usage. The following sections cover some common ones,

4.3.1 A process not part of BQN product

In this case, CPU 1 has the high load, and as we can see with the `show system process top` command, the process that causes the high CPU load is a `bash` process, which is not part of the standard BQN processes.

```
bqnadm@bqn0# show system process top
top - 19:19:26 up 49 min, 3 users, load average: 0.53, 0.14, 0.05
Tasks: 137 total, 2 running, 135 sleeping, 0 stopped, 0 zombie
%Cpu(s): 0.2 us, 0.1 sy, 0.0 ni, 99.7 id, 0.0 wa, 0.0 hi, 0.0 si, 0.0 st
KiB Mem: 4046260 total, 488456 used, 3557804 free, 29668 buffers
KiB Swap: 2097148 total, 0 used, 2097148 free, 213880 cached
```

PID	USER	PR	NI	VIRT	RES	SHR	S	%CPU	%MEM	TIME+	COMMAND
6145	root	20	0	11556	2404	2196	R	100.0	0.059	0:48.98	bash
1	root	20	0	37148	5060	3420	S	0.000	0.125	0:01.16	systemd
2	root	20	0	0	0	0	S	0.000	0.000	0:00.00	kthreadd
4	root	0	-20	0	0	0	S	0.000	0.000	0:00.00	kworker/0:0H
5	root	20	0	0	0	0	S	0.000	0.000	0:00.00	kworker/u8:0
6	root	20	0	0	0	0	S	0.000	0.000	0:00.00	ksoftirqd/0
7	root	20	0	0	0	0	S	0.000	0.000	0:00.07	rcu_preempt
8	root	20	0	0	0	0	S	0.000	0.000	0:00.00	rcu_sched
9	root	20	0	0	0	0	S	0.000	0.000	0:00.00	rcu_bh
10	root	rt	0	0	0	0	S	0.000	0.000	0:00.00	migration/0
11	root	0	-20	0	0	0	S	0.000	0.000	0:00.00	lru-add-drain
12	root	rt	0	0	0	0	S	0.000	0.000	0:00.00	watchdog/0
13	root	20	0	0	0	0	S	0.000	0.000	0:00.00	cpuhp/0

In this example, the `bash` process was started to simulate a process with a very high CPU usage, and after terminating it the global CPU usage level drops back to *normal*.

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	1	2021-06-09T11:27:41+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

Do not stop any process that is part of the BQN software, since the service may be compromised. In addition, avoid executing any program that may affect the performance of the BQN. If you must, use always `nice` execution mode.

4.3.2 Not enough IO PKTENG processes

The BQN packet processing processes are called PKTENG. Some of them (the IO instances) are dedicated to handling input-output operations between the BQN software and the network cards and others (the workers) are specialized in BQN packet processing as such.

Which CPU cores are assigned to the IOs which ones to the workers, can be obtained with the command:

```
bqnadm@bqn0# show pkteng affinity
```

FUNCTION	AFFINITY	COUNT
cpu-available	ff	8
pkteng-all	ff	8
pkteng-worker	fe	7
pkteng-io	01	1

```

en0o7-io          01      1
en0o8-io          01      1

```

In this example, there is one single IO process, running on core number 0, and shared between both ports of the en0o7-en0o8 wire. The other cores are assigned to workers. If the core 0 has a very high load during peak traffic hours, an extra core for IO can be added. For example, to add core number 1.

```

bqnadm@bqn0# configure
bqnadm@bqn0(config)# pkteng
bqnadm@bqn0(config-pkteng)# dimension 6 0x3F 0x3C
bqnadm@bqn0(config-pkteng)# root
bqnadm@bqn0(config)# interface en0o7
bqnadm@bqn0(config-iface)# nic io affinity 0x03
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# interface en0o8
bqnadm@bqn0(config-iface)# nic io affinity 0x03
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0# show pkteng affinity

```

FUNCTION	AFFINITY	COUNT
cpu-available	ff	8
pkteng-all	3f	6
pkteng-worker	3c	4
pkteng-io	03	2
en0o7-io	03	2
en0o8-io	03	2

```

bqnadm@bqn06#

```

And now two cores (0 and 1) are assigned to IO processes, shared between the two ports of the wire. Note that there is one less worker (6 instead of the original 7). There is a trade off to reach between IOs and workers.

4.3.3 Overloaded PKTENG worker

All traffic from a given customer IP address is processed by one particular BQN worker instance. If the customer concentrates too much traffic (for example, because the BQN is behind a NAT encompassing many end subscribers), the core of that worker may have very high load.

In the following example, core 6 has high load:

```

bqnadm@bqn0# show system cpu

```

CPU	USER	NICE	SYS	IO-WA	IRQ	SOFT	STEAL	GUEST	IDLE
all	5.59	0.00	1.40	0.00	0.00	0.00	0.00	0.00	93.01
0	6.45	0.00	1.61	0.00	0.00	0.00	0.00	0.00	91.94
1	5.65	0.00	1.61	0.00	0.00	0.00	0.00	0.00	92.74
2	3.20	0.00	2.40	0.00	0.00	0.00	0.00	0.00	94.40
3	4.76	0.00	1.59	0.00	0.00	0.00	0.00	0.00	93.65
4	5.56	0.00	1.59	0.00	0.00	0.00	0.00	0.00	92.86
5	7.09	0.00	0.79	0.00	0.00	0.00	0.00	0.00	92.13
6	81.53	0.00	1.57	0.00	0.00	0.00	0.00	0.00	17.90
7	4.80	0.00	0.80	0.00	0.00	0.00	0.00	0.00	94.40

You can verify that core 6 is a worker:

```

bqnadm@bqn0# show pkteng affinity

```

FUNCTION	AFFINITY	COUNT
cpu-available	ff	8
pkteng-all	ff	8
pkteng-worker	fe	7
pkteng-io	01	1
en0o7-io	01	1
en0o8-io	01	1

In this example, all cores are workers except core 0.

To see if one subscriber IP concentrates too much traffic:

```

bqnadm@bqn0# show statistics subscribers top all direction downlink categories 3

```

TIME	GIGABYTES	192.168.0.172	192.168.0.162	192.168.0.151	REST
2022-02-13T20:00:00	1266.7381	21.4273%	1.6588%	1.1133%	75.8006%
2022-02-13T21:00:00	1331.1814	21.5691%	1.6492%	1.2478%	75.5339%
2022-02-13T22:00:00	1300.7372	21.7482%	1.6918%	1.7568%	74.8032%
2022-02-13T23:00:00	996.2735	21.7821%	1.5547%	2.0467%	74.6165%
2022-02-14T00:00:00	592.4524	21.9644%	2.1929%	1.6904%	74.1523%

Here, IP 192.168.0.172 is concentrating during the peak hours more than a fifth of the network traffic. That traffic falls in one single worker. To see which one:

```
bqnadm@bqn0# show subscriber 192.168.0.172
Address:          192.168.0.172 Instance:          6
Active flows:      1073 Total created flows:      4135963
Active shaped flows: 2 Duration:          142:06:26.563
Rate-limit enabled: no Automatic Congestion Management: no
DoS volume detection/attack: no/ no DoS SYN detection/attack: no/ no
UDR generation enabled: yes (2.00%) Blocked subscriber: no
Uplink sent bytes: 74601462570 Downlink sent bytes: 1546323242173
Uplink TCP0 bytes: 21459531298 Downlink TCP0 bytes: 1023234486404
Uplink current Mbps: 25.046 Downlink current Mbps: 16.566
Uplink max Mbps: 20.210 Downlink max Mbps: 77.392
Uplink current RTT (ms): 0.934 Downlink current RTT (ms): 1.110
Uplink min RTT (ms): 0.544 Downlink min RTT (ms): 0.608
Uplink current TCP RTX rate: 0.03% Downlink current TCP RTX rate: 4.77%
Uplink average TCP RTX rate: 0.28% Downlink average TCP RTX rate: 3.41%
Policy monitor: monitor-default Policy rate: rate-default
User Name: n/a Calling Station Id: n/a
NAS Identifier: n/a
NAS IP Address: n/a NAS Port: n/a

FLOW-SHAPING-POLICY DOWNLINK-RCV DOWNLINK-SND UPLINK-RCV UPLINK-SND
30Mbps 681204472902 664643445514 12020979178 18434850761
SUBS-RATE-POLICY DOWNLINK-RCV DOWNLINK-SND UPLINK-RCV UPLINK-SND
rate-default 1552099551638 1546323242173 67542149609 74601462570
```

The instance processing this subscriber is number 6, which corresponds to core number 6 (in this example core 0 is used by BQN; in machines where core 0 is not used by BQN, an instance 6 would be core 7).

Now that the issue has been identified, if there is a NAT between the subscribers and the BQN, one possible solution is to assign more IP addresses to the NAT so the BQN sees the traffic more evenly distributed between more IPs.

If only TCP Optimization functionality is used (no bandwidth management of any kind), a possible solution is to configure a per-flow distribution across workers. This will solve the load distribution issue, but only TCPO can be used. The rest of features are per subscriber, and requires all subscriber traffic processed by the same worker instance, so they will not be available.

```
bqnadm@bqn0# configure
bqnadm@bqn0(config)# pkteng
bqnadm@bqn0(config-pkteng)# steering flow
bqnadm@bqn0(config-pkteng)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0#
```

4.3.4 CPUs running at lower than expected frequency

In some rare cases, the CPU clock frequency may be reduced due to high temperature, power supply or hardware problems, which may result in a high CPU usage. In those cases make sure that the hardware is working within the recommended working parameters.

```
bqnadm@bqn0# show system cpu frequency
CPU CURRENT MINIMUM MAXIMUM
0 1282 800 2200
1 1808 800 2200
```

```

2    1517    800    2200
3    1423    800    2200
4    1556    800    2200
5    1047    800    2200
6    1443    800    2200
7     800    800    2200

```

```
bqnadm@bqn0# show system sensors
```

SENSOR	CURRENT	MAXIMUM	CRITICAL
Core1	41.0	82.0	104.0
PackageId0	41.0	82.0	104.0
Core2	41.0	82.0	104.0
Core0	41.0	82.0	104.0
Core3	41.0	82.0	104.0

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.4 Disk Issues

4.4.1 Disk Usage Issue

The system management process monitors the status of the / filesystem and detects when there is no more space or if the filesystem is in read-only mode. If the usage of a filesystem is above 85%, the status is set to *warning*, and if it reaches 99% then the status is *critical*.

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	warning	1	2021-06-09T11:27:41+0200
license-available	normal	1	2021-06-09T11:27:41+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

```
bqnadm@bqn0# show system filesystem
```

Filesystem	Size	Used	Avail	Use%	Mounted on
devtmpfs	2.0G	96K	2.0G	1%	/dev
tmpfs	2.0G	0	2.0G	0%	/dev/shm
tmpfs	2.0G	8.6M	2.0G	1%	/run
/dev/sda3	7.0G	6.6G	621M	92%	/
/dev/loop0	1.3M	1.3M	0	100%	/bqn/img/bqnos
/dev/loop1	254M	254M	0	100%	/bqn/img/linux
/dev/loop2	3.4M	3.4M	0	100%	/bqn/img/bqnkernel
/dev/loop3	149M	149M	0	100%	/bqn/img/kernel
/dev/loop4	1.5M	1.5M	0	100%	/bqn/img/gui
/dev/loop5	13M	13M	0	100%	/bqn/img/bqn
tmpfs	2.0G	0	2.0G	0%	/sys/fs/cgroup
tmpfs	2.0G	8.6M	2.0G	1%	/var/run

In this example, the filesystem mounted on / is getting full, and unnecessary files should be deleted.

Once the full filesystem is clean from unnecessary files and the usage of the filesystem is below 85%, the global disk status is restored to *normal*.

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	1	2021-06-09T11:27:41+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200

```

license-usage      normal      1 2021-06-09T11:27:41+0200
memory-dpdk        normal      1 2021-06-29T10:48:18+0200
memory-pool        normal      1 2021-06-29T10:48:18+0200
process            normal      3 2021-07-01T15:37:58+0200
time               normal      2 2021-07-01T15:37:58+0200
traffic-uplink     normal      2 2021-07-01T15:37:58+0200
traffic-downlink   normal      2 2021-07-01T15:37:58+0200
traffic-low        normal      2 2021-07-01T15:37:58+0200
traffic-inverted   normal      2 2021-07-01T15:37:58+0200
wire               normal      4 2021-07-01T15:38:33+0200

```

```
bqnadm@bqn0# show system filesystem
```

```

Filesystem      Size  Used Avail Use% Mounted on
devtmpfs        2.0G  96K  2.0G   1% /dev
tmpfs           2.0G   0  2.0G   0% /dev/shm
tmpfs           2.0G  8.6M  2.0G   1% /run
/dev/sda3       7.0G  597M  6.5G   9% /
/dev/loop0      1.3M  1.3M   0 100% /bqn/img/bqnos
/dev/loop1     254M  254M   0 100% /bqn/img/linux
/dev/loop2      3.4M  3.4M   0 100% /bqn/img/bqnkernel
/dev/loop3     149M  149M   0 100% /bqn/img/kernel
/dev/loop4      1.5M  1.5M   0 100% /bqn/img/gui
/dev/loop5       13M   13M   0 100% /bqn/img/bqn
tmpfs           2.0G   0  2.0G   0% /sys/fs/cgroup
tmpfs           2.0G  8.6M  2.0G   1% /var/run

```

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.4.2 Disk hardware issue

In the face of hard disk hardware failures, the OS protects itself by placing the filesystem in read-only mode.

The symptom of the problem is that statistics are not shown and configuration changes are not possible. Operations not requiring disk, like traffic processing, are not affected.

To confirm the problem, see if the syslog displays multiple disk errors:

```

bqn0:~# less /var/log/messages
...
[4486534.464803] print_req_error: I/O error, dev sda, sector 66617040
[4486534.464811] print_req_error: I/O error, dev loop1, sector 42706
[4486534.464815] sd 0:0:0:0: [sda] tag#2 FAILED Result: hostbyte=DID_BAD_TARGET driverbyte=DRIVER_OK
[4486534.464816] sd 0:0:0:0: [sda] tag#2 CDB: Read(10) 28 00 03 f8 7e d0 00 00 08 00
[4486534.464825] sd 0:0:0:0: [sda] tag#3 FAILED Result: hostbyte=DID_BAD_TARGET driverbyte=DRIVER_OK
...

```

To complete the problem analysis, log into the BQN server root account and run the following command in the Linux shell. Save the response for later reference (note that in this example `/dev/sda` is the disk device for the hard disk):

```

bqn0:~# smartctl -all /dev/sda
smartctl 6.2 2013-07-26 r3841 [x86_64-linux-4.12.14-155.g4755291-default] (SUSE RPM)
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

=== START OF INFORMATION SECTION ===
Model Family:      Seagate Barracuda 7200.14 (AF)
...

```

Also, run the following test (it will take a few minutes, the command itself will give an estimate of its duration):

```

bqn0:~# smartctl -t short /dev/sda
smartctl 6.2 2013-07-26 r3841 [x86_64-linux-4.12.14-155.g4755291-default] (SUSE RPM)
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

=== START OF OFFLINE IMMEDIATE AND SELF-TEST SECTION ===
Sending command: "Execute SMART Short self-test routine immediately in off-line mode".

```

```
Drive command "Execute SMART Short self-test routine immediately in off-line mode" successful.
Testing has begun.
Please wait 1 minutes for test to complete.
Test will complete after Tue Feb 15 11:30:27 2022
```

```
Use smartctl -X to abort test.
bqn0:~
```

Once the test has been completed, retrieve the result and send it to Bequant support along with the response of the `smartctl -all` command (see *Contacting Bequant Support* section):

```
bqn0:~ smartctl -l selftest /dev/sda
smartctl 6.2 2013-07-26 r3841 [x86_64-linux-4.12.14-155.g4755291-default] (SUSE RPM)
Copyright (C) 2002-13, Bruce Allen, Christian Franke, www.smartmontools.org

=== START OF READ SMART DATA SECTION ===
SMART Self-test log structure revision number 1
#1  Test_Description            Status                      Remaining      LifeTime(hours)  LBA_of_first_error
# 1 Short offline              Completed without error     00%            17734             -
# 2 Short offline              Completed without error     00%            17695             -
# 3 Extended offline           Completed without error     00%             5419             -
# 4 Extended offline           Completed without error     00%             5085             -
# 5 Extended offline           Completed without error     00%             4791             -
# 6 Extended offline           Completed without error     00%             4517             -
# 7 Extended offline           Interrupted (host reset)    00%             4515             -
# 8 Extended offline           Interrupted (host reset)    00%             4513             -
# 9 Extended offline           Completed without error     00%            4474             -
#10 Extended offline           Completed without error     00%            4250             -
#11 Extended offline           Completed without error     00%            4086             -
#12 Extended offline           Completed without error     00%            4061             -
#13 Short offline              Completed without error     00%              0              -
bqn0:~
```

Once the disk hardware failure is confirmed, the disk must be replaced by a new one. We recommend a RAID 1 (mirroring) to avoid data losses as a result of disk failures.

4.5 Wire Problems (Data Plane Interfaces)

The management system monitors all the configured wires. If there are no wires configured or none of them have their interfaces up, the state of the system wires will be *critical*. If some of the configured wires are up, but others are not, the state will be *notice*.

```
bqnadm@bqn0# show system alarms
TYPE                STATUS      UPDATES TIME
cpu                  normal      1 2021-06-29T15:56:56+0200
disk                 normal      1 2021-06-09T11:27:41+0200
license-available    normal      1 2021-06-09T11:27:41+0200
license-expiration   normal      1 2021-06-09T11:27:41+0200
license-usage        normal      1 2021-06-09T11:27:41+0200
memory-dpdk          normal      1 2021-06-29T10:48:18+0200
memory-pool          normal      1 2021-06-29T10:48:18+0200
process              normal      3 2021-07-01T15:37:58+0200
time                 normal      2 2021-07-01T15:37:58+0200
traffic-uplink       normal      2 2021-07-01T15:37:58+0200
traffic-downlink     normal      2 2021-07-01T15:37:58+0200
traffic-low          normal      2 2021-07-01T15:37:58+0200
traffic-inverted     normal      2 2021-07-01T15:37:58+0200
wire                  notice      5 2021-07-01T17:28:21+0200
```

Use the `show interface` command to locate the interface with no link:

```
bqnadm@bqn0# show pkteng wire
ACC-IFACE    ACC-PCAP    INET-IFACE    INET-PCAP
en0o3        no          en0o4         no
en0o5        no          en0o6         no
bqnadm@bqn0# show interface
```

IFACE	TYPE	MAC	STATE	LINK
lo0	loopback	00:00:00:00:00:00	up	yes
en0o1	ethernet	08:00:27:45:36:8c	up	yes
en0o2	ethernet	08:00:27:b8:59:0c	down	no
en0o3	ethernet	08:00:27:0f:f4:1c	up	yes
en0o4	ethernet	08:00:27:0c:46:75	up	no
en0o5	ethernet	08:00:27:9b:3f:4a	up	yes
en0o6	ethernet	08:00:27:9b:3f:4d	up	yes

In the example above the **en0o4** interface has no link and it is part of a wire. Note that the interface **en0o2** is not used and its status does not affect system alarms. After connecting the cable of **en0o4** correctly, the status is restored to *normal*:

```
bqnadm@bqn0# show interface
```

IFACE	TYPE	MAC	STATE	LINK
lo0	loopback	00:00:00:00:00:00	up	yes
en0o1	ethernet	08:00:27:45:36:8c	up	yes
en0o2	ethernet	08:00:27:b8:59:0c	down	no
en0o3	ethernet	08:00:27:0f:f4:1c	up	yes
en0o4	ethernet	08:00:27:0c:46:75	up	yes
en0o5	ethernet	08:00:27:9b:3f:4a	up	yes
en0o6	ethernet	08:00:27:9b:3f:4d	up	yes

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	1	2021-06-09T11:27:41+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	5	2021-07-01T17:28:21+0200

The attributes (duplex, speed) of the network interfaces in the BQN must match the network attributes of the port where it is connected (switch, router, server, etc.) Use the **show interface** command to check the properties of the network interfaces in the BQN. Note that the default behaviour should be auto-negotiation.

```
bqnadm@bqn0# show interface detail
```

```
lo0: UP LOOPBACK RUNNING
  Link type: loopback
  Link detected: yes          Auto-negotiation: unknown
  MTU: 65536
```

```
en0o1: UP BROADCAST RUNNING MULTICAST
  Link type: ethernet        MAC: 08:00:27:45:36:8c
  Link detected: yes          Auto-negotiation: on
  Duplex: Full                Speed: 1000Mbps
  MTU: 1500
```

```
en0o2: BROADCAST MULTICAST
  Link type: ethernet        MAC: 08:00:27:b8:59:0c
  Link detected: no           Auto-negotiation: on
  Duplex: unknown            Speed: unknown
  MTU: 1500
```

```
en0o3: UP PROMISC RUNNING
  Link type: ethernet        MAC: 08:00:27:0f:f4:1c
  Link detected: yes          Auto-negotiation: on
  Duplex: Full                Speed: 1000Mbps
  MTU: 2026
```

```
en0o4: UP PROMISC RUNNING
  Link type: ethernet        MAC: 08:00:27:0c:46:75
  Link detected: yes          Auto-negotiation: on
```

```

Duplex: Full           Speed: 1000Mbps
MTU: 2026
en0o5: UP PROMISC RUNNING
Link type: ethernet    MAC: 08:00:27:9b:3f:4a
Link detected: yes      Auto-negotiation: on
Duplex: Full           Speed: 1000Mbps
MTU: 2026
en0o6: UP PROMISC RUNNING
Link type: ethernet    MAC: 08:00:27:9b:3f:4d
Link detected: yes      Auto-negotiation: on
Duplex: Full           Speed: 1000Mbps
MTU: 2026

```

Sometimes the problem is that the interface is non-Intel and has to be set in PCAP mode (see the *Non-Intel Interfaces* section).

Another possible source of problems is the compatibility of SFP transceivers (see the *SFP+ Modules* section).

4.5.1 Non-Intel Interfaces

When a data network interface is not Intel based, it may not be compatible unless it is placed in PCAP mode. Only interfaces of 1G should be placed in PCAP mode (10G or more must be Intel-compatible).

In the following example, the interfaces `en0p3s0` and `en0p4s0` are Broadcom based and must be in PCAP mode in order to be part of a wire. Setting an interface in PCAP mode reduces the server throughput capacity significantly, so Intel interface cards are highly recommended:

```

bqnadm@bqn0# show pkteng wire
ACC-IFACE      ACC-PCAP      INET-IFACE      INET-PCAP      DIRECTED
en0p3s0        no            en0p4s0         no             yes
bqnadm@bqn0# show interface
IFACE          TYPE          MAC              STATE LINK
lo0            loopback      00:00:00:00:00:00 up    yes
en0p1s0        ethernet      30:27:14:23:ba:12 up    yes
en0p2s0        ethernet      30:27:14:23:ba:13 down  no
en0p3s0        ethernet      30:27:14:23:ba:14 down  no
en0p4s0        ethernet      30:27:14:23:ba:15 down  no
bqnadm@bqn0# show interface en0p3s0 device
Driver: bnx2
PCI class: 0x20000
PCI vendor ID: 0x14e4 : Broadcom Inc.
PCI device ID: 0x1639 : NetXtreme II BCM5709 Gigabit Ethernet
PCI sub-vendor ID: 0x103c : Hewlett-Packard Company
PCI sub-device ID: 0x7055
PCI slot: 0000:02:00.0
NUMA node: 0
bqnadm@bqn0# show interface en0p4s0 device
Driver: bnx2
PCI class: 0x20000
PCI vendor ID: 0x14e4 : Broadcom Inc.
PCI device ID: 0x1639 : NetXtreme II BCM5709 Gigabit Ethernet
PCI sub-vendor ID: 0x103c : Hewlett-Packard Company
PCI sub-device ID: 0x7055
PCI slot: 0000:02:00.0
NUMA node: 0
bqnadm@bqn0# configure
bqnadm@bqn0(config)# interface en0p3s0
bqnadm@bqn0(config-iface)# nic pcap
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# interface en0p4s0
bqnadm@bqn0(config-iface)# nic pcap
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0# show interface

```



```

IFACE          TYPE      MAC          STATE LINK
lo0            loopback  00:00:00:00:00:00 up    yes
en0p1s0        ethernet  30:27:14:23:ba:12 up    yes
en0p2s0        ethernet  30:27:14:23:ba:13 down  no
en0p3s0        ethernet  30:27:14:23:ba:14 up    yes
en0p4s0        ethernet  30:27:14:23:ba:15 up    yes
bqnadm@bqn0# show pkteng wire
ACC-IFACE      ACC-PCAP  INET-IFACE    INET-PCAP  DIRECTED
en0p3s0        yes       en0p4s0       yes        yes

```

4.5.2 SFP+ Modules

If *SFP+* ports are used, then make sure that the Direct Attach Cable (DAC) or the transceivers are compatible with Intel network cards. In addition, ensure that the transceivers are facing the right way and are fully inserted in both ports.

In general, if there are connectivity problems and the network interfaces have no link, perform the following instructions.

1. Make sure that the transceivers are fully inserted into the network ports, and that they correspond with the configured network interfaces in the BQN.
2. Verify that the transceivers are of the supported types and of a flavor compatible with Intel network cards. The transceiver types supported are:
 - 1G ports: SFP 1000BASE-SX and 1000BASE-LX.
 - 10G ports+: SFP+ 10GBASE-SR/1000BASE-SX and 10GBASE-LR/1000BASE-LX.
 - 40G ports+: QSFP+ 40GBASE-SR4 and 40GBASE-LR4 compatible with XL710 series.
 - 25G ports: SFP28 compatible with Intel XXV710 network cards.
 - 100G ports: QSFP28 compatible with Intel E810 series.
3. If the network interface uses the Intel Ethernet Controller X710 (10G ports), make sure that the adapter qualification mechanism is disabled (to support SFP modules by vendors different than Intel) and that all the available SFP modes are fully supported. To verify the SFP+ module state the interfaces must be in PCAP mode.

```

bqnadm@bqn0# system interface en0s1f1 sfp-qualification disable
bqnadm@bqn0# system interface en0s1f1 sfp-support
bqnadm@bqn0# show interface en0s1f1 device
Driver: i40e
PCI class: 0x20000
PCI vendor ID: 0x8086 : Intel Corporation
PCI device ID: 0x1572 : Ethernet Controller X710 for 10GbE SFP+
PCI sub-vendor ID: 0x8086 : Intel Corporation
PCI sub-device ID: 0x0000
PCI slot: 0000:08:00.1
X710 SFP+ qualification: no
X710 SFP+ support: full

```

Note that the last 2 lines indicate the SFP+ compatibility status.

⚠ If these parameters are modified then the system must be rebooted for the changes to take effect.

If the X710 SFP+ information displayed does not show meaningful values, execute the `/opt/bqn/sbin/x710tool` program from the *bash* shell (as *root* user), indicating the operating system name of the interface.

```

bqn0:~ # /opt/bqn/sbin/x710tool en0s1f1
DATA-STRUCT  OFFSET  VALUE DESCRIPTION
PHY-Capability 0x0000  0x000c Section Length
PHY-Capability 0x0001  0x0022 INT-EXT PHY Select
PHY-Capability 0x0002  0x0083 Internal PHY Type
PHY-Capability 0x0003  0x1871 External PHY Type
PHY-Capability 0x0004  0x0000 PHY ID 0
PHY-Capability 0x0005  0x0000 PHY ID 1
PHY-Capability 0x0006  0x3303 Module Type 0

```

```

PHY-Capability 0x0007 0x000b Module Type 1
PHY-Capability 0x0008 0x630c PHY Capabilities Misc0
PHY-Capability 0x0009 0x0a00 PHY Capabilities Misc1
PHY-Capability 0x000a 0x0a1e 40 LESM Timer Values
PHY-Capability 0x000b 0x0003 PHY Capabilities Misc2
PHY-Capability 0x000c 0x0000 PHY Capabilities Misc3

```

The `-v` flag shows more detailed information.

4. If the network interface uses the Intel Ethernet Controller X710, make sure that the adapter firmware version is up to date. To verify the adapter firmware version the interfaces must be in PCAP mode. Execute the `ethtool` program from the `bash` shell (as `root` user), indicating the operating system name of the interface.

```

bqn0:~ # ethtool -i en0s1f1
driver: i40e
version: 2.4.10
firmware-version: 4.60 0x80001f47 1.3072.0
bus-info: 0000:61:00.0
supports-statistics: yes
supports-test: yes
supports-eeprom-access: yes
supports-register-dump: yes
supports-priv-flags: yes

```

In this example, the firmware version is 4.60. At this time, the latest firmware version available is 7.2, so the firmware should be updated following the instructions described in the *Intel Ethernet Controller X710 Firmware Update* chapter.

5. If the first of the interfaces of a wire has link, then connect that transceiver together with its fiber to the second network interface of the wire. If the second network interface now has link, then the problem may be with the transceiver or the fiber originally used with the second network interface.
6. Connect the two network interfaces of a wire directly with the same fiber. Note that if both interfaces have link, then the problem may be in the other router/switch connected to the BQN.

4.6 High Memory Usage

The system monitors the BQN and the DPDK memory pools. If either of them are above 90%, the system signals it with a *warning*:

```

bqnadm@bqn0# show system alarms

```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	1	2021-06-09T11:27:41+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	warning	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

To see memory usage:

```

bqnadm@bqn0# show statistics memory lines 1

```

TIME	SYS-MB	MP00L-MB	DPDK0-MB
2021-07-01T10:11:03	4186.395	222.819	3908.420

```

bqnadm@bqn0# show pkteng memory dpdk

```

NODE	SIZE-USED-MB	SIZE-TOTAL-MB
0	3907.2	4294.9

So it is confirmed that the DPDK pool is almost full. The solution to this problem is to upgrade the server RAM memory. The BQN will automatically recognize the new memory and re-dimension its pools accordingly. The following section covers a scenario where the memory upgrade can be avoided.

4.6.1 Unbalanced DPDK memory usage

The following is applicable only to NUMA servers (a dual-socket server with two CPUs). For performance reasons, a network card uses the DPDK memory pool associated to its NUMA. For example, a network card inserted in a PCI slot associated to NUMA-0 will use the DPDK memory pool of NUMA-0. Therefore, if network cards were inserted unevenly between the two NUMAs, the resulting memory usage will be unbalanced.

The unbalance can be seen with the following command:

```
bqnadm@bqn0# show statistics memory
```

TIME	SYS-MB	MP00L-MB	DPDK0-MB	DPDK1-MB
2022-02-15T05:58:49	31661.758	313.458	183.663	3.232
2022-02-15T06:03:49	31662.598	336.887	191.474	9.693
2022-02-15T06:08:49	31662.094	349.635	200.336	7.392
2022-02-15T06:13:49	31661.887	342.606	200.365	9.657
2022-02-15T06:18:49	31661.789	342.279	194.166	5.401
2022-02-15T06:23:49	31661.199	356.192	199.790	0.923
2022-02-15T06:28:49	31662.246	369.253	212.195	6.996
2022-02-15T06:33:49	31662.492	374.588	207.565	2.248
2022-02-15T06:38:49	31660.426	384.968	203.998	7.128
2022-02-15T06:43:49	31659.539	393.998	215.445	4.333
2022-02-15T06:48:49	31660.500	396.609	221.627	4.992
2022-02-15T06:53:49	31659.562	415.244	215.948	3.416
2022-02-15T06:58:49	31660.484	433.093	220.668	6.716
2022-02-15T07:03:49	31662.738	428.353	218.833	9.735
2022-02-15T07:08:49	31661.539	441.953	221.646	2.435
. . .				

In this case, all traffic is being handled by NUMA-0, so its pool (DPDK0) has a much bigger usage.

If the memory is big enough, this imbalance poses no problem and can be left as it is (in future upgrades, extra network cards should be inserted in the NUMA-1 PCI slots). But if DPDK0 has high usage, it is possible to rebalance the memory by telling the network interfaces to use also the other DPDK pool. The following example uses two wires, both in the same NUMA:

```
bqnadm@bqn0# show pkteng wire
```

ACC-IFACE	ACC-PCAP	INET-IFACE	INET-PCAP
en0p5s0f0	no	en0p5s0f1	no
en0p7s0f0	no	en0p7s0f1	no

```
bqnadm@bqn0# show interface en0p5s0f0 device
```

```
Driver: igb_uio
PCI class: 0x20000
PCI vendor ID: 0x8086 : Intel Corporation
PCI device ID: 0x10fb : 82599ES 10-Gigabit SFI/SFP+ Network Connection
PCI sub-vendor ID: 0x1374
PCI sub-device ID: 0x0132
PCI slot: 0000:05:00.0
NUMA node: 0
```

```
bqnadm@bqn0# show interface en0p7s0f0 device
```

```
Driver: igb_uio
PCI class: 0x20000
PCI vendor ID: 0x8086 : Intel Corporation
PCI device ID: 0x10fb : 82599ES 10-Gigabit SFI/SFP+ Network Connection
PCI sub-vendor ID: 0x1374
PCI sub-device ID: 0x0132
PCI slot: 0000:07:00.0
NUMA node: 0
```

Each wire uses two IO processes:

```
bqnadm@bqn0# show pkteng affinity
```

FUNCTION	AFFINITY	COUNT
cpu-available	ffffff,ffffff	56
pkteng-all	000000,00fffffe	23
pkteng-worker	000000,00ffff3e	21
pkteng-io	000000,0000f000	4
en0p5s0f1-io	000000,00003000	2
en0p5s0f0-io	000000,00003000	2
en0p7s0f1-io	000000,0000c000	2
en0p7s0f0-io	000000,0000c000	2

To balance the memory usage, we can instruct the interfaces to use DPDK0 for some IO processes and DPDK1 for the other IO processes.

```
bqnadm@bqn0# configure
bqnadm@bqn0(config)# interface en0p5s0f0
bqnadm@bqn0(config-iface)# nic io numa 0x1000 0
bqnadm@bqn0(config-iface)# nic io numa 0x2000 1
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# interface en0p5s0f1
bqnadm@bqn0(config-iface)# nic io numa 0x1000 0
bqnadm@bqn0(config-iface)# nic io numa 0x2000 1
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# interface en0p7s0f0
bqnadm@bqn0(config-iface)# nic io numa 0x4000 0
bqnadm@bqn0(config-iface)# nic io numa 0x8000 1
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# interface en0p7s0f1
bqnadm@bqn0(config-iface)# nic io numa 0x4000 0
bqnadm@bqn0(config-iface)# nic io numa 0x8000 1
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0#
```

The previous configuration gets the first wire to use DPDK0 for IO 0x1000 and DPDK1 for IO 0x2000 and, similarly for the second wire. The memory usage will be more balanced:

```
bqnadm@bqn0# show statistics memory
```

	TIME	SYS-MB	MP00L-MB	DPDK0-MB	DPDK1-MB
2022-02-15T05:54:06	70011.793	2547.534	691.772	557.649	
2022-02-15T05:59:06	70010.953	2582.345	684.435	657.337	
2022-02-15T06:04:06	70010.906	2802.498	864.704	759.575	
2022-02-15T06:09:06	70011.078	2785.494	825.033	658.832	
2022-02-15T06:14:06	70011.055	2845.675	721.519	768.127	
2022-02-15T06:19:06	70011.664	2863.118	675.411	767.531	
2022-02-15T06:24:06	70010.879	2844.638	588.927	709.374	
2022-02-15T06:29:06	70011.711	2951.280	905.278	671.670	
2022-02-15T06:34:06	70011.609	3016.513	689.571	821.960	
2022-02-15T06:39:06	70010.617	3033.801	874.681	722.075	
2022-02-15T06:44:06	70010.719	3136.536	795.822	1016.979	
2022-02-15T06:49:06	70012.473	3100.317	679.810	866.036	
2022-02-15T06:54:06	70011.285	3122.440	757.506	934.861	
2022-02-15T06:59:06	70010.863	3083.912	690.496	862.272	
2022-02-15T07:04:06	70010.906	3301.254	795.088	794.413	
. . .					

4.7 License Unavailable Issues

The management system monitors the availability of licenses.

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	critical	2	2021-07-01T17:21:38+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200

license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

If the *license-available* status is not *normal* then follow these steps:

1. Verify that there is a valid license

```
bqnadm@bqn0# show license
FEATURE                                EXPIRATION VALID  USAGE-MAX
```

2. If there is no license, it is possible that the BQN has not retrieved a valid license from the license manager. Make sure that the license manager has been contacted:

```
bqnadm@bqn0# show remctr status
State: idle
Timer expiration: 00:05:23.599
Last in "connected" state: n/a
Session ID: 5672e81430c7f9b5
```

If so, force the BQN to contact the licence manager:

```
bqnadm@bqn0# system remctr connect
bqnadm@bqn0# show license
FEATURE                                EXPIRATION VALID  USAGE-MAX
bta                                2021-07-04T16:59:59-0500 yes      1000
```

3. Sometimes the BQN cannot reach the license manager, which needs to access the the *13151* TCP port at *146.59.206.4* and *46.26.190.166* IP addresses. To test if the license manager is reachable, enter the following command as *root*:

```
bqn0:~ # telnet 146.59.206.4 13151
Trying 146.59.206.4...
telnet: connect to address 146.59.206.4: Connection refused
bqn0:~ #
```

This lack of access can be caused by a firewall rule preventing an outgoing TCP connection to those IP addresses, which requires that you review your firewall rules.

If the BQN firewall is used, make sure the license manager IPs are included. For example, if *en0o1* is the management interface and the firewall is active;

```
bqnadm@bqn0# show interface firewall
IFACE      CHAIN  RANGE
en0o1      input  10.0.0.0/8
en0o1      input  172.16.0.0/12
en0o1      input  192.168.0.0/16
bqnadm@bqn0# configure
bqnadm@bqn0(config)# interface en0o1
bqnadm@bqn0(config-iface)# firewall input 46.26.190.166/32
bqnadm@bqn0(config-iface)# firewall input 146.59.206.4/32
bqnadm@bqn0(config-iface)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0#
```

After sorting out the firewall, the license manager should be reachable, which can be tested by entering the following command as *root*:

```
bqn0:~ # telnet 146.59.206.4 13151
Trying 146.59.206.4...
Connected to 146.59.206.4.
Escape character is '^]'.
^]Connection closed by foreign host.
bqn0:~ #
```

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.8 License Expiration Issues

The system management process monitors if there are licenses which have expired.

```
bqnadm@bqn0# show system alarms
TYPE                STATUS    UPDATES  TIME
cpu                 normal    1 2021-06-29T15:56:56+0200
disk                normal    1 2021-06-09T11:27:41+0200
license-available   normal    2 2021-07-01T17:21:38+0200
license-expiration  critical  1 2021-06-09T11:27:41+0200
license-usage       normal    1 2021-06-09T11:27:41+0200
memory-dpdk         normal    1 2021-06-29T10:48:18+0200
memory-pool         normal    1 2021-06-29T10:48:18+0200
process             normal    3 2021-07-01T15:37:58+0200
time                normal    2 2021-07-01T15:37:58+0200
traffic-uplink      normal    2 2021-07-01T15:37:58+0200
traffic-downlink    normal    2 2021-07-01T15:37:58+0200
traffic-low         normal    2 2021-07-01T15:37:58+0200
traffic-inverted    normal    2 2021-07-01T15:37:58+0200
wire                normal    4 2021-07-01T15:38:33+0200

bqnadm@bqn0# show license
FEATURE              EXPIRATION  VALID  USAGE-MAX
bta                  2021-06-30T00:00:00+0200  no      1000
```

In that case, a license renewal will be necessary from your sales representative.

It is possible that the renewal is already waiting in the license manager but the license manager is currently not reachable. See the *License Unavailable Issues* section for details.

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.9 Traffic Above The License Limit

If the license limit is in *warning* state, it indicates that the system is processing more traffic throughput than the purchased license.

```
bqnadm@bqn0# show system alarms
TYPE                STATUS    UPDATES  TIME
cpu                 normal    1 2021-06-29T15:56:56+0200
disk                normal    1 2021-06-09T11:27:41+0200
license-available   normal    2 2021-07-01T17:21:38+0200
license-expiration  normal    1 2021-06-09T11:27:41+0200
license-usage       warning    1 2021-06-09T11:27:41+0200
memory-dpdk         normal    1 2021-06-29T10:48:18+0200
memory-pool         normal    1 2021-06-29T10:48:18+0200
process             normal    3 2021-07-01T15:37:58+0200
time                normal    2 2021-07-01T15:37:58+0200
traffic-uplink      normal    2 2021-07-01T15:37:58+0200
traffic-downlink    normal    2 2021-07-01T15:37:58+0200
traffic-low         normal    2 2021-07-01T15:37:58+0200
traffic-inverted    normal    2 2021-07-01T15:37:58+0200
wire                normal    4 2021-07-01T15:38:33+0200
```

When the license usage is in *warning* state, the BQN continues forwarding all the traffic, so the connectivity is not lost, but some flows are not processed to keep the throughput of optimized traffic approximately within the license limit. Flows already optimized continue to be so in order to mitigate the impact on end users experience.

The system alarm will be in *warning* state during the time when traffic exceeds the license.

You will need to purchase a license upgrade from your sales representative.

4.10 No Traffic in Uplink or Downlink Directions

The BQN monitors that traffic in uplink and downlink directions are flowing through the server. When this is not the case, a *warning* alert is issued.

For example, if there is no uplink traffic flowing through the BQN:

```
bqnadm@bqn0# show system alarms
TYPE                STATUS      UPDATES  TIME
cpu                  normal      1 2021-06-29T15:56:56+0200
disk                 normal      1 2021-06-09T11:27:41+0200
license-available    normal      2 2021-07-01T17:21:38+0200
license-expiration   normal      1 2021-06-09T11:27:41+0200
license-usage        normal      1 2021-06-09T11:27:41+0200
memory-dpdk          normal      1 2021-06-29T10:48:18+0200
memory-pool          normal      1 2021-06-29T10:48:18+0200
process              normal      3 2021-07-01T15:37:58+0200
time                 normal      2 2021-07-01T15:37:58+0200
traffic-uplink        warning     2 2021-07-01T15:37:58+0200
traffic-downlink      warning     2 2021-07-01T15:37:58+0200
traffic-low           normal      2 2021-07-01T15:37:58+0200
traffic-inverted      normal      2 2021-07-01T15:37:58+0200
wire                  normal      4 2021-07-01T15:38:33+0200
```

You can check the traffic flowing through the BQN with the following command:

```
bqnadm@bqn0# show interface pkteng bandwidth
INTERFACE          PKTS-RX-Kpps  BYTES-RX-Mbps  PKTS-TX-Kpps  BYTES-TX-Mbps
en0o7               0.000         0.000          0.000         0.000
en0o8               0.000         0.000          0.000         0.000
```

In this example, there is no traffic through the BQN.

If the traffic goes in only one direction (for example, only downlink), you would see something like:

```
bqnadm@bqn0# show interface pkteng bandwidth
INTERFACE          PKTS-RX-Kpps  BYTES-RX-Mbps  PKTS-TX-Kpps  BYTES-TX-Mbps
en0o7               0.000         0.000          1.897         15.515
en0o8               1.970         18.113          0.000         0.000
```

By default, the system reports a problem if the traffic reaches zero, but you can define a more strict threshold. For example, to report an alarm if the traffic goes below 100 Mbps in downlink and 20 Mbps in uplink:

```
bqnadm@bqn0# configure
bqnadm@bqn0(config)# system
bqnadm@bqn0(config-system)# management traffic threshold 100000 20000
bqnadm@bqn0(config-system)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0#
```

Note that in this example the traffic thresholds are specified in Kbps.

4.11 Traffic Too Low

While there is traffic in uplink and downlink directions, the BQN monitors if the total level of received traffic in both directions goes below a threshold and if it does, signals it with a *notice* alarm.

```
bqnadm@bqn0# show system alarms
TYPE                STATUS      UPDATES  TIME
cpu                  normal      1 2021-06-29T15:56:56+0200
disk                 normal      1 2021-06-09T11:27:41+0200
license-available    normal      2 2021-07-01T17:21:38+0200
license-expiration   normal      1 2021-06-09T11:27:41+0200
license-usage        normal      1 2021-06-09T11:27:41+0200
memory-dpdk          normal      1 2021-06-29T10:48:18+0200
memory-pool          normal      1 2021-06-29T10:48:18+0200
process              normal      3 2021-07-01T15:37:58+0200
time                 normal      2 2021-07-01T15:37:58+0200
traffic-uplink        normal      2 2021-07-01T15:37:58+0200
traffic-downlink      normal      2 2021-07-01T15:37:58+0200
traffic-low           notice      2 2021-07-01T15:37:58+0200
```

```

traffic-inverted    normal      2 2021-07-01T15:37:58+0200
wire                normal      4 2021-07-01T15:38:33+0200

```

You need to check if this low level of traffic is normal.

By default, the level of low traffic is 1 Mbps, but you can define a different threshold. For example, to raise the threshold to 500 Mbps:

```

bqnadm@bqn0# configure
bqnadm@bqn0(config)# system
bqnadm@bqn0(config-system)# management traffic low 500000
bqnadm@bqn0(config-system)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0#

```

Note that in this example the traffic threshold is specified in Kbps.

If there is no traffic, this alarm will stay in *unknown* state.

4.12 Traffic Inverted

While there is traffic in uplink and downlink directions, the BQN monitors if the uplink received traffic is less than the downlink received traffic. Traffic usually has more throughput in the downlink direction than in the uplink direction. If this is not the case, a *warning* alarm is issued:

```

bqnadm@bqn0# show system alarms

```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	2	2021-07-01T17:21:38+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	3	2021-07-01T15:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	warning	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

For the BQN it is important the direction of the traffic, because it needs to know where the subscribers and the Internet lie. When the traffic is signalled as inverted, it is usually due to some wires that contain ports that have been connected in inverted order (the access interface is the one on the Internet side and vice versa). To verify the directionality, first list the wire configuration:

```

bqnadm@bqn0# show pkteng wire

```

ACC-IFACE	ACC-PCAP	INET-IFACE	INET-PCAP
en0o3	no	en0o4	no
en0o5	no	en0o6	no

Then check the throughput of those interfaces:

```

bqnadm@bqn0# show statistics interface speed lines 6

```

	TIME	TX-Mbps	en0o3 RX-Mbps	TX-Mbps	en0o4 RX-Mbps	TX-Mbps	en0o5 RX-Mbps	TX-Mbps	en0o6 RX-Mbps	...
2021-07-02T10:25:29	95.59	345.52	341.16	97.72	270.43	36.81	38.26	266.81	...	
2021-07-02T10:30:29	84.07	308.87	306.04	84.37	264.17	32.00	33.55	261.19	...	
2021-07-02T10:35:29	110.54	357.93	352.72	113.40	268.12	36.70	38.23	265.27	...	
2021-07-02T10:40:29	92.36	338.68	336.39	93.59	296.24	40.09	41.87	291.66	...	
2021-07-02T10:45:29	97.69	334.42	332.46	99.75	290.77	38.16	39.57	284.97	...	
2021-07-02T10:50:29	90.91	351.32	348.21	93.81	278.66	40.51	41.82	274.15	...	

It can be observed that **en0o3** receives more than it transmits and it is configured as an access interface in the wire. Interface **en0o4** sends more than it receives and it is configured in its wire as the Internet

interface. That wire is inverted and it is causing the inverted traffic alarm. To fix it, either change the physical cables or revert the configuration:

```
bqnadm@bqn0# set wire en0o4 en0o3 0 bqnadm@bqn0# show pkteng wire
ACC-IFACE      ACC-PCAP  INET-IFACE    INET-PCAP
en0o4          no        en0o3         no
en0o5          no        en0o6         no
```

And after a while the throughput should be correct and the alarm should go to normal state:

```
bqnadm@bqn0# show statistics interface speed lines 6
                                en0o4      en0o3o      en0o5      en0o6 ...
                                TX-Mbps   RX-Mbps   TX-Mbps   RX-Mbps   TX-Mbps   RX-Mbps   TX-Mbps   RX-Mbps ...
2021-07-02T11:10:29  400.18    92.59    93.00    397.07    318.87    37.97    39.33    312.07 ...
2021-07-02T11:15:29  386.63   110.96   112.47   382.89   340.75   42.31   43.59   333.36 ...
2021-07-02T11:20:29  400.43   129.60   134.19   396.74   329.78   39.88   41.19   323.03 ...
2021-07-02T11:25:29  394.71    86.28    87.74   394.01   331.49   39.52   41.15   325.75 ...
2021-07-02T11:30:29  418.99   123.71   126.81   412.89   353.49   38.17   39.97   347.01 ...
2021-07-02T11:35:29  394.50   119.44   121.68   390.73   356.91   39.81   41.94   350.53 ...
bqnadm@bqn0# show system alarms
TYPE              STATUS      UPDATES  TIME
cpu               normal      1 2021-06-29T15:56:56+0200
disk             normal      1 2021-06-09T11:27:41+0200
license-available normal      2 2021-07-01T17:21:38+0200
license-expiration normal      1 2021-06-09T11:27:41+0200
license-usage     normal      1 2021-06-09T11:27:41+0200
memory-dpdk       normal      1 2021-06-29T10:48:18+0200
memory-pool       normal      1 2021-06-29T10:48:18+0200
process           normal      3 2021-07-01T15:37:58+0200
time              normal      2 2021-07-01T15:37:58+0200
traffic-uplink    normal      2 2021-07-01T15:37:58+0200
traffic-downlink  normal      2 2021-07-01T15:37:58+0200
traffic-low       normal      2 2021-07-01T15:37:58+0200
traffic-inverted  normal      2 2021-07-01T15:37:58+0200
wire              normal      4 2021-07-01T15:38:33+0200
```

If there is no traffic, this alarm will stay in *unknown* state.

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.13 Process Issues

The management system monitors the BQN mandatory processes and in case of failure it automatically restarts them.

When a process fails, the *process* alarm is triggered, and a new process is restarted within seconds.

In the following example, the *apimgr* process has a failure and the *process* alarm is triggered.

```
bqnadm@bqn0# show process mandatory
BQN USER      PID STATE  RESPAWN      TIME INST PROCESS
0 root        7878 stopped 0      0:00:00.925 0 apimgr
0 root        5962 running 0      4:22:53.315 0 cfgmgr
0 root        5943 running 0      4:22:53.467 0 ctrmgr
0 root        5960 running 0      4:22:53.372 0 dnsmgr
0 root        5969 running 0      4:22:53.265 0 ipmgr
0 root        5966 running 0      4:22:53.265 0 licmgr
0 root        5964 running 0      4:22:53.283 0 ossrv
0 root        6048 running 0      4:22:52.787 0 pkteng
0 root        6141 running 0      4:22:52.381 1 pkteng
0 root        6142 running 0      4:22:52.381 2 pkteng
0 root        6143 running 0      4:22:52.376 3 pkteng
0 root        6041 running 0      4:22:52.813 0 pktengmgr
0 root        5968 running 0      4:22:53.261 0 remctr
0 root        5965 running 0      4:22:53.283 0 rtmgr
0 root        7862 running 0      4:22:53.292 0 snmpagt
0 root        5963 running 0      4:22:53.314 0 statmgr
```

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	2	2021-07-01T17:21:38+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	critical	3	2021-07-01T19:37:58+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

After a short time the process is automatically restarted and the alarm is cleared.

```
bqnadm@bqn0# show process mandatory
```

BQN	USER	PID	STATE	RESPAWN	TIME	INST	PROCESS
0	root	8432	running	1	0:00:01.618	0	apimgr
0	root	5962	running	0	4:29:14.014	0	cfgmgr
0	root	5943	running	0	4:29:14.166	0	ctrmgr
0	root	5960	running	0	4:29:14.071	0	dnsmgr
0	root	5969	running	0	4:29:13.964	0	ipmgr
0	root	5966	running	0	4:29:13.964	0	licmgr
0	root	5964	running	0	4:29:13.982	0	ossrv
0	root	6048	running	0	4:29:13.486	0	pkteng
0	root	6141	running	0	4:29:13.079	1	pkteng
0	root	6142	running	0	4:29:13.080	2	pkteng
0	root	6143	running	0	4:29:13.075	3	pkteng
0	root	6041	running	0	4:29:13.511	0	pktengmgr
0	root	5968	running	0	4:29:13.960	0	remctr
0	root	5965	running	0	4:29:13.982	0	rtmgr
0	root	7862	running	0	4:29:13.994	0	snmpagt
0	root	5963	running	0	4:29:14.013	0	statmgr

```
bqnadm@bqn0# show system alarms
```

TYPE	STATUS	UPDATES	TIME
cpu	normal	1	2021-06-29T15:56:56+0200
disk	normal	1	2021-06-09T11:27:41+0200
license-available	normal	2	2021-07-01T17:21:38+0200
license-expiration	normal	1	2021-06-09T11:27:41+0200
license-usage	normal	1	2021-06-09T11:27:41+0200
memory-dpdk	normal	1	2021-06-29T10:48:18+0200
memory-pool	normal	1	2021-06-29T10:48:18+0200
process	normal	4	2021-07-01T19:37:59+0200
time	normal	2	2021-07-01T15:37:58+0200
traffic-uplink	normal	2	2021-07-01T15:37:58+0200
traffic-downlink	normal	2	2021-07-01T15:37:58+0200
traffic-low	normal	2	2021-07-01T15:37:58+0200
traffic-inverted	normal	2	2021-07-01T15:37:58+0200
wire	normal	4	2021-07-01T15:38:33+0200

If the problem remains, then follow the instructions in the *Contacting Bequant Support* section for assistance.

4.14 Time Issues

As indicated in the installation procedure, it is important that the BQN has the correct system time. To that end, the BQN monitors that the NTP service is configured and synchronized.

4.14.1 NTP not configured

The management process triggers a *time* alarm when the NTP service is not configured.

```
bqnadm@bqn0# show system alarms
```

BQN USER	PID STATE	RESPAWN	TIME INST	PROCESS
cpu	normal	1	2021-06-29T15:56:56+0200	
disk	normal	1	2021-06-09T11:27:41+0200	
license-available	normal	1	2021-06-09T11:27:41+0200	
license-expiration	normal	1	2021-06-09T11:27:41+0200	
license-usage	normal	1	2021-06-09T11:27:41+0200	
memory-dpdk	normal	1	2021-06-29T10:48:18+0200	
memory-pool	normal	1	2021-06-29T10:48:18+0200	
process	normal	4	2021-07-02T14:04:38+0200	
time	notice	2	2021-07-02T14:21:26+0200	
traffic-uplink	normal	2	2021-07-01T15:37:58+0200	
traffic-downlink	normal	2	2021-07-01T15:37:58+0200	
traffic-low	normal	2	2021-07-01T15:37:58+0200	
traffic-inverted	normal	2	2021-07-01T15:37:58+0200	
wire	normal	1	2021-07-02T09:42:21+0200	

Make sure that the NTP service is configured. It is recommended to use several NTP servers for redundancy.

```
bqnadm@bqn0# configure
bqnadm@bqn0(config)# service ntp
bqnadm@bqn0(config-ntp)# server 18.26.4.105
bqnadm@bqn0(config-ntp)# server 145.238.203.14
bqnadm@bqn0(config-ntp)# server 188.119.192.10
bqnadm@bqn0(config-ntp)# server 193.145.15.15
bqnadm@bqn0(config-ntp)# root
bqnadm@bqn0(config)# commit
bqnadm@bqn0(config)# end
bqnadm@bqn0# show service ntp
ntp.service - LSB: Network time protocol daemon (ntpd)
  Loaded: loaded (/bqn/img/linux/etc/init.d/ntp)
  Drop-In: /run/systemd/generator/ntp.service.d
           -50-insserv.conf-$time.conf
  Active: active (running) since Fri 2021-07-02 09:41:46 CEST; 4h 44min ago
  . . .
bqnadm@bqn0#
```

4.14.2 NTP Service not Synchronized

While the NTP time is not synchronized the *time* alarm is triggered.

```
bqnadm@bqn0# show system alarms
```

BQN USER	PID STATE	RESPAWN	TIME INST	PROCESS
cpu	normal	1	2021-06-29T15:56:56+0200	
disk	normal	1	2021-06-09T11:27:41+0200	
license-available	normal	1	2021-06-09T11:27:41+0200	
license-expiration	normal	1	2021-06-09T11:27:41+0200	
license-usage	normal	1	2021-06-09T11:27:41+0200	
memory-dpdk	normal	1	2021-06-29T10:48:18+0200	
memory-pool	normal	1	2021-06-29T10:48:18+0200	
process	normal	4	2021-07-02T14:04:38+0200	
time	notice	2	2021-07-02T14:21:26+0200	
traffic-uplink	normal	2	2021-07-01T15:37:58+0200	
traffic-downlink	normal	2	2021-07-01T15:37:58+0200	
traffic-low	normal	2	2021-07-01T15:37:58+0200	
traffic-inverted	normal	2	2021-07-01T15:37:58+0200	
wire	normal	1	2021-07-02T09:42:21+0200	

Make sure that the configured NTP servers are reachable by setting the appropriate static routes to the NTP servers.

If the management interface is behind a firewall, make sure that the NTP server IPs are reachable (NTP uses port 123 of the UDP protocol).

Once the NTP servers are reachable, the BQN NTP service should synchronize:

```
bqnadm@bqn0# show system ntp
REMOTE          REFID          ST T WHEN POLL REACH   DELAY   OFFSET  JITTER
+188.119.192.10  150.214.94.5   2 U 333 1024   377 12.666 -68.433  5.622
*145.238.203.14  .MRS.          1 U 390 1024   377 25.680 -78.606  7.907
+193.145.15.15   193.147.107.33 2 U 305 1024   377  5.027 -74.237  6.768
18.26.4.105      .M12.          1 U 133M 256      0 100.014 -50.026  0.000
```

In this example, at least three servers are synchronized with the BQN (those marked with +).

Note that if the BQN system time and the network time vary, it could take some time for the system to reach the right time, and that during that period the *time* alarm will be armed.

If the problem persists, follow the instructions in the *Contacting Bequant Support* section for assistance.

4.14.3 Server clock not set to UTC

A correct installation of BQN requires the server clock in the BIOS to be set to UTC (Coordinated Universal Time). If this has not been done, it could be corrected by setting the local time again. The change should be run at times of low traffic, because changing the system clock may cause a brief service interruption:

```
bqnadm@bqn0# show system date full
  Local time: Tue 2022-02-15 13:06:18 CET
  Universal time: Tue 2022-02-15 12:06:18 UTC
    RTC time: Tue 2022-02-15 09:05:45
    Timezone: Europe/Madrid (CET, +0100)
  NTP enabled: n/a
NTP synchronized: no
  RTC in local TZ: no
bqnadm@bqn0# system date local 2022-02-15 13:09:00
bqnadm@bqn0# show system date full
  Local time: Tue 2022-02-15 13:09:02 CET
  Universal time: Tue 2022-02-15 12:09:02 UTC
    RTC time: Tue 2022-02-15 12:09:02
    Timezone: Europe/Madrid (CET, +0100)
  NTP enabled: n/a
NTP synchronized: no
  RTC in local TZ: no
```

4.15 Contacting Bequant Support

Please contact Bequant support at support@bequant.com and include the following information:

1. Detailed problem description and the steps performed so far to try to solve the problem.
2. System diagnostic file as indicated in the *Diagnostic Generation* section in the *User Guide*.

If remote access to the BQN is available, please provide detailed instructions to access it in order for Bequant engineers to directly analyze the problem.

Note that if a software bug is the cause of the problem, it may be necessary to update the software with a newer version that fixes the problem.

Virtual Machine Environment

This chapter describes how to prepare a VMware or KVM environment to install a BQN virtual machine.

A.1 Prerequisites

The minimum resources for a BQN virtual machine are:

- 2 vCPUs
- 8 GB of RAM
- 16 GB of disk
- 3 network ports. Two will be used for data plane processing and the third one for management.

All resources will be fully dedicated (pinned) to the virtual machine (no oversubscription). Depending on the traffic load, check with Bequant the required resources needed. As a general guideline, use the following resources:

- For each wire of 1Gbps capacity: 2 vCPUs and 8 GB of RAM.
- For each wire of 10Gbps capacity: 12 vCPUs and 32 GB of RAM.

where each vCPU is equivalent to one core of an Intel Xeon E5-2630 v4 @ 2.20GHz CPUs, with hyperthreading enabled.

For the data plane interfaces, the recommended configuration is using Intel network cards with PCI passthrough, because of performance and reliability reasons. Other options are described below, but before using them, contact Bequant support.

A.2 VMware

The management interface can be connected to a pre-existing virtual switch used for the management of other VMs.

A.2.1 PCI Passthrough Option

Follow these instruction to setup the VM using PCI passthrough:

1. Under *Host*→*Manage*→*Hardware*→*PCI devices*, mark *Toggle Passthrough* in the two physical ports that will be used for the data plane of the BQN virtual machine. The management interface does not need to be in PCI-passthrough mode.
2. Create the virtual machine with the following options:
 - *Guest OS family*: *Linux*
 - *Guest OS version*: *SUSE Linux Enterprise 12*
3. Under *Memory*, mark *Reserve all guest memory*
4. In the *Machine* menu *Add other device*→*PCI device* page, the two physical ports previously placed in passthrough mode should be available. Select them both.

5. Select the desired amount of memory, CPUs and disk space. Check with Bequant the resources needed for you traffic throughput.
6. Configure a *CD/DVD Media* of type *Datastore ISO file* and select the BQN ISO file to install.

A.2.2 VMXNET Option

This is not a generally supported option. Contact Bequant support before using it.

Two virtual switches will be created for the data plane. The access network port will be connected to one of the virtual switches and the Internet port to the other.

1. Create two virtual switches, Access and Internet. For each virtual switch, set the following options under *Configuration*→*Networking*→*Virtual Switch Properties*→*Security*:
 - *promiscuous mode*
 - *forged transmits*
2. Create two port groups, Access and Internet, and associate them to their corresponding virtual switches. In the *Security* option, mark that they will inherit their switch settings.
3. Create the virtual machine with the following options:
 - *Guest OS family: Linux*
 - *Guest OS version: SUSE Linux Enterprise 12*
4. Create three network interfaces, one connected to the OAM switch and the other two to the Access and Internet switches. Make the Access and Internet interfaces of type VMXNET¹.
5. Select the desired amount of memory, CPUs and disk space. Check with Bequant the resources needed for you traffic throughput.
6. Configure a *CD/DVD Media* of type *Datastore ISO file* and select the BQN ISO file to install.

A.3 KVM

The software requirements are the following:

- Linux kernel of the host machine should be version 4.11 or later.
- QEMU should be version 2.9 or later.

The Virtual Machine (VM) will need one network interface for management and at least another two for data plane packet processing.

The following sections describe the configuration details. To interact with QEMU, *virt-manager* the *Virtual Machine Manager* part of the *libvirt* package are used, but equivalent commands should be available in other popular managers.

The configuration of a VM is stored on an XML file. This file is located in the following directory:

`/etc/libvirt/qemu`

The configuration file name is the name of the virtual machine plus the `.xml` extension. Note that it is highly inadvisable to modify the configuration file directly.

A.3.1 Virtual Machine Creation

1. Copy the Bequant ISO file to the host machine where the VM will be created.
2. Select *New Virtual Machine*.
3. Under *Connection*, choose the host where the VM will be created (local or remote to the *virt-manager*).
4. Select *Choose ISO or CDROM install media* as the installation method.
5. Type the path to the Bequant ISO file previously copied to the host machine.
6. Under *Choose the operating system you are installing* enter *openSUSE*.

¹VMXNET is the preferred option for performance reasons. Use E1000 only if VMXNET is not possible

7. Under *Choose memory and CPU setting*, select the desired amount of memory and the number of CPUs. Check with Bequant the resources needed for you traffic throughput.
8. In the next window, select the desired disk size.
9. Check the option *Customize configuration before install*.

A.3.2 Virtual Disk

Select either *VirtIO* or *SATA* disk bus type. Note that the 4.12.14 kernel fails to start if the *IDE* disk bus type is selected.

A.3.3 Network interfaces

A minimum of three interfaces must be created in the VM.

The first interface, used for management, is normally already added when the VM is created. If it is not, select *Add hardware* and choose *Network*.

The other two network interfaces are for data plane traffic processing and should be added.

For the data plane interfaces, the recommended configuration is using Intel network cards with PCI passthrough, because of performance and reliability reasons. Other options are described below, but before using them, contact Bequant support.

A.3.3.1 PCI passthrough

For each network interface (e.g. for each of the two data plane interfaces):

1. Verify that the CPU of the host server has the VT-d instruction set enabled. This is usually set under the server BIOS menu.
2. The host OS kernel must have the kernel parameter `intel_iommu` enabled.
3. Select *Add Hardware*.
4. Choose *PCI Host Device*.
5. Under *Host Device* select the network interface to be used in PCI passthrough.

One example of the XML section created in the configuration file:

```
<hostdev mode="subsystem" type="pci" managed="yes">
  <source>
    <address domain="0" bus="3" slot="0" function="0"/>
  </source>
</hostdev>
```

A.3.3.2 Linux bridges

This is not a generally supported option. Contact Bequant support before using it.

For each network interface (e.g. for each of the two data plane interfaces):

1. Select *Add Hardware*.
2. Choose *Network*.
3. Under *Network source* select *Bridge Device*.
4. Under *Device name* specify the name of the bridge.
5. Select *virtio* as the *Device model*.

On the host server, check that hardware offloading is disabled in the physical interfaces participating in the bridges. If offloading needs to be disabled, enter the following commands as `root`:

```
ethtool -K 'iface1' tx on rx on tso off gso off gro off
ethtool -K 'iface2' tx on rx on tso off gso off gro off
```

Make these changes persistent according to your Linux distribution. Make sure that the interfaces are in promiscuous mode (being part of a bridge they should already be).

One example of the XML section created in the VM configuration file:

```
<interface type="bridge">
  <mac address="52:54:00:84:eb:c2"/>
  <source bridge="bridgeManagement"/>
  <model type="virtio"/>
  <address type="pci" domain="0x0000" bus="0x06" slot="0x00"
function="0x0"/>
</interface>
```

A.3.3.3 MACVTAP over a device

This is not a generally supported option. Contact Bequant support before using it.

For each network interface (e.g. for each of the two data plane interfaces):

1. Select *Add Hardware*.
2. Choose *Network*.
3. Under *Network source* select *Macvtap device*.
4. Under *Device name* specify the name of the network device.
5. Select *virtio* as the *Device model*.

On the host server, check that hardware offloading is disabled in the physical interfaces being tapped. If offloading needs to be disabled, enter the following commands as **root**:

```
ethtool -K 'ifacel' tx on rx on tso off gso off gro off
ethtool -K 'iface2' tx on rx on tso off gso off gro off
```

Make these changes persistent according to your Linux distribution. Make sure that the interfaces are in promiscuous mode (they should already be, being tapped).

One example of the XML section created in the VM configuration file:

```
<interface type="direct">
  <mac address="52:54:00:84:eb:c2"/>
  <source dev="enp4s0" mode="bridge"/>
  <model type="virtio"/>
  <address type="pci" domain="0x0000" bus="0x06" slot="0x00" function="0x0"/>
</interface>
```


Intel Ethernet Controller X710 Firmware Update

This chapter describes how to update the firmware for ethernet network adapters based on the *Intel Ethernet Controller X710*.

1. Obtain the latest version of the *Non-Volatile Memory (NVM) Update Utility for Intel® Ethernet Adapters 700 Series* for the Linux operating system from the official Intel web page:

<https://downloadcenter.intel.com/product/82947/Intel-Ethernet-Controller-X710-Series>

At the time of writing, the latest package version is 7.2.

2. Move the downloaded package to the BQN (if downloaded from a different system) and unpack it as **root** in the home directory.

```
bqn0:~ # tar xvzf 700Series_NVMUpdatePackage_v7_20_Linux.tar.gz
```

and change the current directory into the Linux directory:

```
bqn0:~ # cd 700Series/Linux_x64
```

```
bqn0:~/700Series/Linux_x64 #
```

3. Before the Intel adapters can be updated, it is important to remove the existing PKTENG configuration so that the Intel update utility can access the ethernet adapters.

```
bqn0:~/700Series/Linux_x64 # bqnsb
Copyright (c) 2009-2015 Bequant S.L.
root@bqn0# configure
root@bqn0(config)# no pkteng
root@bqn0(config)# commit
root@bqn0(config)# end
root@bqn0# exit
bqn0:~/700Series/Linux_x64 #
```

4. Execute the Intel firmware update utility and after all the available adapters are listed enter the adapter number when prompted (in this example the *Intel(R) Ethernet Converged Network Adapter X710-4*, which is listed as 02).

```
bqn0:~/700Series/Linux_x64 # ./nvupdate64e
Intel(R) Ethernet NVM Update Tool
NVMUpdate version 1.34.22.6
Copyright (C) 2013 - 2019 Intel Corporation.
```

WARNING: To avoid damage to your device, do not stop the update or reboot or power off the system during the Inventory in progress. Please wait [*****-....]

Num	Description	Ver.(hex)	DevId S:B	Status
01)	Intel(R) Ethernet Connection X552 10 GbE SFP+	n/a(n/a)	15AC 00:004	Update not available
02)	Intel(R) Ethernet Converged Network Adapter X710-4	4.37(4.25)	1572 00:006	Update available
03)	Intel(R) I350 Gigabit Network	1.99(1.63)	1521 00:011	Update not available

```

Connection
04) Intel(R) I210 Gigabit Network      n/a(n/a)  1533 00:007 Access error
Connection
05) Intel(R) I210 Gigabit Network      n/a(n/a)  1533 00:008 Access error
Connection

```

```

Options: Adapter Index List (comma-separated), [A]ll, e[X]it
Enter selection: 02
Would you like to back up the NVM images? [Y]es/[N]o: Y
Update in progress. This operation may take several minutes.
[...|*****]

```

Num	Description	Ver.(hex)	DevId S:B	Status
01)	Intel(R) Ethernet Connection X552 10 GbE SFP+	n/a(n/a)	15AC 00:004	Update not available
02)	Intel(R) Ethernet Converged Network Adapter X710-4	4.66(4.42)	1572 00:006	Update successful
03)	Intel(R) I350 Gigabit Network Connection	1.99(1.63)	1521 00:011	Update not available
04)	Intel(R) I210 Gigabit Network Connection	n/a(n/a)	1533 00:007	Access error
05)	Intel(R) I210 Gigabit Network Connection	n/a(n/a)	1533 00:008	Access error

Please Power Cycle your system now and run the NVM update utility again to complete the update. Failure to

Tool execution completed with the following status: The selected adapter (location:[08:00:00]) cannot be up
Update the device driver and reboot the system before running this utility again.
Consult the utility documentation for more information.
Press any key to exit.

Note that after executing `nvmupdate64e` the version has been upgraded from 4.37 to 4.66.

A As indicated by the utility program, the system must be restarted and the update utility must be executed again, since the update process is incremental, until the latest version is installed.

```
bqn0:~/700Series/Linux_x64 # shutdown -r now
```

5. Change the current directory to the location where the update application was unpacked and execute the update utility again until the latest version is installed.

```

bqn0:~ # cd 700Series/Linux_x64
bqn0:~/700Series/Linux_x64 # ./nvmupdate64e
Intel(R) Ethernet NVM Update Tool
NVMUpdate version 1.34.22.6
Copyright (C) 2013 - 2019 Intel Corporation.

```

WARNING: To avoid damage to your device, do not stop the update or reboot or power off the system during the
Inventory in progress. Please wait [*****|....]

Num	Description	Ver.(hex)	DevId S:B	Status
01)	Intel(R) Ethernet Connection X552 10 GbE SFP+	n/a(n/a)	15AC 00:004	Update not available
02)	Intel(R) Ethernet Converged Network Adapter X710-4	4.66(4.42)	1572 00:006	Update available
03)	Intel(R) I350 Gigabit Network Connection	1.99(1.63)	1521 00:011	Update not available
04)	Intel(R) I210 Gigabit Network Connection	n/a(n/a)	1533 00:007	Access error

05) Intel(R) I210 Gigabit Network Connection n/a(n/a) 1533 00:008 Access error

Options: Adapter Index List (comma-separated), [A]ll, e[X]it

Enter selection: **02**

Would you like to back up the NVM images? [Y]es/[N]o: **Y**

Update in progress. This operation may take several minutes.

[**-.....]

Num	Description	Ver.(hex)	DevId	S:B	Status
01)	Intel(R) Ethernet Connection X552 10 GbE SFP+	n/a(n/a)	15AC	00:004	Update not available
02)	Intel(R) Ethernet Converged Network Adapter X710-4	7.32(7.20)	1572	00:006	Update successful
03)	Intel(R) I350 Gigabit Network Connection	1.99(1.63)	1521	00:011	Update not available
04)	Intel(R) I210 Gigabit Network Connection	n/a(n/a)	1533	00:007	Access error
05)	Intel(R) I210 Gigabit Network Connection	n/a(n/a)	1533	00:008	Access error

Reboot is required to complete the update process.

Tool execution completed with the following status: The selected adapter (location:[08:00:00]) cannot be up

Update the device driver and reboot the system before running this utility again.

Consult the utility documentation for more information.

Press any key to exit.

⚠ Note that this time the version has finally updated to 7.32, so in this case a final reboot is required and the update process is completed; otherwise, reboot and repeat this step until the latest version is updated.

bqn0:~/700Series/Linux_x64 # **shutdown -r now**

End User License Agreement

This chapter contains the Bequant End User License Agreement document. Note that the EULA can be displayed from the CLI using the `show license eula` command.

C.1 Bequant End User License Agreement

THIS END USER LICENSE AGREEMENT ("EULA") IS A LEGAL AGREEMENT BETWEEN YOU (EITHER AN INDIVIDUAL OR AN ENTITY) AND BEQUANT S.L., A SPANISH PRIVATE LIMITED LIABILITY CORPORATION, HAVING ITS PRINCIPAL PLACE OF BUSINESS AT CALLE RAIMUNDO FERNÁNDEZ VILLAVERDE 61, MADRID 28003, SPAIN, WITH CIF (TAX ID) ES-B85612539, REGISTERED IN THE MADRID MERCANTILE REGISTRY, VOLUME 26.401, FOLIO 62, SECTION 8, SHEET M-475.780, 1st INSCRIPTION. ("BEQUANT"). THIS AGREEMENT GOVERNS ALL SOFTWARE ("SOFTWARE") AND ANY UPGRADES, UPDATES, PATCHES, HOTFIXES, MODULES, ROUTINES, FEATURE ENHANCEMENTS AND ADDITIONAL VERSIONS OF THE SOFTWARE THAT REPLACE OR SUPPLEMENT THE ORIGINAL SOFTWARE (COLLECTIVELY CALLED "UPDATES") AND THEIR ASSOCIATED MEDIA, PRINTED MATERIALS, ONLINE OR ELECTRONIC DOCUMENTATION, DISTRIBUTED BY OR ON BEHALF OF BEQUANT. THE "SOFTWARE" SHALL MEAN COLLECTIVELY THE SOFTWARE PROGRAM AND UPDATES AND ANY COPIES THEREOF. THIS EULA, IN AND OF ITSELF, DOES NOT ENTITLE YOU TO ANY UPDATES AT ANY TIME IN THE FUTURE. BY EXPRESSLY ACCEPTING THESE TERMS OR BY DOWNLOADING, INSTALLING, ACTIVATING AND/OR OTHERWISE USING THE SOFTWARE, YOU ARE AGREEING THAT YOU HAVE READ, AND THAT YOU AGREE TO COMPLY WITH AND ARE BOUND BY THE TERMS AND CONDITIONS OF THIS EULA AND ALL APPLICABLE LAWS AND REGULATIONS. IF YOU DO NOT AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS EULA, THEN YOU MAY NOT DOWNLOAD, INSTALL, ACTIVATE OR OTHERWISE USE ANY OF THE SOFTWARE. IF YOU ARE ACCEPTING THESE TERMS AND CONDITIONS ON BEHALF OF AN ENTITY, YOU ACKNOWLEDGE THAT YOU HAVE THE APPROPRIATE AUTHORITY TO ACCEPT THESE TERMS AND CONDITIONS ON BEHALF OF SUCH ENTITY.

1. **License.** Subject to the terms, conditions and restrictions of this EULA (as a condition to the grant below), Bequant hereby grants you a limited, nonexclusive, nontransferable, non-assignable license, without rights to sublicense, to install or have installed, display and use the Software (in object code form only) solely for internal purposes, only on the computers, devices and/or in such configurations as expressly permitted by Bequant (e.g., as set forth in the applicable Bequant, or its authorized RESELLER, sales quote or invoice), and for such period specified in a term license, or perpetually if no term is specified. The SOFTWARE license is limited to a maximum amount of data processing rate, as expressly permitted by Bequant (e.g., as set forth in the applicable Bequant, or its authorized RESELLER, sales quote or invoice), with this limitation enforced automatically by the software. The SOFTWARE shall require a license code for activation, which shall be specific for each hardware or virtual machine where the SOFTWARE is allowed to run. This activation code may be supplied directly by BEQUANT or may be obtained by the SOFTWARE by connecting it to an online license server provided by BEQUANT, and may require periodic validation.
2. **License Conditions.** This license is conditioned upon BEQUANT, or a RESELLER authorized by BEQUANT, receiving your timely payment of any fees or royalties applicable to the Software,

according to an official quote from BEQUANT, or from a RESELLER authorized by BEQUANT, to you for which you place an order. If no such quotation and order exist, the license is void and you have no rights over the Software.

3. **License Limitations.** You may not copy the Software except for a reasonable number of copies solely as needed for backup or archival purposes or as otherwise expressly permitted in Section 1 "License" above. You may not modify or remove any titles, trademarks or trade names, copyright notices, legends, or other proprietary notices or markings on or in the Software. The rights granted herein are limited to Bequant's and its licensors' and suppliers' intellectual property rights in the Software and do not include any other third party's intellectual property rights. If the Software was provided to you on removable media (e.g., CD, DVD, or USB drive), you may own the media on which the Software is recorded but Bequant, Bequant's licensor(s) and/or supplier(s) retain ownership of the Software itself and all related intellectual property rights. You are not granted any rights to any trademarks or service marks of Bequant or any of its licensors or suppliers.
4. **Rights Reserved.** THE SOFTWARE IS LICENSED, NOT SOLD. Except for the license expressly granted in this EULA, Bequant, on behalf of itself and its licensors and suppliers, retains all right, title, and interest in and to the Software and in all related content, materials, copyrights, trade secrets, patents, trademarks, derivative works and any other intellectual and industrial property and proprietary rights, including moral rights, registrations, applications, renewals and extensions of such rights (the "Works"). The rights in these Works are valid and protected in all forms, media and technologies existing now or hereafter developed and any use other than as expressly set forth herein, including the reproduction, modification, distribution, transmission, adaptations, translation, display, republication or performance of the Works is strictly prohibited. Bequant, on behalf of itself and its licensors and suppliers, retains all rights not expressly granted herein.
5. **Derivative works or contributions.** To the extent that your use of the Product and/or contributions through the use of the Product, including any feedback or information given to Bequant or its agents during any support or maintenance services rendered by Bequant give rise to any copyright interest or any intellectual and/or industrial property rights, Bequant shall be the sole and exclusive owner of such rights which shall be deemed automatically included in this License and licensed to you in the terms hereof. Such ownership shall entitle Bequant to use the contributions in any way and for any purpose in connection with the Product and related goods and services including the rights to reproduce, copy, adapt, modify, perform, display, publish, broadcast, transmit, or otherwise communicate to the public and/or exploit by any means whether now known or hereinafter devised without any further notice or compensation to you of any kind. To the extent permitted, you hereby waive any moral rights or attribution under applicable law with respect to Bequant and its licensees use and enjoyment of such assets in connection with the Product and related goods and services. The transfer of ownership to Bequant and the above waiver of any applicable moral rights, survives any termination of this License.

In the event that Bequant communicates and/or exploits by any means any feedback, information or contribution from the user, the personal data of the latter will be anonymized or pseudonymized prior to the publication of such contributions, according to the GDPR or any other applicable data protection legislation.

6. **Restrictions.** Except as otherwise provided herein or expressly agreed by Bequant, you may not, and will not allow a third party to: (A) sell, lease, license, sublicense, assign, distribute or otherwise transfer or encumber by any means (including by lien, hypothecation or otherwise) in whole or in part the Software; (B) provide, make available to, or permit use of the Software in whole or in part by, any third party, including contractors, without Bequant's prior written consent, unless such use by the third party is solely on your behalf, is strictly in compliance with the terms and conditions of this EULA, and you are liable for any breach of this EULA by such third party (a "Permitted Third Party"); (C) copy, reproduce, republish, upload, post or transmit the Software in any way; (D) decompile, disassemble, reverse engineer, or otherwise attempt to derive source code (or underlying ideas, algorithms, structure or organization) from the Software program, in whole or in part; (E) modify or create derivative works based upon the Software, even for fault correction; (F) use the Software on a service bureau, rental or managed services basis or permit other individuals or entities to create Internet "links" to the Software or "frame" or "mirror" the Software on any other server or wireless or Internet-based device; (G) use the Software to create a competitive offering; or (H) share or publish the results of any benchmarking of the Software without Bequant's prior written consent. You may not, and will not allow a Permitted Third Party to, use the Software in excess of the number of licenses purchased from or expressly authorized by Bequant.

7. **Compliance.** Upon request by Bequant, you will certify in writing that all use of Software is in compliance with the terms of this EULA, indicating the number of Software licenses deployed at that time. You grant Bequant, or an agent selected by Bequant, the right to perform, during normal business hours, a reasonable audit of your compliance with this EULA. You agree to cooperate and provide Bequant with all records reasonably related to your compliance with this EULA. Such audits will be performed according to any provisions on data protection, non-disclosure and/ or confidentiality on this contract and/ or provided by law.
8. **Non-Transferability.** This license is non-transferable. You may not distribute, sublicense, assign, share, sell, grant a security interest in, use for service bureau purposes, or otherwise transfer the Software or your license to use the Software without the prior written consent of Bequant.
9. **Maintenance and Support Services Not Included.** Bequant does not provide any maintenance or support services under this EULA. Maintenance and support services, if any, are provided under a separate agreement.
10. **Open-Source:** Certain components of the Software may be subject to open-source software licenses ("Open-Source Components"), which means any software license approved as open-source licenses by the Open Source Initiative or any substantially similar licenses, including without limitation any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format. The Software documentation includes copies of the licenses applicable to the Open-Source Components. To the extent there is conflict between the license terms covering the Open-Source Components and this EULA, the terms of such licenses will apply in lieu of the terms of this EULA. To the extent the terms of the licenses applicable to Open-Source Components prohibit any of the restrictions in this Agreement with respect to such Open-Source Component, such restrictions will not apply to such Open-Source Component. To the extent the terms of the licenses applicable to Open-Source Components require Licensor to make an offer to provide source code in connection with the Product, such offer is hereby made, and you may exercise it by contacting Bequant.
11. **Termination.** Bequant may terminate this EULA immediately and without prior notice if you fail to comply with any term or condition of this EULA or if Bequant does not receive timely payment for the licenses to the Software. This EULA will terminate automatically if you fail to comply with any of its terms or if the license term ends. You may terminate this EULA at any time on written notice to Bequant. In the event of termination of this EULA, all licenses granted hereunder shall automatically terminate and you must immediately cease use of the Software and return or destroy all copies of the Software. The parties recognize and agree that their obligations under this EULA, as well as obligations for payment, shall survive the cancellation, termination and/or expiration of this EULA, and/or the licenses granted hereunder. Bequant will not have any obligation upon the termination of this EULA to refund any portion of any license fee.
12. **Export, Import and Government Restrictions.** The Software is subject to European Union ("EU") export laws (in particular Regulation (EC) No 428/2009), as well as the laws of the country where it is delivered or used. You agree to abide by these laws.
13. **Warranty.** The software is covered by a one-year guarantee service, free of charge. The guarantee service consists on access to patches and fault fixes, or to a software update collecting a number of such patches and fixes. This guarantee starts from the day of the software delivery.
Bequant makes, and you receive, no other warranties related to the software whether express, implied or statutory, and Bequant specifically disclaims any implied warranties of merchantability, fitness for a particular purpose, and non-infringement. Bequant does not warrant that the functions of the software will meet your requirements or that operation of the software will be uninterrupted or error free. You assume responsibility for selecting the software and the results achieved. Your sole and exclusive remedy, and Bequant's entire liability, is for Bequant, at its sole discretion, to either use commercially reasonable efforts to remedy any defect in the software or to provide a refund of the license fees received by Bequant for the software and terminate this agreement. This disclaimer of warranty may not be valid in some jurisdictions and you may have warranty rights under law which may not be waived or disclaimed.
14. **Limitation of Liability.** Bequant will not be liable for any lost profits, lost savings, lost value or lost sales (whether such profits, savings, value or sales are direct, indirect, consequential or of any other nature), lost or corrupted data or software, loss of use of system(s) or network(s), or the recovery of such data, systems(s) or network(s), loss of business opportunity, business interruption or downtime, loss of goodwill or reputation, software not being available for use or the procurement of substitute software or goods, incidental, indirect, punitive, special or consequential damages

arising out of or in connection with this EULA under any theory of liability even if advised or aware of the possibility of such damages.

Notwithstanding anything to the contrary set forth in this EULA, Bequant's total liability for any and all claims arising out of or in connection with this EULA and/or the software shall not exceed the total amount received by Bequant for the applicable software license during the twelve month period immediately preceding the date on which the relevant claim arose.

Insofar as applicable law prohibits any limitation on liability herein, the parties agree that such limitation will be automatically modified, but only to the extent required to make the limitation compliant with applicable law.

15. **Injunctive Relief.** You agree that a breach of this License may cause irreparable injury to Bequant for which monetary damages would or may not be an adequate remedy and Bequant shall be entitled to seek equitable relief in addition to any other remedies it may have hereunder or at law.
16. **High-Risk Disclaimer.** The Software is not designed or intended for high-risk applications, for use as online control systems or use in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communications systems, air traffic control, life support, weapons systems or in any other device or system in which function or malfunction of the software could result in death, personal injury or physical or environmental damage.
17. **Choice of Law.** This agreement and any claims under any theory of liability in any way to this agreement or any relationships contemplated herein shall be governed and construed in accordance with the laws of Spain.
18. **No Waiver.** No waiver of breach or failure to exercise any option, right, or privilege under the terms of this EULA on any occasion by Bequant shall be construed to be a waiver of a subsequent breach or right to exercise any option, right, or privilege.
19. **No Assignment.** Customer may not assign or transfer its interests, rights or obligations under this EULA, in whole or in part, whether voluntarily, by contract, or by merger (whether that party is the surviving or disappearing entity), stock or asset sale, consolidation, dissolution, through government action or order, or otherwise. Any attempt to assign this EULA without prior written consent from an authorized executive officer of Bequant shall be null and void.
20. **Entire Agreement.** Unless you have entered into another written agreement with respect to the Software which has been signed by you and an authorized representative of Bequant and which conflicts with the terms of this EULA, you agree that this EULA supersedes all prior written or oral agreements, warranties or representations with respect to the use of the Software. If any term (or part thereof) of this EULA is found to be invalid or unenforceable, the remaining provisions (including other valid parts within the affected term) will remain effective. You acknowledge that you have read this Agreement, that you understand it, that you agree to be bound by its terms, and that this is the complete and exclusive agreement between you and Bequant.
21. **Confidentiality.** Each party must treat all Confidential Information received from the other party as it would treat its own confidential information generally, but with no less than a reasonable degree of care.
22. **Data Protection.** Bequant will scrupulously respect the confidentiality of the personal data submitted by you, and it will initiate any measures necessary for their processing according to the observance of the regulations in force on the protection of data and, among others, the provisions of the Spanish Organic Law 3/2018, of 5th December, on the Protection of Personal Data and Guarantee of Digital Rights. The personal data that you provide to Bequant will be used for the maintenance of the business relationship between you and Bequant, or any other legitimate reason under such regulations. Refusal to provide your essential personal data will not allow Bequant to offer you our services.

Besides, under your specific consent, Bequant will inform you about new products that affect the development of the present Bequant's license.

You have the following rights with regards to your personal data: the right to be informed, of access, to rectification, to erasure, to restrict processing, to data portability, to object processing, and to object to automated decision making and profiling.

If you wish to exercise such rights, you will have to contact Bequant in writing at the abovementioned address enclosing an official means of identification. You can also exercise at any time your right to opt-out from receiving any marketing communication or chose other communication modalities.

You can also lodge a complaint with the Spanish Data Protection Authority (Agencia Española de Protección de Datos).

23. **Data for License Validation and Preventive Maintenance.** The Bequant Software may contact a secure on-line license validation server over Internet. Said server, maintained by Bequant, will collect usage information for the purpose of validating the capacity limitation of the license, as well as allowing preventive maintenance. It shall therefore be necessary for you to ensure the Bequant software has access to said server over Internet to allow a daily validation of the software license.

Open Source Licenses

D.1 Third Party Software

This product uses *libedit*.

Copyright (c) 1992, 1993 The Regents of the University of California. All rights reserved.
This code is derived from software contributed to Berkeley by Christos Zoulas of Cornell University.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION). HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes software based on the red-black tree implemented in the Standard Template Library (STL) v3.3 by SGI.

Copyright (c) 1996,1997. Silicon Graphics Computer Systems, Inc.
Permission to use, copy, modify, distribute and sell this software and its documentation for any purpose is hereby granted without fee, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation. Silicon Graphics makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

Copyright (c) 1994. Hewlett-Packard Company
Permission to use, copy, modify, distribute and sell this software and its documentation for any purpose is hereby granted without fee, provided that the above copyright notice appear in all copies and that both that copyright notice and this permission notice appear in supporting documentation. Hewlett-Packard Company makes no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

This product includes software that uses the *TurboJPEG* API.

Copyright (C)2009-2016 D. R. Commander. All Rights Reserved.
Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the libjpeg-turbo Project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS", AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes software that uses the *libgd* API.

In order to resolve any possible confusion regarding the authorship of gd, the following copyright statement covers all of the authors who have required such a statement. If you are aware of any oversights in this copyright notice, please contact Pierre-A. Joye who will be pleased to correct them.

- Portions copyright 1994, 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004 by Cold Spring Harbor Laboratory. Funded under Grant P41-RR02188 by the National Institutes of Health.
- Portions copyright 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004 by Boutell.Com, Inc.
- Portions relating to GD2 format copyright 1999, 2000, 2001, 2002, 2003, 2004 Philip Warner.
- Portions relating to PNG copyright 1999, 2000, 2001, 2002, 2003, 2004 Greg Roelofs.
- Portions relating to gdttf.c copyright 1999, 2000, 2001, 2002, 2003, 2004 John Ellson (ellson@graphviz.org).
- Portions relating to gdfc.c copyright 2001, 2002, 2003, 2004 John Ellson (ellson@graphviz.org).
- Portions copyright 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007 Pierre-Alain Joye (pierre@libgd.org).
- Portions relating to JPEG and to color quantization copyright 2000, 2001, 2002, 2003, 2004, Doug Becker and copyright (C) 1994, 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004 Thomas G. Lane. This software is based in part on the work of the Independent JPEG Group. See the file README-JPEG.TXT for more information.
- Portions relating to GIF compression copyright 1989 by Jef Poskanzer and David Rowley, with modifications for thread safety by Thomas Boutell.
- Portions relating to GIF decompression copyright 1990, 1991, 1993 by David Koblas, with modifications for thread safety by Thomas Boutell.
- Portions relating to WBMP copyright 2000, 2001, 2002, 2003, 2004 Maurice Szmurlo and Johan Van den Brande.
- Portions relating to GIF animations copyright 2004 Jaakko Hyvätti (jaakko.hyvatti@iki.fi)

Permission has been granted to copy, distribute and modify gd in any context without fee, including a commercial application, provided that this notice is present in user-accessible supporting documentation.

This does not affect your ownership of the derived work itself, and the intent is to assure proper credit for the authors of gd, not to interfere with your productive use of gd. If you have questions, ask. "Derived works" includes all programs that utilize the library. Credit must be given in user-accessible documentation.

This software is provided "AS IS." The copyright holders disclaim all warranties, either express or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to this code and accompanying documentation.

Although their code does not appear in the current release, the authors wish to thank David Koblas, David Rowley, and Hutchison Avenue Software Corporation for their prior contributions.

Web interface based on AdminBSBMaterialDesign theme:

The MIT License (MIT) Copyright (c) 2016 Güray Yazar

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes software that uses DPDK:

The DPDK uses the Open Source BSD-3-Clause license for the core libraries and drivers. The kernel components are naturally GPL-2.0 licensed.

SPDX-License-Identifier: BSD-3-Clause

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

This product includes software that uses windowed min/max tracker by Kathleen Nichols:

Copyright 2017, Google Inc.

Use of this source code is governed by the following BSD-style license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Google Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes *OpenSUSE Linux distribution*.

This agreement governs your download, installation, or use of openSUSE 13.1 and its updates, regardless of the delivery mechanism. openSUSE 13.1 is a collective work under US Copyright Law. Subject to the following terms, The openSUSE Project grants to you a license to this collective work pursuant to the GNU General Public License version 2. By downloading, installing, or using openSUSE 13.1, you agree to the terms of this agreement. openSUSE 13.1 is a modular Linux operating system consisting of hundreds of software components. The license agreement for each component is generally located in the component's source code. With the exception of certain files containing the "openSUSE" trademark discussed below, the license terms for the components permit you to copy and redistribute the component. With the potential exception of certain firmware files, the license terms for the components permit you to copy, modify, and redistribute the component, in both source code and binary code forms. This agreement does not limit your rights under, or grant you rights that supersede, the license terms of any particular component. openSUSE 13.1 and each of its components, including the source code, documentation, appearance, structure, and organization, are copyrighted by The openSUSE Project and others and are protected under copyright and other laws. Title to openSUSE 13.1 and any component, or to any copy, will remain with the aforementioned or its licensors, subject to the applicable license. The "openSUSE" trademark is a trademark of SUSE, LLC. in the US and other countries and is used by permission. This agreement permits you to distribute unmodified or modified copies of openSUSE 13.1 using the "openSUSE" trademark on the condition that you follow The openSUSE Project's trademark guidelines located at <http://en.opensuse.org/Legal>. You must abide by these trademark guidelines when distributing openSUSE 13.1, regardless of whether openSUSE 13.1 has been modified.

Except as specifically stated in this agreement or a license for a particular component, TO THE MAXIMUM EXTENT PERMITTED UNDER APPLICABLE LAW, OPENSUSE 13.1 AND THE COMPONENTS ARE PROVIDED AND LICENSED "AS IS" WITHOUT WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY, TITLE, NON-INFRINGEMENT, OR FITNESS FOR A PARTICULAR PURPOSE. The openSUSE Project does not warrant that the functions contained in openSUSE 13.1 will meet your requirements or that the operation of openSUSE 13.1 will be entirely error free or appear precisely as described in the accompanying documentation. USE OF OPENSUSE 13.1 IS AT YOUR OWN RISK.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE OPENSUSE PROJECT (AND ITS LICENSORS, SUBSIDIARIES, AND EMPLOYEES) WILL NOT BE LIABLE TO YOU FOR ANY DAMAGES, INCLUDING DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOST PROFITS, OR LOST SAVINGS ARISING OUT OF THE USE OR INABILITY TO USE OPENSUSE 13.1. EVEN IF THE OPENSUSE PROJECT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN A JURISDICTION THAT LIMITS THE EXCLUSION OR LIMITATION OF DAMAGES, THE OPENSUSE PROJECT'S (AND ITS LICENSORS', SUBSIDIARIES', AND EMPLOYEES') AGGREGATE LIABILITY IS LIMITED TO \$50US, OR IF SUCH A LIMITATION IS NOT ALLOWED, IS LIMITED TO THE MAXIMUM EXTENT ALLOWED.

As required by US law, you represent and warrant that you: (a) understand that openSUSE 13.1 is subject to export controls under the Export Administration Regulations ("EAR") which are implemented and enforced by the US Department of Commerce, Bureau of Industry and Security; (b) are not located in a prohibited destination country or are specifically prohibited under the EAR or US sanctions regulations; (c) will not export, re-export, or transfer openSUSE 13.1 to any prohibited destination, entity, or individual without the necessary export license(s) or authorization(s) from the US Government; (d) will not use or transfer openSUSE 13.1 for use in any sensitive nuclear, chemical, or biological weapons or missile technology end-uses unless authorized by the US Government by regulation or specific license; (e) understand that countries other than the US may restrict the import, use, or export of encryption products and that you will be solely responsible for compliance with any such import, use, or export restrictions. If any provision of this agreement is held to be unenforceable, that will not affect the enforceability of the remaining provisions. This agreement will be governed by the laws of the State of Utah and of the US, without regard to any conflict of laws provisions, except that the United Nations Convention on the International Sale of Goods will not apply. This agreement sets forth the entire understanding and agreement between you and The openSUSE Project regarding its subject matter and may be amended only in a writing signed by both parties. No waiver of any right under this agreement will be effective unless in writing, signed by a duly authorized representative of the party to be bound. No waiver of any past or present right arising from any breach or failure to perform will be deemed to be a waiver of any future right arising under this agreement. Use, duplication, or disclosure by the U.S. Government is subject to the restrictions in FAR 52.227-14 (June 1987) Alternate III (June 1987), FAR 52.227-19 (June 1987), or DFARS 252.227-7013 (b)(3) (November 1995), or applicable successor clauses.

Copyright © 2008-2013 The openSUSE Project. All rights reserved. "SUSE" and "openSUSE" are registered trademarks of SUSE LLC, or its affiliates, which founded, sponsors, and is designated by, The openSUSE Project. "Linux" is a registered trademark of Linus Torvalds. All other trademarks are the property of their respective owners.

This product includes *libpng*.

libpng versions 1.0.7, July 1, 2000, through 1.6.35, July 15, 2018 are Copyright (c) 2000-2002, 2004, 2006-2018 Glenn Randers-Pehrson, are derived from libpng-1.0.6, and are distributed according to the same disclaimer and license as libpng-1.0.6 with the following individuals added to the list of Contributing Authors:

Simon-Pierre Cadieux, Eric S. Raymond, Mans Rullgard, Cosmin Truta, Gilles Vollant, James Yu, Mandar Sahastrabudhe, Google Inc., Vadim Barkov

and with the following additions to the disclaimer:

There is no warranty against interference with your enjoyment of the library or against infringement. There is no warranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user.

Some files in the "contrib" directory and some configure-generated files that are distributed with libpng have other copyright owners, and are released under other open source licenses.

libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998-2000 Glenn Randers-Pehrson, are derived from libpng-0.96, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals added to the list of Contributing Authors:

Tom Lane, Glenn Randers-Pehrson, Willem van Schaik

libpng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996-1997 Andreas Dilger, are derived from libpng-0.88, and are distributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list of Contributing Authors:

John Bowler, Kevin Bracey, Sam Bushell, Magnus Holmgren, Greg Roelofs, Tom Tanner

Some files in the "scripts" directory have other copyright owners, but are released under this license.

libpng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995-1996 Guy Eric Schalnat, Group 42, Inc.

For the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals:

Andreas Dilger, Dave Martindale, Guy Eric Schalnat, Paul Schmidt, Tim Wegner

The PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, Inc. disclaim all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The Contributing Authors and Group 42, Inc. assume no liability for direct, indirect, incidental, special, exemplary, or consequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility of such damage.

Permission is hereby granted to use, copy, modify, and distribute this source code, or portions hereof, for any purpose, without fee, subject to the following restrictions:

1. The origin of this source code must not be misrepresented.
2. Altered versions must be plainly marked as such and must not be misrepresented as being the original source.
3. This Copyright notice may not be removed or altered from any source or altered source distribution.

The Contributing Authors and Group 42, Inc. specifically permit, without fee, and encourage the use of this source code as a component to supporting the PNG file format in commercial products. If you use this source code in a product, acknowledgment is not required but would be appreciated.

This product includes *JQuery*.

Copyright OpenJS Foundation and other contributors, <https://openjsf.org/>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *D3*.

Copyright 2010-2020 Mike Bostock All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the author nor the names of contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes *NVD3*.

Copyright (c) 2011-2014 Novus Partners, Inc. Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at <http://www.apache.org/licenses/LICENSE-2.0> Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

d3.js License Copyright (c) 2012, Michael Bostock All rights reserved. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name Michael Bostock may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL MICHAEL BOSTOCK BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes *chart*.

The MIT License (MIT) Copyright (c) 2014-2021 Chart.js Contributors Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions: The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE

AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *IonRangeSlider*.

The MIT License

Copyright © 2019 by Denis Ineshin (<http://ionden.com>)

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *Minimist*.

This software is released under the MIT license:

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *moment*.

Copyright (c) JS Foundation and other contributors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *Ssh2*.

Copyright Brian White. All rights reserved.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *ws*.

The MIT License (MIT)

Copyright (c) 2011 Einar Otto Stangvik <einaros@gmail.com>

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *Waves*.

The MIT License (MIT)

Copyright (c) 2014-2018 Alfiana E. Sibuea

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *bootstrap*.

The MIT License (MIT)

Copyright (c) 2011-2021 Twitter, Inc. Copyright (c) 2011-2021 The Bootstrap Authors

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *GIFlib*.

The GIFLIB distribution is Copyright (c) 1997 Eric S. Raymond

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

This product includes *hidapi*.

Copyright (c) 2010, Alan Ott, Signal 11 Software All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Signal 11 Software nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes *rfc6234*.

Copyright (c) 2011 IETF Trust and the persons identified as authors of the code. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Internet Society, IETF or IETF Trust, nor the names of specific contributors, may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY

AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

