

Instruction Manual

ENG

HYDROBAR SPRINT S3



LNS America
4621 East Tech Drive
Cincinnati, Ohio 45245

9.014.31.US

TABLE OF CONTENTS

| | |
|---|-----------|
| 1. SAFETY INSTRUCTIONS | 1 |
| 2. PREPARATION FOR INSTALLATION | 1 |
| 3. ASSEMBLING INSTRUCTIONS | 2 |
| 4. AIR REQUIREMENTS AND CONNECTIONS | 3 |
| 5. ALIGNMENT | 4 |
| 6. ANCHORING | 4 |
| 7. ASSEMBLING | 5 |
| 7.1. LOADER ASSEMBLING | 5 |
| 8. HYDRAULICS | 8 |
| 8.1. Hydraulic oil requirements | 8 |
| 9. DESCRIPTION OF COMPONENTS | 9 |
| 9.1. ELECTRICAL CONTROL COMPONENTS LAYOUT | 9 |
| 10. ELECTRICAL CONNECTIONS | 11 |
| 11. BAR STOCK PREPARATION | 12 |
| 12. DIAMETER CHANGEOVER | 13 |
| 12.3. ROTATING SLEEVE CHANGEOVER | 14 |
| 12.4. FLAG CHANGEOVER | 15 |
| 12.5. LOADER ADJUSTMENT | 15 |
| 12.6. GEAR RATIOS | 16 |
| 12.7. PUSHING FORCE CHART | 17 |
| 12.8. DIAMETER CHANGEOVER CHART | 18 |
| 13. SPINDLE REDUCTION TUBES CHANGEOVER | 19 |
| 14. GUIDING ELEMENTS CHANGE | 20 |
| 15. END OF BAR | 21 |
| 16. MECHANICAL STOP | 23 |
| 17. REMOTE CONTROL | 24 |
| 17.1. Display | 25 |
| 18. POWERING UP | 28 |
| 18.1. Description | 28 |

| | |
|---|-----------|
| 19. AUTOMATIC SEQUENCE | 29 |
| 19.1. Description | 29 |
| 20. SETTINGS | 30 |
| 20.1. Description | 30 |
| 20.2. Access to the functions | 31 |
| 21. AIR ADJUSTMENTS | 39 |
| 21.1. MAIN PRESSURE | 39 |
| 21.2. AIR MOTOR PRESSURE | 40 |
| 21.3. PUSHER FEED RATE ADJUSTMENTS | 41 |
| 22. MAINTENANCE | 41 |
| 23. AIR CYLINDERS, AIR VALVES | 43 |
| 24. INTERFACE ELECTRICAL DIAGRAM | 44 |
| 25. HYDRAULIC DIAGRAM | 45 |
| 26. PNEUMATIC DIAGRAM | 46 |
| 27. INPUTS AND OUTPUTS | 48 |
| 28. ELECTRICAL DIAGRAM | 49 |
| 29. FLOOR PLANS | 57 |
| 30. SPARE PARTS | 63 |



This instruction manual is written for a Sprint S3 with left/front loading system. Drawings and pusher / loading flag control will be opposite for a rear loading system

1. SAFETY INSTRUCTIONS

- Follow all operating and safety instructions of the manufacturer.
- Do not override any of the safety switches or devices either on the lathe or the bar feeder.
- Do not service, perform maintenance or handle any parts of the bar feeder during automatic cycling.
- Do not touch the bar stock while in rotation or any part in motion.
- Before operating the bar feeder and the lathe in automatic cycle, always close the main cover of the bar feeder.
- Spindle reduction tubes must be mounted when running barstock of a smaller diameter than the maximum capacity of the spindle.
- Do not wear any loose fitting clothing near any rotating parts.



Failure to follow the above safety instructions can result in serious personal injury or bar feeder damage.

2. PREPARATION FOR INSTALLATION

It is recommended the bar feeder to be installed by LNS or by one of its representatives.

The Sprint S3 will be delivered either in two separate crates or on two pallets.

To prevent serious damage to the bar feeder, thoroughly follow the hoisting instructions provided with the bar feeder. Do not lift the unit other than at the indicated hoisting points.







Prior to installation the customer must provide the following :

- Air supply and connections (see point 4)
- Anchoring bolts (see point 6)
- Hydraulic oil (see point 8.1)

3. ASSEMBLING INSTRUCTIONS

- Open the crate containing the stands and the bar loader (tall rectangular crate).
- Unbolt the loader and other components fastened to the crate for transportation purposes.
- Position the stands behind the lathe in approximate alignment with the spindle (refer to floor plan). Remove nuts (E) and upper seals (D) only.
- Place the 16 leveling pads under the stands and set the leveling screws to allow 3 mm (1/8") gap between the top of the leveling pads and the bottom of the base plate (refer to point 6). Level the stands with the leveling screws maintaining equal pressure on all leveling screws.
- Loosen the 8 set screws (A) located on the side of the 2 stands. Using the provided spanner wrench (C) raise or lower the threaded columns by rotating the lock nuts (B) evenly. Adjust so that the lower seals (lower half of D) are located at 230 mm (9") from the centerline of the spindle.
- Open the long crate by removing the top panel. Remove the pins of the hinges on the bar feeder main cover. Carefully remove the main cover of the bar feeder and take out of crate by hand.
- Remove the 4 screws holding the main body to the bottom of the crate and located inside the main body. Assemble the provided hoisting kit :
 - 1: the threaded rods (1) must be mounted in the lifting plate located in the center of the main body.
 - 2: install the rods connecting plate (2)
 - 3: lock plate with eyed lock nuts (3)
- Carefully raise the main body of the Sprint out of the crate. The lower part of the body will remain in the crate.
- Remove lower part out of the crate and carefully lower it on top of the stands verifying that all O'ring (F) remain seated in their grooves.
- Install the 4 upper seals (D) inside the lower part of the body..
- Lower the main body into the lower part of the body.
- Secure with nuts (E) using the provided hexagonal tube wrench.



4. AIR REQUIREMENTS AND CONNECTIONS

Air pressure is necessary for installation to operate the bar feeder. A minimum pressure of 5 bar (75 psi) is required. Maximum pressure : 6 bar (90 psi).

Air must be clean and dry. The Sprint is equipped with a filtering device to provide maximum air cleaning (see point 17.1).

1/2" standard air hose must be provided by the customer.

Connection :


The connection piece (C) is located at the rear of the barfeeder near the support plate for electrical connection (A) for junction box and the hydraulic pump (B).

With collar (D) secure hose (E) tightly.

The air hose must be connected and air present before final alignment of the bar feeder.

Air consumption :

- Production cycle : 9 l / min
- Loading cycle : 20 l



5. ALIGNMENT

- To obtain optimum rpm performance, position the front of the bar feeder as close as possible from the rear of the spindle.
- Align the centerline of the bar feeder with the centerline of the spindle by adjusting the height with the nuts (B, see point 3) and sideways by moving the front and rear stands.
- The alignment can be done by using either a nylon string or an optical unit.




Prior to aligning the bar feeder, the lathe must be leveled.

IMPORTANT : To obtain optimum rpm performance, the bar feeder must be accurately aligned. Should the bar feeder not be aligned properly, the bar stock guidance will be affected and vibrations will result.

6. ANCHORING

After alignment, to secure the bar feeder, it is strongly recommended to anchor the unit to the floor by using eight M10 x 120 mm (1/2" x 5") wedge type anchors.

Both front and rear stands as well as the loader must be anchored.



After the bar feeder has been lagged down, the alignment must be checked and eventually corrected. During anchoring, the stands may have moved and mis-aligned the bar feeder.

Lock the columns in position with set screws (A, see point 3).

Once the bar feeder is secured, the bar loader must be mounted (see point 7).



7. ASSEMBLING

7.1. LOADER ASSEMBLING




Care must be taken that the bar loader does not topple over.


- Remove the bar loader from the crate and position on the side of the Sprintbody.
- Install the 4 leveling pads (A) under the 4 leveling screws (B).
- With screws (B), adjust approximatively the height (1). The bar loader must be perpendicular.
- Remove the protection sheets on side of the Sprint.
- Position (2) the bar loader towards the body of the Sprint.
- Adjust height and level (N) in order to allow an easy mounting of the support arms with their respective screws (C).
- Verify the perpendicularity of the loader. Also an equal pressure of the leveling screws on their leveling pads must be present.
- Fasten the small protection sheets on the loader, then the larges.




- Adjust the chain tension (3) with screws (D)



- Loosen the clamps (H1) and (H2)
- Position the lateral supports (G) (F) and pass them through the holes (J) of the supports. Secure with the provided nuts.
- Adjust (5) both supports evenly to desired slant with screws (O).




- Adjust the level (N) on both lateral supports, secure with clamps (H1) and (H2).
- Anchor the magazine and the lateral supports to the floor, with anchor bolts through holes (E) and (L).



- If unit does not load a heavy bar, friction clutch located inside chain guard can be adjusted manually by tightening to create more friction on toothed sprocket.

Cross section of clutch is shown at right.




8. HYDRAULICS

The Sprint is equipped with a hydraulic pump to provide oil pressure to the bearing elements. This oil will allow ideal guidance and support of the bar in rotation.

A flow adjusting valve is located inside the body of the Sprint next to the hydraulic pump motor (rear of the bar feeder, see point 9).

Description of components).


- M2: Hydraulic pump and motor.
 A: Flow adjustment.
 B: Oil return hose (OUT).
 C: Pressure switch.
 D: Oil supply hose (IN).
 E: Pressure gauge
 F: Stop screw
 G: Switching point adjustment



The switching points may be set even during operation. Proceed as follows :

1. Loosen stop screw (F) with a screwdriver.
2. Adjust switching points by means of a 5 mm Hexagon spanner (G). Depending on the sense of rotation the switching point moves upwards or downwards Clockwise rotation means a higher switching value as originally set.

Counter clockwise rotation means a lower switching value as originally set.



3. Retighten stop screw.

8.1. Hydraulic oil requirements

The Sprint is delivered without oil. 80 liters (22 US gal.) of hydraulic oil must be provided by the customer. Oil must comply with ISO 100 standards.

Oil will be poured inside the lower part of the SPRINT S3.




List of suppliers and brand names :

| | | | |
|---------|----------------|--------------|------------------|
| BP | HLP 100 | MOTOREX | COREX HLP 100 |
| CASTROL | HYSPIN AWS 100 | SHELL | TELLUS 100 |
| ESSO | NUTO 100 | STANDARD OIL | HL-100 |
| EXXON | NUTO H-100 | TEXACO | RANDO OIL HD 100 |
| GULF | ARMONY AW 100 | TOTAL | AZOLLA 100 |
| MOBIL | HEAVY / DTE 27 | | |


These oils are just a few of the suppliers that could be used.

9. DESCRIPTION OF COMPONENTS

| | | |
|--------|---------|---|
| A | : 3.192 | : Air control unit |
| SQ5 | : 4.393 | : Pusher home position prox. switch |
| SQ8 | : 4.393 | : Loader down prox. switch |
| SQ9 | : 4.393 | : Loader up prox. switch |
| SQ4 | : 4.391 | : Bearing blocks closed prox. switch |
| SQ3 | : 4.391 | : Bearing blocks locked prox. switch (SQ3/1 : 4.005) |
| SQ1 | : 4.772 | : Positioner stop prox. switch |
| SQ11 | : 4.284 | : Main cover closed micro - switches (SQ11/1: 4.005) |
| SQ6 | : 4.005 | : Dropping fingers switch |
| SQ32 | : 4.005 | : Breaking chain |
| C | : - | : Connection box |
| D | : - | : Hydraulic filter |
| E | : 4.869 | : Remote control station |
| F | : - | : Control box |
| G | : - | : Loader |
| H | : - | : Loading ramp |
| I | : - | : Oil recuperator |
| M1 | : 3.160 | : Pneumatic motor |
| M2 | : 3.160 | : Hydraulic pump motor |
| M3 | : 3.160 | : Loader motor |
| YV1-21 | : 3.568 | : Air valve assembly |
| Z1-10 | : 3.003 | : Cylinders bearing blocks locking/unlocking |
| Z13/14 | : 3.143 | : Cylinder bearing blocks des opening/closing |
| Z19 | : 3.283 | : Vérin doigts dépose-matière |



9.1. ELECTRICAL CONTROL COMPONENTS LAYOUT



| Désignation | Article No | Description |
|-------------|------------|--|
| A | 4.887 | Programmable controller PCD3 (PLC) |
| B | - | Interface terminal blocks (XT3) |
| C | - | Power supply terminal block (XT1) |
| D | - | Safety terminal blocks (XT2) |
| K1 | 4.507 | Safety chain control |
| KReset | 4.606 | Kreset relay (M2 motor encoder reset) |
| KM2 | 4.606 | KM2 relay (hydraulic motor M2) |
| M3B | 4.606 | KM3B relay (bar loader is moving down) |
| M3H | 4.606 | KM3H relay (bar loader is moving up) |
| QF1 | 4.815 | Circuit breaker 2 x 2A |
| QM1 | 4.503 | Circuit breaker 2.5 to 4 A |
| QS1 | 4.380 | Main disconnect switch |
| RC1 | 4.352 | RC1 relay (filtre) |
| RC2 | 4.352 | RC2 relay (filtre) |
| R1 | 4.194 | Alarm relay |
| R2 | 4.194 | Bar feeder loading cycle relay |
| R3 | 4.194 | End of bar relay |
| R4 | 4.194 | Headstock release relay |
| R5 | 4.194 | Headstock release relay |
| T1 | 4.769 | Transformer with 24 VDC power supply |
| T2 | 4.779 | 24 VDV Power supply 150W |

10. ELECTRICAL CONNECTIONS

The necessary conduits and cable for the electrical connections to the lathe are provided.

Always refer to the interface electrical diagram located inside the electrical control box.



The factory voltage connection is indicated on the cover of the electrical control box.

Electrical income power must be checked before turning the power on.

Bar feeder arrangements may need to be changed accordingly.


Any damaged components due to mis-connections will not be covered by the factory's warranty.

Should the bar feeder electrical arrangements be changed, the following steps must be taken :

Control box

At the transformer terminal block connect the wire according to the income voltage

A : Fuse (3.15 A)



Electric motors


The hydraulic pump motor as well the bar loader motor can be arranged to receive 3x200-220V or 3x380-480V, 50/60 Hz. Refer to the electrical diagram located in the motor connection box.

Hydraulic motor :

| | |
|----------------------|--------|
| 200 - 220 V 50/60 Hz | 1,07 A |
| 380 - 480 V 50/60 Hz | 0,62 A |

Bar loader motor :

| | |
|----------------------|-------|
| 200 - 220 V 50/60 Hz | 1,4 A |
| 380 - 480 V 50/60 Hz | 0,8 A |




11. BAR STOCK PREPARATION

SOLID BARS


LNS recommends to chamfer the back end of the bar stock with a 30 degrees concentric chamfer (60 degrees included). This will provide a concentric rotation of the pusher and a safe contact bar stock/pusher cone after the bar stock leaves the bar feeder.

The front of the bar stock must be free of burrs to feed smoothly through the clamping system and the spindle of the lathe.



TUBING


To prevent any mixing between the hydraulic oil and the coolant of the lathe, a sealed plug must be mounted at the rear of the tubing.



HEXAGONAL- SQUARE BAR STOCK

To allow the feeding of the material through the profile of the collet, an adapter bushing will be mounted in the collet of the lathe. The inside hole of the adapter must be identical to the profile of the bar stock + 0.2 mm (+ .0078").

When loading a new bar stock, the spindle of the lathe must rotate at low rpm (30 rpm). Spindle inching or orientation will also allow a correct functioning.



IMPORTANT: To improve RPM performance when running profiled bar stock (hex., square), a rotating element (with I.D. = barstock dia. across the corners+0,2mm/+ .0078") can be installed in the front outboard support, as well as elongated bearing elements must be mounted. Refer to point 12.2 for installation.

Please contact LNS or one of its representatives for further information.

11.1. BAR STOCK REQUIREMENTS

For optimum results, the bar stock must be straight.

Should the bar stock exceed 0.5 mm/m (.020" / 3Ft) straightness, RPM performance may decrease depending on the material type, length, etc...

Bar stock must be preferably clean to minimize maintenance and free of burrs.

12. DIAMETER CHANGEOVER

For optimum performance, it is recommended to equip the Sprint with the corresponding accessories to each bar stock diameter. These elements are also designed to operate in a certain diameter range. To obtain optimal rpm performance, it is recommended not to exceed 6 mm (.23") gap between the O.D. of the bar stock and the I.D. of the bearing elements. 1 mm (.04") provides ideal guidance.

To order supplies, please use the following ordering numbers.

| Ref.(*) | Element | Diameter | Ordering Nr | | |
|---------|------------------|----------|----------------------------|----------------------------|----------------------------|
| | | | 3m | 12' | 4m |
| I | Bearing elements | 14 - 81 | 014.011.253/ + Diameter | 014.011.263/ + Diameter | 014.011.273/ + Diameter |
| II | Pusher | 13 - 80 | 014.011.223 / + Diameter | | |
| III | Rotating sleeve | 13 | 014.011.103 | | |
| III | Rotating sleeve | 18 | 014.011.113 | | |
| III | Rotating sleeve | 25 | 014.011.243 | | |
| III | Rotating sleeve | 36 | 014.011.133 | | |
| III | Rotating sleeve | 50 | 014.011.143 | | |
| IV | Flag | 13 | GAV - 014.011.513 | GAR - 014.011.543 | |
| IV | Flag | 18 | GAV - 014.011.523 | GAR - 014.011.553 | |
| IV | Flag | 36 | GAV - 014.011.533 | GAR - 014.011.563 | |

(*) Please refer to the chart (point 12.8) to ensure correct part selection.

In addition, a spindle reduction tube (spindle liner) must be mounted in the spindle of the lathe. Its I.D. must be identical to the I.D. of the bearing elements. The bar loader must be adjusted for different bar stock diameters to select one bar stock at a time (see point 12.5).

12.1 PUSHER CHANGEOVER

The pusher will always match the I.D. of the bearing elements - 1 mm (.040").

Procedure:

Refer to point 15.2/7, DIAMETER CHANGEOVER

- Manually open the main cover.
 - Remove the pusher.
 - Change the bearing elements (point 12.2)
 - If required, change the rotating sleeve (point 12.3)
 - If required, change the flag (point 12.4)
 - Install new pusher (verify correct overall length which must correspond to all other pushers).
- Close the main cover.


Refer to point 12. DIAMETER CHANGEOVER

12.1 BEARING ELEMENTS CHANGEOVER

Procedure (Open the bearing blocks, remove the pusher. Refer to point 12.1)

1: Upper half bearing element

The upper elements (1) are secured in the upper half of the bearing blocks by a quick disconnect system (A). To remove them, push down the bearing elements. Install new elements. When installing elongated bearing blocks to run profiled material (hex., square, etc...), a special care must be taken due to the dissimilarity of the bearing elements. Please refer to the indication on each element (note : block #1 is located at the rear of the Sprint S2) (The upper elongated elements are secured with a screw).




2: Lower half bearing element

Using a standard screw driver, pop-out the lower bearing element (2) to extract them from their location. A locating pin will seat the new bearing element into the correct position.

3: Outboard support bearing element

Loosen set screw (C), remove bearing element (D), place new element into the front extended guiding support and secure with set screw (C).



4: Pusher supports bearing element

Identical to 3.



12.3. ROTATING SLEEVE CHANGEOVER

Each rotating sleeve covers a pusher diameter range (refer to chart point 12.8).

Sleeves for dia. 13mm (1/2") to 35 mm (1-3/8")

1. Remove lock pin
2. Remove pusher



3. Install new pusher
4. Secure with lock pin



Sleeves for dia. 36mm (1-3/8") to 80 mm (3-1/8")

1. Remove set screws (A)
2. Remove pusher

3. Install new pusher
4. Secure with set screws




12.4. FLAG CHANGEOVER

Each flag covers a range and can be used for different size of rotating sleeves. The range is indicated on each flag.

Before replacing the flag, remove the pusher and the rotating sleeve.

Unscrew lock screws (A) and remove flag. Select appropriate flag (B) and install on chain. Secure with lock screws (A).



C : Chain guiding rail.

12.5. LOADER ADJUSTMENT


Place three to six bars (same diameter) on the magazine ramp (2).

Adjust slant of the ramp (1) with adjusting screws (refer to point 7.1) so that the bars roll down (2) towards the elevator.

Excessive slant will cause loading problems.

Loosen lock nuts (B) and adjust (3) bar stoppers (D) with knob (C) so that only one bar stock (A) is being selected by the lifting fingers (E).

Secure with lock nuts (B)



12.6. GEAR RATIOS

The pushing force of the pusher must be adjusted according to the bar stock diameter. The pushing force can be adjusted with the air adjusting valve (refer to 17.2, Pushing force).


For more flexibility and for wider adjusting range, the motor gear ratio can be changed. The gear ratio 1/6 is recommended for bar stock over 58mm (2") diameter.

To prevent small diameter bar stock to bent due to an excessive pushing force, the gear ratio 1/4 (standard ratio) is recommended.

An excessive pushing force could also cause bearing failures (refer to point 12.7).


| RATIO | PUSHING FORCE in Newton | | | | | | PUSHING FORCE in LBS (US) | | | | | |
|-----------------------|-------------------------|-------|-----|------|-----|-------|---------------------------|--------|-------|--------|--------|--------|
| | 2,5 | 3 BAR | 3,5 | 4BAR | 3,5 | 5 BAR | 31.5 | 45 PSI | 52.5 | 60 PSI | 67.5 | 75 PSI |
| 1 : 4 (014.08.244) | 150 | 220 | 280 | 350 | 420 | 480 | 31.20 | 45.76 | 58.24 | 72.80 | 87.36 | 99.84 |
| 1 : 6 (014.08.164) | 260 | 360 | 460 | 560 | 660 | 760 | 54.08 | 74.88 | 95.68 | 116.48 | 137.28 | 158.08 |

The air motor is located at the rear of the SPRINT S3.




Changing the gear ratios :

- 1: Loosen the bolt (A).
- 2: Swing up the motor mounting plate to free the ratio gear (B).
- 3: Lock in position with bolt (A).
Loosen the gear set screw (C).
 - Remove gear and install new gear.
 - Align (by sight) the new ratio gear with motor gear.
 - Secure with set screw (C).
 - Loosen the bolt (A) and swing the motor mounting plate down into position. Secure with bolt (A). To prevent gear binding, Position the mounting plate to allow a small play between the gears.



12.7. PUSHING FORCE CHART






13. SPINDLE REDUCTION TUBES CHANGEOVER

To allow proper feeding of the bar stock through the clamping cylinder and the headstock, it is recommended to mount spindle reduction tubes (spindle liners). Ideally, the I.D. of the spindle liner must correspond to the I.D. of the bearing elements.

To remove or to install the spindle liner, the bearing element of the front extended support and the air blast (unscrew screws (D)) must be removed.



14. GUIDING ELEMENTS CHANGE

Conditions :

- No bar stock in the magazine
- Pusher in home position
- Barfeed in STOP mode

1. Enter the manual mode by pushing F1

2. Manual mode:

Select the pusher changeover procedure by pushing F4 [SET].

The text " READY TO START PUSHER CHANGEOVER FUNCTION " is displayed on the screen.

Start the function by pushing F1 [START].

The pusher goes to its changeover position. Follow the instructions on the remote control.

3. Open the protection grid and the main cover of the bar feeder.

Remove the pusher.

Upper half bearing elements:

- a. To extract the upper half bearing elements, press on the lever of the Quick Change system and pull down the element.
- b. Install the new elements by pushing the elements inside the supports. A click confirms that the element is secured.

Lower half bearing elements:

- a. Extract the lower half elements (2) by pulling them out of the bearing supports
- b. Adjust the new elements on the shaft, and push down the elements inside the support.

Outboard support bearing element:

- a. Loosen the lock screw (A)
- b. Remove the guiding element (B).
- c. Install the new guiding element. Take care of the side nuthole
- d. Place back the holding plate

Pusher support bearing elements:

- a. Remove the holding plate.
- b. Remove the guiding element
- c. Install the new guiding element, slit towards the back.
- d. Place back the holding plate.

Install the new pusher

4. Close the main cover and the protection grid of the bar feeder.

5. Press 2x the button F1 [START] on the remote control.

The pusher is engaged in its home position.

Once the bar feeder has completed the pusher changeover cycle, the bar feeder is ready to work.

At this point, it is necessary to check the parameters like bar stock diameter, guiding elements diameter, feeding length, etc. See point 3.1 of this manual for further information.

15. END OF BAR

Principle:

In automatic cycle, when the pusher reaches the end of bar position, the remaining material is too short to machine another part and the lathe will hold its production cycle and a new bar is loaded. The production cycle (program) will resume once the new bar has reached the top-cut position.

The end of bar position must be adjusted to obtain minimum bar stock remnant. The front of the pusher will be located 12 mm (1/2") behind the collet pads or the chuck jaws of the lathe.

To minimize the loading cycle time, it is possible to load a new bar while machining the last part. The end of bar position must be adjusted 12 mm (1/2") + one part length behind the collet pads or the chuck jaws

End of bar adjustment

- Conditions :*
- *Main cover closed.*
 - *Bearing blocks closed.*
 - *No bar stock in the bearing blocks.*
 - *The position of the pusher does not matter.*

Procedure :

1. Press the key [STOP].
2. Enter the main menu by pushing F4.
3. Enter the menu "positions / torques".by pushing F3 [ENTER].
4. Screen "End of bar position":
Press the key corresponding to the icon [SET] (F3).
Depending on which sequence the bar feed is in when the parameter is selected, the available functions and icons can change
5. [+/-] By offset correction:
 - Presser la touche correspondant à l'icône [+/-].
 - La position de tronçonnage (Z) actuelle est affichée.
 - Introduire à l'aide des touches numériques la correction à apporter, puis presser la touche correspondant à l'icône [+] si vous souhaitez ajouter la correction, ou la touche correspondant à l'icône [-] si vous souhaitez la soustraire. La nouvelle valeur est mémorisée et affichée à l'écran.
 - Pour quitter ce mode de réglage, presser la touche correspondant à l'icône [ESC].

6. [TEACH IN] Apprentissage:

- Presser la touche correspondant à l'icône [TEACH IN]. La position de fin de barre actuelle est affichée.
- Presser la touche [FWD] et amener le poussoir à la position de fin de barre souhaitée (voir page précédente).
- Pour mémoriser la valeur, maintenir la touche correspondant à l'icône [ENTER] pressée jusqu'à ce que l'icône disparaisse.


7. To exit the set mode, press the keys [ESC] or [STOP].

16. MECHANICAL STOP

To prevent damage to the pusher and to the tools of the lathe, a mechanical stop is mounted in front of the bar feeder.

This stop must be adjusted during initial installation. It must be positioned so that the front of the pusher (A) cannot reach the inside of the collet of the lathe (B).

During end of bar (1), the pusher (A) will stop before touching (2) the collet of the lathe (B). The stopper (C) will stop (2) the flag (D).




17. REMOTE CONTROL

The ergonomic and user-friendly remote control with a clear built-in display facilitates the handling of the bar feed system. Depending on the sequence under way, the bar feed system gives access only to those functions which are available, thus avoiding any incorrect handling, and reducing the access time to the necessary functions.

The display reads, continuously and clearly, the status of the bar feed system and the production, allowing one to verify at all times the functions, diagnostics, error signals, or their analysis. The most recent error signals are saved in a register and can be recalled to establish the diagnostics.

The remote control has five distinct segments, namely: display (A), function keys (B), left / right / up / down keys (C), STOP key (D) and the emergency button (E).


























17.1. Display

The liquid crystal display provides the operator with all the necessary data, both for handling the bar feed system and for maintenance.

- The upper portion of the display has eleven lines and is reserved for the reading of text.
- Error messages are usually displayed with their diagnostics.
- The lower portion of the display is reserved for the display of icons. The icons indicate to the operator which functions are attributed to keys F1 through F4

The icons available are the following:

| Icon | Signification |
|---|---|
|  | Referencing position |
|  | Switch to automatic mode |
|  | Stop after machining one bar stock |
|  | Switch to manual mode |
|  | Pusher forward (picture may be reversed) |
|  | Pusher reverse (picture may be reversed) |
|  | Automatic Top-Cut positioning in manual mode |
|  | Extract the bar out of the clamping device of the lathe (picture may be reversed) |
|  | Setup menu |

| Icône | Signification |
|---|--|
|  | Confirm |
|  | Start sequence |
|  | Set up |
|  | Escape |
|  | Return to previous menu |
|  | Jump to next menu |
|  | Load a bar stock in the guiding elements |
|  | Confirm the unloading of a bar stock out of the guiding elements |
|  | Validate |
|  | Cancel |
|  | Teach data |
|  | Offset correction |
|  | Increment data in offset correction mode |
|  | Decrement data in offset correction mode |

17.2. Function keys F1 - F4

These keys are located right below the display. The functions attributed to them are indicated on the display by icons.

As the operator advances in the handling, the functions of the keys are automatically reattributed to correspond to the circumstance and availability of the bar feed system.

17.3. Left / right / up / down keys

These keys allow entering values (bar stock diameter, part length, etc.) or parameters.

17.4. Emergency stop button

When a dangerous situation arises, pressing the emergency stop switch interrupts immediately all bar feed system and lathe functions (if interface is wired accordingly).

To cancel the alarm, release the switch by rotating its red knob counter-clockwise, then press [STOP].

17.5. STOP key

The STOP key allows interrupting the sequence under way.

Important: the automatic cycle of the lathe must first be interrupted.

By pressing the STOP key, allows to exit the setting mode, regardless of the level reached, and to return to the work screen.

18. POWERING UP



Please read the safety instructions described at the start of this manual before handling the equipment.

18.1. Description

The motor of the Hydrobar Sprint S3 bar feed system is equipped with a built-in absolute encoder that continually controls the position of the carrier.

When the bar feed system is powered down or there is a power failure, this position is kept in the memory by the PLC.

When powering up, the value saved is immediately taken into account, thus avoiding any input from the beginning. The status saved in the PLC prior to powering are then checked by the PLC which analyses them. The latter then gives the operator access only to those handling operations, which should be undertaken.

This chapter shows the various functions of the bar feed system and indicates how to access them.

The conditions to be fulfilled to proceed with the handling are systematically displayed on the screen, and, therefore, are not reproduced in this manual.

Given that the handling may vary depending on the status and configuration of the bar feed system, a standard procedure cannot always be described.

19. AUTOMATIC SEQUENCE



Please read the safety instructions described at the start of this manual before handling the equipment.

19.1. Description

The autonomy of the bar feed system is directly connected to the frequency at which the operator feeds the magazine.

Each time the automatic sequence of the bar feed system needs to be started up, it is advisable to check the following elements:

- In the storage unit, the end of the bars must be resting against the rear limiter.
- The guiding elements must be adapted to the diameter of the bar.
- The front rest guiding elements must be adapted to the profile of the material.
- The installed pusher must be adapted to the diameter of the guiding elements and to the inside diameter of the spindle.
- The collet of the bar feed system must correspond to the diameter of the bar.
- The pushing torque must correspond to the material to be loaded.
- On the lathe, the clamping device must correspond to the material to be loaded.

20. SETTINGS



Please read the safety instructions described at the start of this manual before handling the equipment.

20.1. Description

The Sprint S3 bar feed system has different parameters and functions allowing the operator to configure it in the manner best adapted to the lathe on which it is installed, and to the mode of production in progress.

These parameters permit the positioning of the material in the clamping system of the lathe during the feeding process. Then, during the production cycle, the material is advanced with precision at every opening of the clamping system.

The position of the flag, or the quantity of material remaining to be machined, may be known at any time by simply consulting the remote control.

The pushing torque of the motor is adjusted automatically in relation to the material to be loaded

20.2. Access to the functions

The functions are structured as follows :

By pressing the MENU key it is possible to visualize the values of the settings, regardless of the position of the bar feed system (automatic sequence, manual sequence, etc.).

| | | |
|---|----------|--|
| Note : <i>To change or modify any parameter, the bar feeder must be in STOP mode.</i> | 1 | Part setup |
| | 1.1 | Total part feed out length |
| | 1.2 | Number of clamping device openings for overall part length |
| | 1.3 | <i>Top Cut Position</i> |
| | 1.4 | <i>Auxiliary end of bar position</i> |
| | 2 | Position |
| | 2.1 | End of bar position |
| | 2.2 | Top Cut position |
| | 2.3 | Top Cut brake position |
| | 2.4 | <i>Auxiliary end of bar position</i> |
| Note : <i>The parameters in italic are optional.</i> | 3 | Misc. functions |
| | 3.1 | Language |
| | 3.2 | Unit of measure |
| | 3.3 | Request for reference point |
| | 3.4 | <i>Clamping mode reversed</i> |
| | 3.5 | <i>Time for clamping device to close</i> |
| | 3.6 | <i>Time for clamping device to open</i> |
| | 4 | Service |
| | 4.1 | Bar feeder setup |
| | 4.2 | Interface |
| | 4.3 | Special functions |
| | 4.4 | Parameter masking |

Depending on the sequence at which the bar feed system is positioned, certain functions may not be accessible, and therefore, not displayed.

To exit the setting functions and return to the work display, press MENU or STOP key.

For data collection values as well as to navigate in the various menus, please see point 1.1, Display (meaning of the icons).

20.2.1. Part setup

Note :

To validate a new parameter or a new value, keep the [ENTER] key pressed until its icon disappears

The manipulations, adaptations, and settings, specific to the machining of a part, and which must be made to the bar feed system are part of the start-up. The mechanical settings which must be performed on the bar feed system are presented in the Start Up manual. This point presents the most common parameter settings.


IMPORTANT: Prior to changing the bar feed parameters, please make sure that the guiding channel is open. Parameters will not be accepted with the channel closed.

1.1. Total part feed out length

Used to check that the turret movement is according to the needed feeding value.

The feed-out length (L_t) includes the part length (L_p), the cut-off tool width (C) and the face-off length.

To validate the new value, press the [ENTER] key twice.




1.2. Number of clamping device openings for overall part length

When the machining of a part requires several openings of the clamping device (for ex.: a long part, or transfer of the part to the sub-spindle), some interface conflicts may occur during the feeding process.

It is important for the bar feed system to be "informed" of the number of times the clamping device must open for the machining of a part.

NB : The bar feed system only carries out the first positioning for a single part. The following positioning (if any) must be done by the turret.



1.3. Top Cut position


During the loading cycle, the bar is automatically loaded and positioned into the spindle, outside the clamping device of the lathe (chuck or actuator).

This positioning corresponds to a value (Z) programmed by the operator, which is equal to the distance between the measuring cell and the position of the material in the lathe clamping device.

With this system, the setting is the same for any bar length.

The setting for the Top-cut position may be adjusted at any time, in one of two ways :







- By correcting the setting itself
- By teach-in



Top cut position setting



Before handling the bar feeder, stop the lathe at the end of part cycle

| | | |
|---|--|---------------------------------------|
| 1 |  [STOP] | Press the key [STOP]. |
| 2 |  | Enter the main menu. |
| 3 |    [ENTER] | Enter the menu "positions / torques". |
| 4 |  [PG DOWN] | Go to the screen "top cut position". |









| | | |
|---|--|---|
| 6 |  [SET] | <p>Screen "Top cut position":</p> <p>Press the key corresponding to the icon [SET].</p> <p>Depending on which sequence the bar feed is in when the parameter is selected, the available functions and icons can change :</p> <p>Table setting: see next page</p> <p>By offset correction: jump to point 6 By teach in: jump to point 7</p> |
| 6 |  [+/-] | <p>[+/-] By offset correction:</p> <ul style="list-style-type: none"> • Press the key attributed to the icon [+/-]. • The current top-cut position (Z) is displayed. • Enter with the direction keys the correction to insert, and press the [+] icon to add the value, or the icon [-] to subtract it. The new value is stored. • To exit the top-cut position set mode, press the key attributed to the icon [ESC]. <p>Jump to point 8.</p> |
| 7 |  [TEACH IN]  [START]  [FWD]  [ENTER] | <p>[TEACH IN] By teaching:</p> <ul style="list-style-type: none"> • Press the key attributed to the icon [TEACH IN]. • Press the key attributed to the icon [START]. • A bar is loaded and the guiding channel is closed. The feeding pusher inserts the bar into the lathe spindle. The feeding pusher is now facing the spindle. • Press the key [FWD] and advance the bar stock to the desired position (see previous page). • To validate the new top cut position, keep [ENTER] pressed until the icon disappears. |
| 8 |  [TEACH IN]  [STOP] | <p>To exit the set mode, press the keys [ESC] or [STOP].</p> |

Table setting:

| Conditions | Available functions | |
|--|----------------------|------------------------|
| | By offset correction | Teach in |
| <ul style="list-style-type: none"> Guiding channel open Bar stock in the loading rack Pusher in home position | Icon [+/-] | Icon [TEACH IN] |
| <ul style="list-style-type: none"> All other cases | Icon [+/-] | --- |

20.2.2. Positions**2.1. End of bar**

The end of bar position determines the moment when the bar feed enters the loading cycle.

Usually, the end of bar position is adjusted as closely as possible behind the clamping system of the lathe (approximately 5 mm or a 1/4" behind the chuck jaws or collet pads).

This will provide minimum bar stock remnant.


Regardless of the length of the bars, or parts, the end of bar position is always the same.

In very special cases, a different end of bar setting needs to be selected.

The length of the remnant may vary :

- The minimum remnant length (Min) is obtained when the feeding pusher is just behind the clamping device while the last part is being machined
- La chute maximale (Max), est obtenue lorsque la matière est légèrement insuffisante pour l'usinage d'une pièce supplémentaire ($L_p - 1\text{mm}$).
- The maximum remnant length (Max) is obtained when there is not enough material for machining an additional part ($L_p - 1\text{mm}$)

Maximum remnant length = $L_p - 1\text{mm} + \text{Min}$



2.2. Top Cut brake position

In order to save time, the bar is first moved in high speed; then the pusher switches to low speed when approaching the optical cell or Top Cut position.

This switching point is defined by this parameter

2.3. Auxiliary end of bar position

Depending on the lathe and its options, the auxiliary end of bar may be used in several ways, for example for the opening of an external rest.

The procedure is the same as this for the end of bar setting.

20.2.3. Misc. functions

Note :

To validate a new parameter or a new value, keep the [ENTER] key pressed until its icon disappears.

3.1. Language

This parameter allows to adapt the language in which the messages will appear, depending on the country of destination of the bar feed system (*for practical reason, it is not necessary to stop the bar feeder to select a language*).

3.2. Unit of measure (millimetres / inches)

This parameter defines whether the measures will be indicated in millimetres or in inches..

3.3. Request for reference point

This operation allows the bar feed system to find the original position of the absolute converter and the parameters when and if these have been lost.

3.4. Clamping mode reversed

The interface signal is reversed depending on whether the clamping device functions by pushing or by pulling. It is therefore essential to know the operation of the clamping device, without this, the feeding process cannot be done correctly.

3.5. Time for clamping device to close

This is the time it takes for the clamping device to be physically closed. The majority of CNC lathes are equipped with confirmation switches to provide this signal. The time is set at a default value of zero seconds.

3.6. Time for clamping device to open

In the case of a clamping device with jaws, some time may be provided to prevent any movement before the clamping device is completely open.

20.2.4. Service

- 4.1 Bar feeder setup
- 4.2 Interface
- 4.3 Special functions
- 4.4 Parameter masking

ATTENTION! Password will be required!

The service parameters allow to configure the bar feed system in its environment and to adapt the interface connected to the lathe.

These parameters are protected with a password, because only LNS (or certified) technician is authorized to modify them.

21. AIR ADJUSTMENTS


21.1. MAIN PRESSURE

For trouble free operation of the Sprint, a minimum of 5 bar (75 PSI) is required but should not exceed 6 bar (90 PSI).

Procedure :

Should an adjustment be necessary :
Pull up the knob (1) and turn clockwise to increase the pressure.
Turn counter-clockwise to decrease the pressure. After adjustment, push down the knob back into normal position.

- 1: Main pressure adjusting valve
- 2: Main pressure gauge
- 3: Decanter/Filter
- 4: Drain
- 5: 1/2" dia. connection (air inlet)
- 6: Air outlet



| Designation | Article No. | Description |
|-------------|-----------------------------------|------------------------------|
| YV1 - YV10 | 3M 3.568 12' 3.569 4M 3.570 | Bearing blocks locking |
| YV13 | | Bearing blocks open |
| YV14 | | Bearing blocks close |
| YV19 | | Coupling for dopping fingers |
| YV21 | | Air blow |


21.2. AIR MOTOR PRESSURE

The pushing force (torque) can be adjusted with knob (7). Maximum pressure allowed, 5 bar (75 PSI). To secure the connection between the bar stock and the pusher and to increase the life time of the rotating sleeves of the pusher as well as to prevent small diameter bar stock to bent, the pushing force must be adjusted accordingly.

- 7: Air motor pressure adjusting valve
- 8: Air motor pressure gauge
- 9: Air pressure switch
- 10: Air inlet
- 11: Air outlet to the motor (adjustable pressure)
- 12: Air outlet to the motor (direct)
- 13: Air outlet to air valves

Procedure :

Pull up the knob (7) and turn clockwise to increase the pressure. Turning counterclockwise will decrease the pressure. After adjustment, push down the knob back into normal position.



21.3. PUSHER FEED RATE ADJUSTMENTS

The feed rate can be adjusted with adjusting valves 6 and 7.

An average feed rate is factory adjusted.

Should an adjustment be necessary :

Pusher fast forward

- To increase the feed rate turn adjusting valve 6 counterclockwise.
- To decrease the feed rate turn adjusting valve 6 clockwise..

Pusher slow forward (forward deceleration)



- To increase the feed rate turn adjusting valve 7 counterclockwise.
- To decrease the feed rate turn adjusting valve 7 clockwise.

Pusher slow reverse (reverse deceleration)

- To increase the feed rate turn adjusting valve 8 counterclockwise.
- To decrease the feed rate turn adjusting valve 8 clockwise.

Note : The fast reverse speed is factory set at its maximum feed rate and cannot be adjusted.

- 1: Air inlet (adjustable flow)
- 2: Air inlet (neutral)
- 3: V18 Fast/slow selection electro-valve
- 4: V16 Pusher forward electro-valve
- 5: V17 Pusher reverse electro-valve
- 6: Pusher fast forward adjusting valve
- 7: Pusher slow forward adjusting valve
- 8: Pusher slow reverse adjusting valve
- 9: Outlet air motor forward
- 10: Outlet air motor reverse
- 11: Pusher fast reverse adjusting valve



22. MAINTENANCE

The bar feeder requires minimum maintenance. However, the following needs to be regularly checked :


Hydraulic filter/hydraulic oil

The oil filter must be maintained clean and requires cleaning once a month.

The hydraulic oil may need to be replaced once a year depending on the cleanness of the bar stock.

Procedure :

1. Install plug (1) in bottom of the reservoir.
2. Place a container (min 5l) under the drain plug.U
3. Unscrew drain plug (2) located outside the oil filter and drain oil catcher (3).
4. Remove oil catcher cover (4) and clean filter cartridge.
5. Put back in place.
6. Remove plug inside the reservoir.



Air filtration unit


The air decanter must be checked weekly and must be free of dirt and water. Eventually drain water out of the decanter.

Note :


Used batterie must be disposed of in an ecologically safe manner.

Replacing the programmable logic controller battery:

1. Open the blue cover.
2. Remove the card with LED's
3. Remove the battery. Insert the new one.
4. Insert back the card and close the cover.




23. AIR CYLINDERS, AIR VALVES



An air cylinder can be manually activated by rotating the screw "A" located on its corresponding air valve




The screw "A" must be returned to its original position (B) to prevent any malfunction of the electro-valve and the Sprint.




The feed rate of the piston can also be adjusted by turning the air regulators (1) and (2).

These air regulators are factory adjusted and should normally not be re-adjusted.


- 1 : Air regulator forward
- 2 : Air regulator reverse
- 3 : Forward limit damper
- 4 : Reverse limit damper




Always refer to the electrical diagram sent with the bar feeder and located in the electrical control box.



25. HYDRAULIC DIAGRAM




| | | | |
|----------|-------------------------|----------|--|
| A | M1 / Motor 0,18 kw | E | B 34 / Pressure switch 0,5 Bar (12PSI) |
| B | Pump 15 l/min 4 Gal/min | F | Oil supply to bearing blocks |
| C | Flow adjustment | G | Oil filter |
| D | Pressure gauge | | |





27. INPUTS AND OUTPUTS


| Inputs | | | | Outputs | |
|--------|--|--|--|---------|---|
| I16 | Safety line relay (K1) | | | O48 | Guiding element 1 (YV1) |
| I17 | Main access cover safety (SQ11) | | | O49 | Guiding element 2 (YV2) |
| I18 | Measuring cell (SQ1) | | | O50 | Guiding element 3 (YV3) |
| I19 | Guiding bearings locked (SQ3) | | | O51 | Guiding element 4 (YV4) |
| I20 | Guiding bearings closed (SQ4) | | | O52 | Guiding element 5 (YV5) |
| I21 | Pusher in referencing position (SQ5) | | | O53 | Guiding element 6 (YV6) |
| I22 | Dropping fingers coupling (SQ6) | | | O54 | Guiding element 7 (YV7) |
| I24 | Air pressure switch (SP1) | | | O55 | Guiding element 8 (YV8) |
| I25 | Oil pressure switch (SP2) | | | O56 | Guiding element 9 (YV9) |
| I26 | Bar loader in lower position / Bar loader indexing (SQ8) | | | O57 | Guiding element 10 (YV10) |
| I27 | Bar loader in upper position / Bar presence on (SQ9) | | | O58 | Guiding bearings opening (YV13) |
| I40 | Clamping device signal A1 | | | O59 | Guiding bearings closing (YV14) |
| I41 | Lathe in auto cycle A2 | | | O60 | Pusher in forward position (YV16) |
| I42 | Feed order A3 | | | O61 | Pusher in backward position (YV17) |
| I43 | Push order A4 | | | O62 | Low speed (YV18) |
| I44 | Programmable interface input (option) | | | O63 | Déposes matière (YV19) |
| I45 | Programmable interface input (option) | | | O64 | Air blast (YV21) |
| I46 | Programmable interface input (option) | | | O66 | Hydraulic motor (KM2) |
| I47 | Programmable interface input (option) | | | O67 | Bar loader motor for upper position / Bar loader (KM3A) |
| | | | | O68 | Moteur gerbeur descend (KM3B) |
| | | | | O72 | Relais d'alarme (R1) |
| | | | | O73 | Ravitailleur en chargement (R2) |
| | | | | O74 | Relais de fin de barre (R3) |
| | | | | O75 | Relais de libération de poupée (R4) |
| | | | | O76 | Sortie interface paramétrable |
| | | | | O77 | Sortie interface paramétrable |
| | | | | O78 | Sortie interface paramétrable |
| | | | | O79 | Sortie interface paramétrable |



28. ELECTRICAL DIAGRAM







| | | | | | |
|------|--|-------------------------------|--|------------|--|
| Rev. | | Description | | DE | |
| 1 | | Added SQ11/1 NC on the page 4 | | 10.03.2008 | |
| 2 | | | | To | |
| 3 | | | | | |
| 4 | | | | | |
| 5 | | | | | |
| 6 | | | | | |
| 7 | | | | | |
| 8 | | | | | |
| 9 | | | | | |
| 10 | | | | | |
| 11 | | | | | |
| 12 | | | | | |
| 13 | | | | | |
| 14 | | | | | |
| 15 | | | | | |
| 16 | | | | | |
| 17 | | | | | |
| 18 | | | | | |
| 19 | | | | | |
| 20 | | | | | |
| 21 | | | | | |
| 22 | | | | | |
| 23 | | | | | |
| 24 | | | | | |
| 25 | | | | | |
| 26 | | | | | |
| 27 | | | | | |
| 28 | | | | | |
| 29 | | | | | |
| 30 | | | | | |
| 31 | | | | | |
| 32 | | | | | |
| 33 | | | | | |
| 34 | | | | | |
| 35 | | | | | |
| 36 | | | | | |
| 37 | | | | | |
| 38 | | | | | |
| 39 | | | | | |
| 40 | | | | | |
| 41 | | | | | |
| 42 | | | | | |
| 43 | | | | | |
| 44 | | | | | |
| 45 | | | | | |
| 46 | | | | | |
| 47 | | | | | |
| 48 | | | | | |
| 49 | | | | | |
| 50 | | | | | |
| 51 | | | | | |
| 52 | | | | | |
| 53 | | | | | |
| 54 | | | | | |
| 55 | | | | | |
| 56 | | | | | |
| 57 | | | | | |
| 58 | | | | | |
| 59 | | | | | |
| 60 | | | | | |

Standard

014-40-600

Page 3 / 9

Index

SPRINT S3

ELECTRICAL DIAGRAMS

FABRIQUE DE MACHINES
Suisse - 2534 Orvin


DE


To

Date


29.09.2008


014406001 VSD






| | | | |
|--|-------------------|------------|--|
| Rev. 10.03.2008 DE | | 014-40-600 | |
| Description | | Standard | |
| Contrôle : ** | Date : ** 2008 | Page 5 / 9 | |
| Auteur : HC | Date : 29.09.2008 | Index | |
| G:\DOCUMENTATION\DOCUMENTATION PRODUIT\LNS\1 | | I | |
| Dessin : SPRINTS3DOC TECHNIQUE\SCHEMAS\ | | | |
| 014406001_VSD | | | |





| | | | | | | | | | | | |
|---|--|--|--|-------------------------------|--|--|--|------------|--|--|--|
|  | | | | | | | | | | | |
| Rev. | | | | Description | | | | DE | | | |
| 1 | | | | Added SQ11/1 NC on the page 4 | | | | 10.03.2008 | | | |
| 2 | | | | Date | | | | To | | | |
| 3 | | | | Date | | | | To | | | |
| 4 | | | | Date | | | | To | | | |
| 5 | | | | Date | | | | To | | | |
| 6 | | | | Date | | | | To | | | |
| 7 | | | | Date | | | | To | | | |
| 8 | | | | Date | | | | To | | | |
| 9 | | | | Date | | | | To | | | |
| 10 | | | | Date | | | | To | | | |
| 11 | | | | Date | | | | To | | | |
| 12 | | | | Date | | | | To | | | |
| 13 | | | | Date | | | | To | | | |
| 14 | | | | Date | | | | To | | | |
| 15 | | | | Date | | | | To | | | |
| 16 | | | | Date | | | | To | | | |
| 17 | | | | Date | | | | To | | | |
| 18 | | | | Date | | | | To | | | |
| 19 | | | | Date | | | | To | | | |
| 20 | | | | Date | | | | To | | | |
| 21 | | | | Date | | | | To | | | |
| 22 | | | | Date | | | | To | | | |
| 23 | | | | Date | | | | To | | | |
| 24 | | | | Date | | | | To | | | |
| 25 | | | | Date | | | | To | | | |
| 26 | | | | Date | | | | To | | | |
| 27 | | | | Date | | | | To | | | |
| 28 | | | | Date | | | | To | | | |
| 29 | | | | Date | | | | To | | | |
| 30 | | | | Date | | | | To | | | |
| 31 | | | | Date | | | | To | | | |
| 32 | | | | Date | | | | To | | | |
| 33 | | | | Date | | | | To | | | |
| 34 | | | | Date | | | | To | | | |
| 35 | | | | Date | | | | To | | | |
| 36 | | | | Date | | | | To | | | |
| 37 | | | | Date | | | | To | | | |
| 38 | | | | Date | | | | To | | | |
| 39 | | | | Date | | | | To | | | |
| 40 | | | | Date | | | | To | | | |
| 41 | | | | Date | | | | To | | | |
| 42 | | | | Date | | | | To | | | |
| 43 | | | | Date | | | | To | | | |
| 44 | | | | Date | | | | To | | | |
| 45 | | | | Date | | | | To | | | |
| 46 | | | | Date | | | | To | | | |
| 47 | | | | Date | | | | To | | | |
| 48 | | | | Date | | | | To | | | |
| 49 | | | | Date | | | | To | | | |
| 50 | | | | Date | | | | To | | | |
| 51 | | | | Date | | | | To | | | |
| 52 | | | | Date | | | | To | | | |
| 53 | | | | Date | | | | To | | | |
| 54 | | | | Date | | | | To | | | |
| 55 | | | | Date | | | | To | | | |
| 56 | | | | Date | | | | To | | | |
| 57 | | | | Date | | | | To | | | |
| 58 | | | | Date | | | | To | | | |
| 59 | | | | Date | | | | To | | | |
| 60 | | | | Date | | | | To | | | |
| 61 | | | | Date | | | | To | | | |
| 62 | | | | Date | | | | To | | | |
| 63 | | | | Date | | | | To | | | |
| 64 | | | | Date | | | | To | | | |
| 65 | | | | Date | | | | To | | | |
| 66 | | | | Date | | | | To | | | |
| 67 | | | | Date | | | | To | | | |
| 68 | | | | Date | | | | To | | | |
| 69 | | | | Date | | | | To | | | |
| 70 | | | | Date | | | | To | | | |
| 71 | | | | Date | | | | To | | | |
| 72 | | | | Date | | | | To | | | |
| 73 | | | | Date | | | | To | | | |
| 74 | | | | Date | | | | To | | | |
| 75 | | | | Date | | | | To | | | |
| 76 | | | | Date | | | | To | | | |
| 77 | | | | Date | | | | To | | | |
| 78 | | | | Date | | | | To | | | |
| 79 | | | | Date | | | | To | | | |
| 80 | | | | Date | | | | To | | | |
| 81 | | | | Date | | | | To | | | |
| 82 | | | | Date | | | | To | | | |
| 83 | | | | Date | | | | To | | | |
| 84 | | | | Date | | | | To | | | |
| 85 | | | | Date | | | | To | | | |
| 86 | | | | Date | | | | To | | | |
| 87 | | | | Date | | | | To | | | |
| 88 | | | | Date | | | | To | | | |
| 89 | | | | Date | | | | To | | | |
| 90 | | | | Date | | | | To | | | |
| 91 | | | | Date | | | | To | | | |
| 92 | | | | Date | | | | To | | | |
| 93 | | | | Date | | | | To | | | |
| 94 | | | | Date | | | | To | | | |
| 95 | | | | Date | | | | To | | | |
| 96 | | | | Date | | | | To | | | |
| 97 | | | | Date | | | | To | | | |
| 98 | | | | Date | | | | To | | | |
| 99 | | | | Date | | | | To | | | |
| 100 | | | | Date | | | | To | | | |
| 101 | | | | Date | | | | To | | | |
| 102 | | | | Date | | | | To | | | |
| 103 | | | | Date | | | | To | | | |
| 104 | | | | Date | | | | To | | | |
| 105 | | | | Date | | | | To | | | |
| 106 | | | | Date | | | | To | | | |
| 107 | | | | Date | | | | To | | | |
| 108 | | | | Date | | | | To | | | |
| 109 | | | | Date | | | | To | | | |
| 110 | | | | Date | | | | To | | | |
| 111 | | | | Date | | | | To | | | |
| 112 | | | | Date | | | | To | | | |
| 113 | | | | Date | | | | To | | | |
| 114 | | | | Date | | | | To | | | |
| 115 | | | | Date | | | | To | | | |
| 116 | | | | Date | | | | To | | | |
| 117 | | | | Date | | | | To | | | |
| 118 | | | | Date | | | | To | | | |
| 119 | | | | Date | | | | To | | | |
| 120 | | | | Date | | | | To | | | |
| 121 | | | | Date | | | | To | | | |
| 122 | | | | Date | | | | To | | | |
| 123 | | | | Date | | | | To | | | |
| 124 | | | | Date | | | | To | | | |
| 125 | | | | Date | | | | To | | | |
| 126 | | | | Date | | | | To | | | |
| 127 | | | | Date | | | | To | | | |
| 128 | | | | Date | | | | To | | | |
| 129 | | | | Date | | | | To | | | |
| 130 | | | | Date | | | | To | | | |
| 131 | | | | Date | | | | To | | | |
| 132 | | | | Date | | | | To | | | |
| 133 | | | | Date | | | | To | | | |
| 134 | | | | Date | | | | To | | | |
| 135 | | | | Date | | | | To | | | |
| 136 | | | | Date | | | | To | | | |
| 137 | | | | Date | | | | To | | | |
| 138 | | | | Date | | | | To | | | |
| 139 | | | | Date | | | | To | | | |
| 140 | | | | Date | | | | To | | | |
| 141 | | | | Date | | | | To | | | |
| 142 | | | | Date | | | | To | | | |
| 143 | | | | Date | | | | To | | | |
| 144 | | | | Date | | | | To | | | |
| 145 | | | | Date | | | | To | | | |
| 146 | | | | Date | | | | To | | | |
| 147 | | | | Date | | | | To | | | |
| 148 | | | | Date | | | | To | | | |
| 149 | | | | Date | | | | To | | | |
| 150 | | | | Date | | | | To | | | |
| 151 | | | | Date | | | | To | | | |
| 152 | | | | Date | | | | To | | | |
| 153 | | | | Date | | | | To | | | |


| | | | |
|--|--|--|--|
| G:\DOCUMENTATION\DOCUMENTATION PRODUITS\US | | | |
| Dessin : SPRINTS3\DOCG TECHNIQUE\ELECTRIQUE\SCHEMAS\ | | | |
| 014400001.VSD | | | |


| | | | |
|--|--|--|--|
| Fabricque de Machines Suisse - 2534 Orvin | | | |
|--|--|--|--|


| | | | | | | | | | | | |
|---------------------|--|--|--|----------|--|--|--|------------|--|--|--|
| SPRINT S3 | | | | Standard | | | | 014-40-600 | | | |
| ELECTRICAL DIAGRAMS | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | </ | | | |





29. FLOOR PLANS













30. SPARE PARTS

When ordering parts, always indicate the part number and the fabrication number of the bar feeder.

The fabrication number is printed on a tag located inside the SPRINT on the chassis.

The main cover must be opened to access to the tag.

| | | | |
|-----------------|----------------------|--|--|
| MODEL | <input type="text"/> |  | |
| S.Nr/YEAR | <input type="text"/> | LNS-SA 2534 ORVIN SWITZERLAND | |
| INCOME VOLTAGE | <input type="text"/> | PHASE | <input type="text"/> HERZ <input type="text"/> |
| CONTROL VOLTAGE | <input type="text"/> | AMP max. | <input type="text"/> |
| F.L.A. | <input type="text"/> | AMP | <input type="text"/> |
| WEIGHT | <input type="text"/> | Kgs | <input type="text"/> |
| | |  MADE IN SWITZERLAND | |



