

# TALKING RADIO CONTROLLED DIGITAL WATCH INSTRUCTIONS

This digital displayed talking radio-controlled watch can pick up time signal in; USA, UK, Germany and Japan, and accounts for daylight saving time automatically.

**Please retain this instruction manual for future reference.**

## **SHIP Mode (*Sleep Mode*)**

When you first take the watch out of the box it will say “SHIP” at the top of the screen. This means that it is in a sleep mode to save battery life when in shipping.

To start using your watch hold the 2 o'clock and 8 o'clock buttons simultaneously for 3 seconds, the watch will beep and show the time and date. To return to sleep mode, complete the same operation again.



## Automatic Time Setting

This radio-controlled talking watch recalls your selected Atomic Clock signal automatically at 3AM every night, after reception of the signal it will show the official local time and date on the watch screen. Everything is done automatically however your watch can also be set manually.

### Button Functions:

- Pressing the 2 o'clock button will speak the time in 12-hour format (e.g. 11:34AM)
- Pressing the 4 o'clock button will speak the date (e.g. Friday, 6<sup>th</sup> of May, Year 2022)
- Pressing the 8 o'clock button will speak the reception status.
- Pressing the 10 o'clock button will say whether the alarm is set and if so, at what time.

**Before the first use please be sure the watch is showing the correct country or region on the screen:**

- **UK:** (United Kingdom)
- **GE:** (Germany)
- **JP:** (Japan)
- **P:** (USA. Pacific)
- **M:** (USA. Mountain)
- **C:** (USA. Central)
- **E:** (USA. Eastern)

**If the watch is showing the incorrect country or region, please follow the directions below:**

- Hold the 8 o'clock button for more than 3 seconds, the watch will speak.
- Press the 8 o'clock button another 3 times until the watch says, "To Select Country or Region".
- Press the 10 o'clock button once.


- Then press the 2 o'clock button until the watch speaks the correct country or region.
- Finally, press the 8 o'clock button to confirm.

During "Summertime" or "Daylight Saving time" there will be a one-hour difference after you have set the watch to a new country. This will be corrected after the local time reception has been updated.

The watch will synchronize with the local atomic clock automatically starting at 3AM so you must make sure that the correct country or region has been set or the watch will not be able to pick up the time signal in either daytime or night-time.

## **Manual Signal reception:**

Please be sure the watch is set to the correct country or region before you continue.

- Press and hold the 10 o'clock button until the signal icon (  ) is flashing.
- The watch takes about 3-8 minutes to pick up the radio signal. Please wait until the watch has finished the signal receiving procedure.
- After successful signal reception, the watch will show the correct time.
- Push the 8 o'clock button for the watch to status of the reception. The watch will state "(Country or region name) time is/is not updated".

If you're unable to get the signal the first time, you may need to try another location where the reception may be more favourable and try manual reception again or wait overnight for better possible reception.

## **Best Overnight Signal Reception Method:**

Your watch should be positioned in the following manner and placed near a window during signal reception in order to get the best possible result.

## **Correct Position for Signal Reception**

Put the watch on its side close to a window facing out (As shown in the illustration).



### **Put the watch on its side facing out of the window**

**If your watch does not synchronize the time with the atomic tower in the first attempt, try it a few more times since the synchronization depends on the clear signal reception and atomic tower location. Try the above methods in different locations. The night-time is the best time to get clear signal from the atomic tower. Radio signals from other home appliances such as tv, radio or computers may interfere with the atomic signals used by your watch. It is recommended to keep the watch away from these devices for time synchronization.**

### **Manual time Setting (For Countries Without Time Signal):**

You should use this function only when you travel to or live in countries with no time signal. You must set your watch to your local time when you come back from countries without radio signal otherwise your watch will never be able to pick up signal at 3AM.

- Hold the 8 o'clock button for more than 3 seconds. The watch will speak.
- Push the 8 o'clock button 4 more times until the watch says, "Set time...."
- Press the 10 o'clock button. The watch will instruct you how to set the time.
- Press the 2 o'clock button to set the hour. Listen carefully to the watch to make sure the right AM or PM time is selected.
- Press the 4 o'clock button to set minutes.
- Press the 8 o'clock button to confirm after you have set the time.

## **Manual Date Setting:**

- Hold the 8 o'clock button for more than 3 seconds. The watch will speak.
- Push the 8 o'clock button 5 more times until the watch says, "Set Date..."
- Press the 10 o'clock button.
- The watch will instruct you on how to set the date.
- Press the 10 o'clock button to set year.
  - The 2 o'clock button for the month.
  - The 4 o'clock button for the day.
  - The 8 o'clock button to confirm.

## **Alarm Setting:**

### **Set Daily Alarm Time:**

- Hold the 8 o'clock button for more than 3 seconds until the watch says "Set Alarm..."
- Press the 10 o'clock button once.
- The watch will instruct you on how to set the time.
- Press the 2 o'clock button repeatedly to set the hour. Press the 4 o'clock button repeatedly to set the minutes.
- Press the 8 o'clock button to confirm after you have set the time.
- After confirmation, the watch will speak the alarm time that you set.
- You can check your alarm time by pressing the 10 o'clock button any time you want.
- The watch will beep for 30 seconds on ALARM TIME; you can interrupt the Beeping Sound by pressing any button. The alarm will sound every day at the set time. If you want to disable the alarm, you can follow the following "Alarm on/off" instructions.

### **Alarm ON/OFF:**

- Hold the 8 o'clock button for more than 3 seconds until the watch says, "Set Alarm..."
- Push the 8 o'clock button one more time. The watch will say, "Alarm ON/Off."
- Press the 10 o'clock button once.
- To turn ON the daily alarm press the 2 o'clock button. To turn off the daily alarm press the 4 o'clock button.
- Press the 8 o'clock button to confirm.

## **Hourly Chime Settings:**

### **Hourly Announcement (Chime) ON/OFF**

(When Chime is ON, the watch announces the HOUR between 6AM and 9PM.

- Hold the 8 o'clock button for more than 3 seconds until the watch says, "Set Alarm..."
- Press the 8 o'clock button 2 more times. The watch will say, "Chime ON/OFF".
- Press the 10 o'clock button once.
- Press the 2 o'clock button to turn ON Chime and the 4 o'clock button to turn OFF Chime.
- Press the 8 o'clock button to confirm

## **Watch Not Receiving Time Signal:**

Reasons for not being able to receive the Time Signal include:

- Being outside of the UK, Germany, USA, or Japan(60Khz) signal area.
- Being in a heavily built-up area.
- Metal objects blocking Radio Signal.
- Interference from computers or TVs

Ensure that the watch is sitting near a window as this provides the best reception. You may have to try different windows in the house to see which is best. Please note that the reception is always best at night. If your watch is unable to receive the Radio Signal, it will continue to function in the same way as a standard watch, the time will then be corrected the next time your watch receives the time signal.

## **Low Battery Detection:**

### **Battery Replacement:**

This watch uses a CR2032 type battery; trained jewellers or watch specialists should be able to replace the batteries to avoid any damage to the watch.

- Open and carefully remove the back of the watch.
- Lift up the battery spring on the bottom.
- Remove the battery and insert a new one with the polarity “+” facing up.
- Push the battery spring down until it locks.
- Before you replace the case-back, make sure the seal is in place.
- After battery replacement the watch defaults to UK time. Please set your country or region as necessary.