



Impaling Clip Installation Instructions

Using Impaling Clips:

Clips should be installed using the Sonus North America placement recommendation sheet included with each panel order.

Mounting on drywall can be done with screws only or with screws and adhesive. Mounting on concrete or masonry with adhesive should be done ahead of installation time for maximum strength.

If the wall panels are not required to be removable, the easiest method of installation is [Impaling Clips](#).

- Impaling clips are shipped from the factory with the panels and should be screwed into the wall where the panels are to be installed. Care should be taken to screw the impaling clips into a stud when possible and to space the clips so that they will be evenly spaced on the back of the panel.
- Some contractors use construction adhesive on the tips of the impaling hardware for extra strength to hold the panels more securely. Please allow 24-48 hours for the construction adhesive to fully cure.

NOTE:

A flat board or plywood piece should be used on the face of the acoustical panel to make sure that pressure necessary to push panel onto the clip, does not crease or wrinkle the facing.

If you should have any questions or concerns about installing your new custom products, please call your project coordinator.

STANDARD NUMBER OF CLIPS PER PANEL

PANEL LENGTH	NUMBER OF CLIPS
up to 24"	4
24" x 48"	4
48" x 72"	6-8
48" x 96"	6-8
48" x 120"	8

