

Formwork Cost Comparison

CANZAC Speedform VS Timber Formwork (shutters)

Example:

To form up and strip a concrete foundation wall 75 LM long x 1.2M high 90 SM per side. 180m² formwork required.

Procedure:

Building Formwork:	CANZAC Speedform	Timber Formwork (Shutters)
Formwork building cost including materials and labour @ \$90.00 per sqm amortised over 5 re-uses		\$18.00/SM
Speedform supplied to height with bend in bottom for strength and fixing	\$26.50/SM	

Formwork Installation:

Install formwork @ \$95.00 per SM install and strip. 75% allocated to installation, 25% allocated to stripping	\$30.00/SM	\$71.25/SM
--	------------	------------

Formwork Stripping:

Stripping formwork @ 25% of allocated installation and stripping cost		\$23.75/SM
---	--	------------

TOTAL COST per SM	\$56.50/SM	\$113/SM
--------------------------	-------------------	-----------------

Savings using CANZAC Speedform \$56.50/SM (50% saving)