

- 1. SUBSTRATE
- 2. EXISTING SMOOTH SUBSTRATE
- 3. TECH GUARD BASE COAT
- 4. TECH GUARD SEAMLESS INSULATION MEMBRANE
- 5. TWO COMPONENT URETHANE PITCH POCKET FILLER
- 6. TECH GUARD TOP COAT
- 7. SMOOTH MEMBRANE
- 8. EXISTING INSULATION
- 9. MINIMUM 1/2" FOAM TERMINATION. MASK SUBSTRATE
- TO AVOID OVER SPRAY. COATING SHELL EXTENDED
- 4" MINIMUM PAST FOAM.

NOTE: EXERCISE COMMON ROOFING PRACTICE TO PREVENT PONDED WATER BY INSTALLING TAPERED INSULATION OR CRICKETS TO CREATE POSITIVE DRAINAGE.



SMOOTH SUBSTRATE ISOLATION TIE-IN (dwg. 62)	DRAWN BY:	DRAWN BY:	APPROVED:
3003 NORTH 73RD STREET, SCOTTSDALE, AZ 85251 402 EAST GRAND ROAD, TUCSON, AZ 85705	SCALE:	PROJECT NO:	DRAWING NO: