

## ACOUSTIVER INSTALLATION INSTRUCTIONS

The wall must be clean (no dust, dirt or grease), dry, even and primed.

Temperature should not be below 46.4 °F.

**1.** Check preparation of the surface (cracks must be filled in, uneven parts must be cut to length according to room height (+ 4 in).

**2.** Apply the adhesive evenly on the wall using ¾" nap roller (-5.9oz/yard<sup>2</sup>).  
Heavy Duty Clear or clay premixed wallcovering adhesive is recommended.

**3.** Place the wallcovering panel on the wall vertically and smooth it with a plastic spatula.

**4.** Place the adjacent panel edge to edge (respect vertical pattern repeat).

Repeat steps 1, 2, and 3 with other panels until you have finished the room.

**5.** Cut off any surplus with a knife.

**6.** Apply a 1st coat of acrylic latex paint.

When dry, apply 2nd coat of acrylic latex paint. The glass fiber fabric is carefully checked before leaving our factory but should also be checked again just before hanging. Any claim should be accompanied with roll label and a sample featuring the defect.

