

Upgrade Your Cardiovascular Research

VICORDER®



PULSE WAVE VELOCITY (PWV)

- Arterial stiffness measurement using validated carotid-femoral method
- Consistent results through oscillometric technology

CENTRAL AORTIC PRESSURE (cSBP) AUGMENTATION INDEX (AIX)

- Identifying cardiovascular risk by measuring arterial stiffness within minutes

PULSE WAVE ANALYSIS (PWA)

- Hemodynamic values through PWA
- Cardiac Output

FLOW MEDIATED SLOWING (FMS)

- Endothelial function indicator utilizing automated testing procedure
- Correlates with gold-standard FMD



Contact

80 Beats Medical GmbH
www.80beatsmedical.com

