




Instruction and Safety Manual

Treestand Hub Style Umbrella MODEL: PTHU-134

- Always Wear a Safety Harness when using this Product
- Practice Using at Ground Level



Thank you
very much
for choosing



We appreciate
your business!



WARNING

SAFETY MUST BE YOUR FIRST PRIORITY WITH THIS PRODUCT

Every year serious injury or death can occur from hunting related accidents. To ensure your safety, please **completely** read and follow this safety manual and **all warning** labels **before** assembling, installing or utilizing this product.

Do not use this product before fully understanding all safety warnings and instructions. If you have questions, are unsure about any information or need additional information concerning your product, contact our customer service department at 1-866-972-6168 or visit www.Primaloutdoors.com. Keep and maintain this safety and instruction manual in a safe location for future reference.

Distributed by Primal Brands, LLC, 1745 Shea Center Drive 4th Floor, Highlands Ranch, CO 80129

©2023 (rev. 1/23)

Customer Service Department 1-866-972-6168

www.primaloutdoors.com



Treestand Hub Style Umbrella

MODEL: PTHU-134

- Always Wear a Safety Harness when using this Product
- Practice Using at Ground Level


PARTS LIST


- A** 1 Hub Umbrella.....Part # HU-134A
- B** 3 Tree Strap.....Part # HU-134B

A Hub Umbrella



B Tree Strap





1 Lay Umbrella **A** down and unfold with the top facing up




2 Hold the umbrella by the center hub strap and lift umbrella up. With your other arm extended, hold the umbrella so that the ribs of the umbrella are resting against your body and open hand.




3 Firmly pull the center hub strap to expand the umbrella.



4 While standing on the foot platform of your tree stand, attach the apron above you as high as possible up the tree. Secure both straps. Pull the straps to tighten the apron to the tree.



5 Raise umbrella and attach the center hub strap to the center apron strap. Pull slack from strap to level the umbrella **A** front to back.



6 Attach and tighten the Tree Strap **B** to the tree below the umbrella **A**. Attach the Swivel Clips of the Tree Strap **B** to the D-rings on the umbrella **A**. Adjust the straps to level the umbrella left to right. **NOTE:** There are two sets of D-rings on the umbrella. It is recommended to use the D-rings in the front corners of the umbrella **A** during windy conditions.