



512926 Active holder with cig-plug With tilt swivel. Fits device with Zebra Original Rugged Boot.

The active holder charges your battery when it is in the holder. The charging device connects to the PDA automatically when you put the PDA in the holder. The holder is attached onto a tilt swivel and can be adjusted in order to avoid light reflection. Connects to the vehicle's cigarette lighter socket, 12/24 Volt. With straight cable. Attach onto a ProClip Mounting Platform.

Dimensions: 87 x 125 x 76 mm (W x H x D mm)

Weight: 220 g

Cable length (Holder+pigtail 27cm, cable+Cig 107cm).

EAN: 7320285129269

Item no 512926 fits:

Zebra TC51 (For all countries)

Zebra TC52 (For all countries)

Zebra TC56 (For all countries)

Zebra TC57 (For all countries)

INSTALLATION INSTRUCTIONS

1.



2.



3.



4.



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.
 2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.
 3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw firm at first, then loosen it a bit so the holder is firmly in place, but still can be adjusted.
 4. The holder is in place.
-