

Amazon Alexa Manual



NOTICE:

1. Lägg först till TLock-appen i telefonen
2. Koppla in Gateway;
3. Lägg till Alexa-appen i telefonen.

1. Para ihop låset

1.1 Ladda ner och installera TTLock från Google Play/App-store



- 1) Android-användare kan skanna vänstra QR-koden ovan
- 2) Apple-användare kan skanna högra QR-koden ovan
- 3) Alternativt kan man söka i Google Play eller App-store
- 4) Registrera nytt konto (telefonnummer eller email) eller logga in. med existerande konto.
- 5) Tryck på kodplattan för att aktivera låset, sedan "+ Lägg till lås" i appen
- 6) Om låset är inom 2 meter kommer det att dyka upp i appen, klicka "+"
- 7) Ändra namn på låset
- 8) Låset har nu lagts till

This is the first screen of the app. It has a blue header with 'Login' and 'Register' buttons. The 'Register' button is highlighted with a red box. Below the header is a blue hand icon with a key. There are two input fields: 'Phone number/Email' and 'Password'. At the bottom, there is a grey 'Login' button and a blue link for 'Forgot Password?'.


1-1

This is the registration screen. It has a blue header with a back arrow and 'Register'. There are two tabs: 'Phone' (selected) and 'Email'. Below the tabs, it shows 'Country/Region American Samoa+1684'. There are three input fields: 'Enter your Phone number', 'Password between 6-20 chars', and 'Confirm Password'. At the bottom, there is a 'Verification Code' field and a 'Get Code' button. A grey 'Register' button is highlighted with a red box at the bottom of the screen.


1-2

This is the login screen. It has a blue header with 'Login' and 'Register' buttons. Below the header is a blue hand icon with a key. There are two input fields: one with the phone number '18520265893' and another with a masked password. At the bottom, there is a blue 'Login' button highlighted with a red box and a blue link for 'Forgot Password?'.


1-3




1-4



1-5



1-6



1-7

2. Para ihop din Gateway

Light Status



When the gateway is powered on:



Light flashes alternately in red and blue:
Stand-by mode, ready for pairing




Blue light: Working mode




Red light: Network failure

Pair the Gateway with APP

1 Activate the APP




2 Press “≡”



4 Select [G2]



5 Plug in the gateway and power it on, while the light flashes alternately in red and blue



3 Select [Gateway]



6 Press “+” sign



7 Add Gateway



8 Select the network and fill in the password



9 Add complete

⚠ Notice: If times out, please power off and try it again.

3. Ladda ner och registrera dig i Amazon Alexa

3.1 Sök Alexa I Google Play/Appstore

3.2 Registrera ev nytt konto (har du redan konto är det bara att logga in)

amazon alexa

Sign-In

[Forgot password?](#)

Email (phone for mobile accounts)

Amazon password

Show password

SIGN-IN

New to Amazon?

CREATE A NEW AMAZON ACCOUNT

© 1999-2019 Amazon.com, Inc. or its affiliates

3-2-1

amazon alexa

Create account

Your name

Your e-mail address

Create a password

i Passwords must be at least 6 characters.

Show password

CREATE YOUR AMAZON ACCOUNT

"By creating an account, you agree to Amazon's Conditions of Use and Privacy Policy."

Already have an account?


SIGN-IN NOW

© 1999-2019 Amazon.com, Inc. or its affiliates


3-2-2

4. Lägga till Alexa Skill: ScienerSmart

4.1 Välj "Skills & Games"




4-1-1




4-1-2

4.2 Skriv in "ScienerSmart" I sökfältet






4-2-1



4-2-2

4.3 Klicka ScienerSmart i sökresultatet och "ENABLE TO USE"



Hardware Requirements:

1. Sciener Smart Lock
2. Gateway - sold separately
3. Echo/Dot

Get Started:

[See More](#)

Start By Saying



English (US) ▾

"Alexa, unlock the door lock."


"Alexa unlock my door lock"



4.4 Skriv in ditt sciener (TTLock) konto för auktorisering






After authorizing, sciener will be able to manage your devices



4-4-1

4.5 När auktoriseringen är klar, återvänd till Amazon Alexa Appen och klicka "Discover device" eller cancel




4-5-1




4-5-2


4.6 Om du väljer #Discover device” kan appen hitta enheter I närheten. Bli inte orolig om sökningen misslyckas att hitta. Tryck på ”Cancel” och gör följande:




4-6-1




4-6-2




4-6-3




4-6-4




4-6-5




4-6-6




4-6-7




4-6-8




4-6-9




4-6-10




4-6-11




4-6-12




4-6-13



4-6-14




4-6-15




4-6-16


4.7 Lägg till lås i Alexa




4-7-1




4-7-2




4-7-3




4-7-4




4-7-5




4-7-6



4-7-7




4-7-8




4-7-9


4.7 När konfigurationen är klar, klicka på det låset du just lagt till klicka på kugghjulet uppe i högra hörnet, klicka "unlock by voice" för att komma in på konfigurationssidan.



4-7-1



4-7-2




4-7-3


4.8 Ställ in konfirmationskoden och verifiera sedan kontot. Funktionen "Unlock by voice" kommer att automatiskt läggas till och konfigurationen är sedan klar.

Nu kan du börja använda den! Alla kommandon måste ske på det i appen inställda språket. (I det här fallet är det engelska)


Exempel: Säg till Alexa :Alexa, unlock Home!



4-8-1



4-8-2



4-8-3