

IP Addressing

1.4 Setup Instructions



What's New?



- Simplified Management Interface
- Easy Setup
 - Now ensuring Static and Dynamic IP's do not collide is easier than ever.
 - Simply set the Employees Group and all other groups will automatically configure.
 - Automatically check for colliding IP addresses

Network/DHCP Configuration

Employees Network

10 . 10 . 1 . X

Unbox Gateway IP Address: 10.10.1.1

Reserved for Static IP Addresses:

- 10.10.1.201 - 10.10.1.254

(If some customer devices have static IPs configured make sure the addresses fall into one of these ranges:)

Dynamic IP addresses (DHCP) will start at:

10.10.1.2

And end at


10.10.1.200

This network will be able to connect up to 199 devices simultaneously.

Advanced DHCP Cancel Save

Indicate the allotted range for the employees group and let the Unbox take care of the rest

Easily see the configuration and all IP addresses included within the ranges



Configuring the Employees Group Automatically configures all other groups

In the Background



- Gateway is checking for colliding IP addresses
- Ensuring the number of connectable DHCP and Static Devices
- Automatically assigns gateway security group IP's and site network based on Employee Group configuration and applies it to all other groups