

000100 CRANKCASE



000200 OIL PAN



000300 CYLINDER HEAD



000400 GEAR CASE

000500 HEAD COVER



003000 ENGINE BRACKET



010000 MAIN BEARING CASE



010100 CAMSHAFT AND IDLE GEAR SHAFT



010200 PISTON AND CRANKSHAFT



010300 FLYWHEEL




010500 FUEL CAMSHAFT AND GOVERNOR SHAFT




020100 STOP SOLENOID




020400 GOVERNOR




020600 NOZZLE HOLDER AND GLOW PLUG




041300 ALTERNATOR




041400 ALTERNATOR (COMPONENT PARTS)




041600 STARTER




041700 STARTER (COMPONENT PARTS)




050000 WATER FLANGE AND THERMOSTAT




050100 WATER PUMP




050600 TENSION PULLEY




051100 RADIATOR




051300 WATER PIPE AND RESERVE TANK




060000 VALVE AND ROCKER ARM




061000 INLET MANIFOLD




061200 EXHAUST MANIFOLD




061400 AIR CLEANER



061600 MUFFLER



090100 UPPER GASKET KIT



090200 LOWER GASKET KIT

