




000200 OIL PAN




000400 GEAR CASE




010000 MAIN BEARING CASE




010100 CAMSHAFT AND IDLE GEAR SHAFT




010200 PISTON AND CRANKSHAFT




010300 FLYWHEEL




010500 FUEL CAMSHAFT




010600 BALANCER




020000 ENGINE STOP LEVER




020200 INJECTION PUMP




020400 GOVERNOR




020500 SPEED CONTROL PLATE [OLD]




020501 SPEED CONTROL PLATE [OLD]




020502 SPEED CONTROL PLATE [NEW]




020600 NOZZLE HOLDER AND GLOW PLUG




020700 NOZZLE HOLDER [COMPONENT PARTS]




050000 WATER FLANGE AND THERMOSTAT




050100 WATER PUMP




060000 VALVE AND ROCKER ARM




060100 INLET MANIFOLD




060200 EXHAUST MANIFOLD




060400 AIR CLEANER




060500 INLET PIPE




060600 MUFFLER



060700 TURBO CHARGER



060800 OIL PIPE (TURBO CHARGER)



070200 OIL COOLER

