




## 000200 OIL PAN




## 000402 GEAR CASE




## 010002 MAIN BEARING CASE




010102 CAMSHAFT AND IDLE GEAR SHAFT




010202 PISTON AND CRANKSHAFT




010302 FLYWHEEL




010502 FUEL CAMSHAFT




010602 BALANCER




020000 ENGINE STOP LEVER




020200 INJECTION PUMP




020402 GOVERNOR




020500 SPEED CONTROL PLATE




020600 NOZZLE HOLDER AND GLOW PLUG




020700 NOZZLE HOLDER [COMPONENT PARTS]




050001 WATER FLANGE AND THERMOSTAT [ROPS TYPE]




# 050100 WATER PUMP




## 060100 INLET MANIFOLD




## 060403 AIR CLEANER [ROPS TYPE]




060404 AIR CLEANER [CAB TYPE]




090100 UPPER GASKET KIT



090202 LOWER GASKET KIT



A01004 ACCELERATOR LEVER [ROPS TYPE]



A01005 ACCELERATOR LEVER [CAB TYPE]

