




100200 OIL PAN




## 100400 GEAR CASE




100600 OIL FILTER




# 110000 MAIN BEARING CASE




## 110200 PISTON AND CRANKSHAFT




## 110500 FUEL CAMSHAFT AND GOVERNOR SHAFT




120000 IDLE APPARATUS




120100 STOP SOLENOID




120200 INJECTION PUMP




120401 GOVERNOR




120402 GOVERNOR




120500 SPEED CONTROL PLATE




## 120700 NOZZLE HOLDER [COMPONENT PARTS]




## 140000 DYNAMO AND PULLEY




140400 STARTER




## 140502 STARTER [COMPONENT PARTS]









## 150000 WATER FLANGE AND THERMOSTAT




150400 FAN







170300 HYDRAULIC PUMP COVER




190001 UPPER GASKET KIT




190002 UPPER GASKET KIT



190101 LOWER GASKET KIT



190102 LOWER GASKET KIT



A00102 ACCELERATOR LEVER

