

## AX charging base



<b>Size:</b>	100*95*45mm
<b>Weight:</b>	140g
<b>Charging voltage:</b>	DC 5V
<b>Charging ways:</b>	
1.Charging with Portable Charger	Take the AX charging base, put the negative pole in to the charging lock. Rotate 90 degrees clockwise to make the positive nut of the charging base to cotact with the positive spring washer of the charging rack;
2. Charging at Charging rack	Take the AX charging base, put the negative pole in to the charging lock. Rotate 90 degrees clockwise to make the positive nut of the charging base to cotact with the positive spring washer of the charging rack;
3. Charging with USB	Use USB cable to connect with DC5V/1A charger; or computer DC5V, USB interface.