


SSRM System breakdown



A: 520024-01 SSR endcap 6"

B: 520030-01 Rear SSR end stop

C: 520023-06 6"x6' Straight suction rail

D: 500047-02 Leg assy. w/ feet

E: 520032-01 Lip insert for rail

F: 520040-02 rail connector pin

G: 520020-04 Crab Assy.

H: 500095-11 Blue/White Hose 5"x11'

I: 500065-01 Swivel "H" for balancer

J: 500084-04 Blue balancer Assy.

K: 530408-05 Lifting Elbow Assy. 5"

L: 530622-02 Handle/Knob 5" Assy.

M: 500071-05 Pressure Sensor

N: 540557-02 Transmitter standard

O: 530630-05: 5"x2' Rigid Blue HT hose

P: 500002-74 Elbow to nozzle stress cable

Q: 500089-04 Nozzle Elbow 5x7 alum

R: 520049-08 SSR Shock absorber endstop

S: 530500-01 Rag screen

T: 500087-03 Boot w/ magpaks

U: 500073-02 5" Tailpipe Adaptor