


Replacement Carpet Insert Tips

1



Build up of salt and debris in the track can cause extra friction when sliding in new carpet inserts.



A steel wire brush held at an angle can be used to remove this build up.



Pliers can be used to help pull the carpet inserts.





3

Another option is to use a steel wire brush to slide the carpet inserts.