













2) PULL FLEX DUCT DOWN THRU HOLE AND ATTACH REGISTER BOOT.



3) INSERT *QUICK ZIPS* IN 4 ZIP RECEPTOR BLOCKS WITH HEADS OF ZIPS ABOVE BOOT FLANGE. PUSH HEADS OF ZIPS AND REGISTER BOOT BACK UP INTO CEILING HOLE UNTIL FLANGE TOUCHES CEILING.



4) GRASP TAIL OF EACH *QUICK ZIP* AND PULL DOWN TO SECURE REGISTER BOOT TO CEILING—SNIP OFF END OF *QUICK ZIPS* AT FLANGE.



5) INSERT EASY ATTACH KNOB IN CENTER OF CEILING GRILLE AND LINE UP WITH REGISTER BOOT CROSSBAR TO ATTACH CEILING GRILLE TO BOOT. EASILY REMOVE JUST GRILLE TO CLEAN OR PAINT.



8 1/2" TEMPLATE FOR
GRILLE LAYOUT & POSITIONING
ON CEILING





ALSO AVAILABLE WITH DAMPER: ON DAMPERED MODELS EASILY ADJUST DAMPER BY INSERTING ADJUSTMENT ROD UP THROUGH CENTER OF ATTACHMENT KNOB AND MANUALLY TURNING TO ADJUST BUTTERFLY OR ROTARY DAMPERS. LEAVE ROD IN PLACE OR REMOVE AND INSERT PROVIDED PLUG IN TOP OF KNOB.

MADE IN THE US/