

- 1 Press Enter amount field.
 After entering the amount, press PAY keyboard button
- 2 Tap the card on the back of the device. !IMPORTANT: Hold the card until the sound signal.
- If you want to cancel (or change the amount), press Discard Transaction button.
- When Enter your PIN screen is displayed, turn the device to the customer to enter the PIN.
- **Solution** After entering 4 digits, **the buyer must press OK** button.

- When Instalment sale screen is displayed, leave Number of instalment field blank and press PAY button.
 - **Press Discard Transaction** button to cancel the transaction.
- Wait until the transaction process completes. !IMPORTANT: Don't exit the app and don't type until end of this action.
- 8 In footer, select prefered way of showing transaction slip.
 - **!Note:** Show slip & Get QR code will show slip in application.
- Press NEW SALE button to return to the initial screen (Sale).











