

## PEL924 – Talking Projection Clock

### Talking Projection Clock



#### Functions:

- Sound controlled backlight and projection display.
- Projection TIME function
- Talking TIME and Temperature function: More Languages for your Choose (one unit is only one language): English, Spanish, Russian, Portuguese, Italian and Chinese.
- Talking time of integer hour
- LED backlight
- Calendar: Can be changed From Jan.1<sup>st</sup> 2000 to Dec.31<sup>th</sup>, 2099. 12-hour or 24-hour Format for chose; It's on Jan.1<sup>st</sup>, 2007 at 12:00 a.m. on Monday when opening.
- Digital Thermometer: (range: Russian - 30 ° ~ 50 ° c and other language - 10 ° ~ 90 ° c)
- Alarm /Snooze function

#### Basic Operations

1. Insert 3 \*AAA ( batteries) to start the unit, at the same time the normal LCD displays: 12:00 1/1 MON
2. **Time setting**
  - In Normal time mode, press and hold SET key for 3 seconds to enter

the date and time setting mode. The YEAR digits are blinking and can be set by pressing UP or DOWN key for setting year. Press SET key again, The month digits are blinking and can be set by pressing UP or DOWN key for setting month, date, hour, minute.

- Setting range: year: 2000-2099. month: 1-12. day: 1-31. hour: 1-12 or 0-23. minute: 0-59

#### 3. Alarm clock, snooze setting

- In Normal time mode, press MODE key one time to enter ALLRM mode, press and hold SET key for 3 seconds to enter the alarm setting mode. The OF digits are blinking and can be set by pressing UP or DOWN key for setting hour and minute.
  - In Setting mode, press MODE key or no any operation within 1 minute, it will exit the setting mode to return the normal mode.
  - In Alarm clock mode, press UP and DOWN key to select the music.
  - When the alarm set time arrived, will ring for 1 minute. press projection head, Pause the alarm and enter into the SNZ mode, and the SNZ icon is flashing. snooze interval time is 10 minutes, arrived the alarm for 1 minutes. Snooze alarm times up to 6 times.
  - In alarm or snooze alarm, press the projection and any keys, then stop the alarm and release the snooze state.
  - In alarm, if not press any key, 1 minutes later the alarm stop and do not enter the snooze function.
4. In Normal time mode, press and hold UP key for 3 seconds to on/off CHIME function. LCD display CHIME: 22: 00-6: 00 Automatic stop time.
  5. In normal time mode, press UP key to switch between 12-hour and 24-hour Format. LCD display AM or PM is the 12-hour Format.
  6. In normal time mode, press SET key to switch between C/F format.
  7. The unit uses 3PCS AAA batteries. Please replace batteries if the screen is not clear or the sound not abnormal.