

FANTASY SOCCER

Player inserts a coin

Ticket values appear randomly at the bottom of the screen.

The ball will move side to side

The player will decide where to drop the ball by pressing the button

As the ball descends the player can alter the course of the ball

By catching the ball and re-releasing the ball in a more favorable ticket value area


The ball will come to a stop and the player will win that number of tickets.



ELAUT® nv
Passtraat 223
B-9100 Sint-Niklaas
Belgium

T +32 (0)3 780 94 80
F +32 (0)3 778 05 61
sales@elaut.be
www.elaut.com

DISTRIBUTED BY:



all dimensions are in mm
1 inch = 25.4mm

Rated Voltage:230/115VAC