7-4-5 Error Code [2503]

1. Error code definition Drain sensor (Thd) fault

2. Error definition and error detection method

- •If the open or short circuit of the thermistor has been detected for 30 seconds, this condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- •If another episode of the above condition is detected during the preliminary error, this is considered a drain sensor error.(If the short or open circuit of the thermistor is no longer detected, normal operation will be restored in 3 minutes.)
- •This error is detected when one of the following conditions are met.
 - *During Cool/Dry operation
 - *Liquid pipe temperature minus inlet temperature is equal to or smaller than -10°C [-18°F] (except during the defrost cycle)
 - *When the liquid temperature thermistor or suction temperature thermistor or short or open circuited.
 - *Drain pump is in operation.
 - *One hour has elapsed since the drain sensor went off.

Short: 90°C [194 °F] or above Open: - 20°C [-4 °F] or below

3. Cause, check method and remedy

Cause		Check method and remedy	
(1)	Faulty connector (CN31) insertion.	1)	Check for connector connection failure. Reinsert the connector, restart the operation, and check for proper operation.
(2)	Broken or semi-broken thermistor wire	2)	Check for a broken thermistor wire.
(3)	Thermistor failure	3)	Check the resistance of the thermistor. $0^{\circ}\text{C}[32\ ^{\circ}\text{F}]\text{:}6.0\ k\Omega$ $10^{\circ}\text{C}[50\ ^{\circ}\text{F}]\text{:}3.9\ k\Omega$ $20^{\circ}\text{C}[68^{\circ}\text{F}]\text{:}2.6\ k\Omega$ $30^{\circ}\text{C}[86^{\circ}\text{F}]\text{:}1.8\ k\Omega$ $40^{\circ}\text{C}[104\ ^{\circ}\text{F}]\text{:}1.3\ k\Omega$
(4)	Indoor unit control board (error detection circuit) failure	4)	Replace the indoor unit control board if the problem recurs when the unit is operated with the No1 and No2 pins on the drain sensor connector (CN31) being short-circuited. If the above item checks out OK, there are no problems with the drain sensor. Turn off the power and turn it back on.