



BRACE TOOL

OILFIELD, WIRELINE & DOWNHOLE TOOLS

R Running Tool



Scan for more
information



Purpose

The R Running Tool is designed to facilitate the efficient running and setting of R and RN locks in R and RN nipples. This versatile tool provides two distinct running modes, Selective and Non-Selective, catering to specific well completion requirements.

In the Selective mode, the running tool can run and set the R Lock in the desired nipple while being able to pass through R Nipples of the same size or larger. In the Non-Selective mode, the R or RN Lock can be run and set in the first nipple of that same size and type R or RN.

For more assurance, using the R Check Set Tool to ensure correct setting of the Locks is recommended.

Application:

- Running and setting R and RN locks in corresponding nipples.

Key Features & Benefits:

- Selective and Non-Selective running modes, providing flexibility in deployment based on the wellbore conditions and lock specifications.
- Available in different sizes.

Technical Data						
Nominal Size	Assembly Number	Upper Thread Connection	Lower Thread Connection	Max O.D.	Fishneck Size	Latched Fishneck
1.71"	02-02-R-171-A0	0.938"-10 UN-2A	0.375"-16 UNC-2B	1.640"	1.187"	1.062"
1.78"	02-02-R-178-A0	0.938"-10 UN-2A	0.500"-13 UNC-2B	1.750"	1.375"	1.375"
1.87"	02-02-R-187-A0	0.938"-10 UN-2A	0.500"-13 UNC-2B	1.780"	1.375"	1.375"
2.13"	02-02-R-212-A0	0.938"-10 UN-2A	0.500"-13 UNC-2B	2.062"	1.375"	1.375"
2.18"	02-02-R-218-A0	0.938"-10 UN-2A	0.625"-11 UNC-2B	2.180"	1.750"	1.812"
2.31"	02-02-R-231-A0	0.938"-10 UN-2A	0.625"-11 UNC-2B	2.180"	1.750"	1.812"
2.56"	02-02-R-256-A0	0.938"-10 UN-2A	0.625"-11 UNC-2B	2.500"	1.750"	1.812"
2.75"	02-02-R-275-A0	1.063"-10 UN-2A	0.750"-10 UNC-2B	2.715"	2.312"	2.312"
2.81"	02-02-R-281-A0	1.063"-10 UN-2A	0.750"-10 UNC-2B	2.715"	2.312"	2.312"
3.43"	02-02-R-343-A0	1.063"-10 UN-2A	1.375"-12 UN-2B	3.400"	2.312"	2.312"
3.68"	02-02-R-368-A0	1.063"-10 UN-2A	1.375"-12 UN-2B	3.650"	2.312"	3.125"
3.81"	02-02-R-381-A0	1.063"-10 UN-2A	1.375"-12 UN-2B	3.750"	2.312"	3.125"
4.12"	02-02-R-412-A0	1.063"-10 UN-2A	2.125"-12 UN-2B	4.020"	2.312"	3.125"
4.31"	02-02-R-431-A0	1.063"-10 UN-2A	2.125"-12 UN-2B	4.245"	2.312"	3.125"

Speak with a Brace Tool sales representative to explore the different configurations available on this tool and discover how we can match your requirements.



www.bracetool.com || Toll-Free: 1-800-438-0061.