

ENGLISH

Washbasin with feeder plug XS

with pedestal

a push button

Ref. 061426

Contents

- Sheathing for washbasin with feeder plug XS.
- 461008 - Turning tap 140X200X1/2" (50mm nut).
- 461212 - H-H 1/2" (900mm) flexible hose with stainless steel mesh.
- 460404 - 1/2" M-M Timer button.
- 461604 - 1/2" M-H-M non-return mixer.
- 454202 - 2 1/2" Valve with trough for 500mm sink.
- 461802 - 1/2" M-H 90° knee.
- 409822 - Plastic nylon Fisher 6x30mm peg.
- 421038 - Plate thread bolt 22x4,8mm. DIN 7981 A2.

Assembly



Check the contents.

Avoid dirt in pipes and in the area before assembly.

If the plumbing is new, let the water flow.

When assembling, it is advisable to use special gloves not to get cuts on hands.

Use teflon to seal connexions.

Pull out front door and remove the plastics from doors and washbasin.

Connect the knee to the push button input (see arrow below the pushbutton) · Fig. 1

Connect the output of the mixer T to the input knee of the button. (See arrow at the bottom of the button) · Fig. 1

Connect the supplied mixed water flexible hose to the outlet of the push button (see the arrow point on the push button to check the incoming flow) · Fig. 1

Introduce the pipe in the upper orifice and fix it the attached bolts · Fig. 2

Connect the water ports to the non-return mixer.

Introduce the push button in the orifice from the inside of the case and fix it with its bolt from the outside.

Connect the free end of the mixed water flex hose to the output

Assemble the discharge valve · Fig. 3

Fix the washbasin on the wall · Fig. 4

You can now connect the water input and the discharge to the washbasin.

Adjust the desired temperature by turning the non-return mixing crown.

Place the waste bag in the wastepaper bin of the door by sliding it upwards and then pulling. Fasten the bag with the rubber band.

Use

To open tap, press the push button with foot.

Temperature can be adjusted with the non-return mixer handle.

Maintenance

- Use only water and neutral soap when cleaning.
- Wipe with a soft cloth.
- Rinse with plenty of water.
- Dry with a soft cloth.
- Do not use acids or strong detergents and do not rub with a scourer or spatula.

Safety

When cleaning, be extra careful with corners.

Other hazards have not been observed.

Available spares

- 461008 - Turning tap 140X200X1/2" (50mm nut).
- 461212 - H-H 1/2" (900mm) flexible hose with stainless steel mesh.
- 460404 - 1/2" M-M Timer button.
- 461604 - 1/2" M-H-M non-return mixer.
- 454202 - 2 1/2" Valve with trough for 500mm sink.
- 461802 - 1/2" M-H 90° knee.

 All sizes are described in mms.