

## AeroChamber Sniffer INSTRUCTIONS



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

Test Preparation	1 Gently insert the Accessory into the Sniffer.	2 Remove the Smart-Tip™ probe from the appropriate test kit.	3 Remove the cover paper from the Smart-Tip™ probe.
	<p>Push until a click sound is heard. <b>CLICK!</b></p>		<p>Do not touch the adhesive.</p>

Test Preparation	4 Insert the Smart-Tip™ probe into the Accessory with the adhesive area facing out from the Sniffer.	<p><b>Important:</b> Push down the Smart-Tip™ probe until it is completely locked into the sampling unit.</p>	5 Collect particles from the suspect surface. Vacuum up to 10 seconds.
	<p>Adhesive located on the FRONT of the probe for collecting particles</p>		<p>Suspect Surface <b>Do not use MAX power.</b></p>

Test Preparation	6 Remove the Smart-Tip™ probe from the Sniffer.	7 Lock Smart-Tip™ probe into test unit. Press firmly.	<p><b>STOP</b> Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit.</p>
		<p>Flex Pins</p>	

### CONTINUE TO KIT INSTRUCTIONS ON OTHER SIDE. →

Operating Notes

- Use only IDenta Sniff & Know™ Detection Kits with the Sniffer.
- The Sniffer can be used for screening suspected people, clothing, hands, packages, shipping containers, and vehicles.
- The Sniffer is for relatively clean surfaces.
- Make sure to use the proper instructions. Testing procedures may vary for different types of detection kits. Using the wrong instructions may lead to improper identification.
- For optimum Sniffer operation time, do not use maximum (MAX) power.
- For maintenance and troubleshooting see the Sniffer Operating Manual.

## AeroChamber Sniffer

TESTING KITS FOR DRUGS

Procedure Card for IDT3300S

MARIJUANA/HASHISH  
IDENTIFICATION

SNIFFER Test Kit



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

SIDE 2

Complete Steps 1-7 before proceeding.

Identification	8 With thumb and forefinger, squeeze chamber 1 until capsule breaks.	9 Gently shake test unit for 5 seconds.

Identification	10 With thumb and forefinger, squeeze chamber 2 until capsule breaks.	11 Gently shake test unit for 5 seconds.

Results

The appearance of a red color within a few seconds on the adhesive or in the liquid indicates the presence of **Cannabis (Marijuana/Hashish)**.



If no red color appears within a few seconds, Cannabis (Marijuana/Hashish) is **not** present.  
\* **Also Note:** The appearance of a yellow color that darkens to a reddish color after 1 minute, does **not** indicate the presence of Marijuana or Hashish.



Disposal

The test kit is safe to dispose of in the trash.