

IDenta SNIFF & Know®

AeroChamber Sniffer INSTRUCTIONS



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

Test Preparation	1	Gently insert the Accessory into the Sniffer. Push until a click sound is heard. CLICK!	2	Remove the Smart-Tip™ probe from the appropriate test kit.	3	Remove the cover paper from the Smart-Tip™ probe. Do not touch the adhesive.

Test Preparation	4	Insert the Smart-Tip™ probe into the Accessory with the adhesive area facing out from the Sniffer. 	Important: Push down the Smart-Tip™ probe until it is completely locked into the sampling unit.	5	Collect particles from the suspect surface. Vacuum up to 10 seconds.
	Adhesive located on the FRONT of the probe for collecting particles			Suspect Surface Do not use MAX power.	

Test Preparation	6	Remove the Smart-Tip™ probe from the Sniffer. 	STOP Do not continue unless probe is locked below the Flex Pins and cannot be removed from the test unit.	7	Lock Smart-Tip™ probe into test unit. Press firmly.

CONTINUE TO KIT INSTRUCTIONS ON OTHER SIDE. →

Operating Notes

- Use only IDenta Sniff & Know™ Detection Kits with the Sniffer.
- The Sniffer can be used for screening suspected people, clothing, hands, packages, shipping containers, and vehicles.
- The Sniffer is for relatively clean surfaces.
- Make sure to use the proper instructions. Testing procedures may vary for different types of detection kits. Using the wrong instructions may lead to improper identification.
- For optimum Sniffer operation time, do not use maximum (MAX) power.
- For maintenance and troubleshooting see the Sniffer Operating Manual.



Manufactured by IDenta Ltd
www.identa-corp.com
Patented Technology • Made in Israel

AeroChamber Sniffer

TESTING KITS FOR DRUGS

Procedure Card for IDT4500S

ECSTASY/
METHAMPHETAMINE
IDENTIFICATION
SNIFFER Test Kit



As a precaution, gloves and eye protection should be worn when handling drug substances and using test units. Do not puncture any part of unit. Do not remove probe once a capsule is broken. In the unlikely event of a spill, rinse affected area thoroughly with water. Keep out of reach of children. All results are presumptive. If necessary, further testing by a competent drug testing lab can provide additional identification.

SIDE 2

Complete Steps 1-7 before proceeding.

Identification	8	With thumb and forefinger, squeeze chamber 1 until capsule breaks. 	9	Gently shake test unit for 2-3 seconds.

Identification	10	With thumb and forefinger, squeeze chamber 2 until capsule breaks. 	11	Do NOT shake or agitate test unit.
			Proceed to Results.	

Results	The appearance of a blue or blue-purple color on the adhesive or in the liquid indicates the presence of Methamphetamine or Ecstasy/MDMA . *The color will darken over time.
	If no blue or blue-purple color develops, neither Ecstasy/MDMA nor Methamphetamine are present.



Disposal The test kit is safe to dispose of in the trash.

01-15



Manufactured by IDenta Ltd
www.identa-corp.com
Patented Technology • Made in Israel