



CALYX

**TH215** User Manual

## Larger Tank, Greater Capacity

Getting the most out of this cartridge is easy thanks to its large capacity 1.5ml tank.



## Designed for CALYX Battery

The CALYX cartridges have a matching luster and hand feel, perfectly complementing the CALYX Battery.

## Cartridge Specs

- Tank Volume: 1.5ml
- Dimensions:  $\varnothing 0.56 \times 2.16$  (in) /  $\varnothing 14.1 \times 54.8$  (mm)
- Resistance: 1.4  $\Omega$
- Aperture inlet: 4 x  $\varnothing 2$ mm
- Features:
  - Standard 510 thread
  - Press-in ceramic mouthpiece
  - CCELL proprietary ceramic heating technology
  - Medical-grade stainless steel center post
  - Borosilicate glass body
  - Available for customization
- Colors: Black, White



# Filling and Assembly Instructions



## STEP ONE

Fill 1.5ml of oil into the empty space around the center post



## STEP TWO

Confirm that the silicone sealing ring is set in place properly.



## STEP THREE

Align the mouthpiece with the body and press it firmly into position.

\*Cap within 1 min to avoid leakage.



## STEP FOUR

Let the filled product sit at least 30 minutes prior to use.

## OEM Capabilities

Front



Back



0.88 in (22.4 mm)

1.73 in (43.96 mm)



3.36 in (85.3 mm)

1.73 in (43.96 mm)

### Oil Tank

**OEM Option:** Silkscreen printing

**OEM Dimensions:**

0.88H x 1.73W (in) / 22.4H x 43.96W (mm)

### Battery Case

**OEM Options:** Coating, electroplating, silkscreen printing, laser engraving

**OEM Dimensions:**

3.36H x 1.73W (in) / 85.3H x 43.96W (mm)



CALYX  
LABS

THANKS /

Visit us at [WWW.CALYXLABS.COM](http://WWW.CALYXLABS.COM)

FOLLOW US: @CALYX\_LABS



© CALYX LABS All rights reserved. Subject to alteration.