

Product Overview

Luster is infused with CCELL's cutting-edge technology and the most exquisite craftsmanship and gives you the solid feel holding in your hand.

Luster incorporates both 0.5-gram and 1.0-gram pods so that you have more options to customize your satisfaction. The gleaming look is not to be ignored. Housed in zinc alloy case, Luster adds a sheen of metallic glow to every color you want to customize it in.









Specs & Features

Battery Specs & Features

- Rattery Canacity: 350 mAh
- · Solidly Built With Craftsmanship
- Consistent Massive Vapor Production
 - Minimalist Design And Gleaming Finish
- Available In 0.5 And 1.0 Gram Pods
- Dimensions: 11 x 20.9 x 82.9(mm)

Luster*



20.9mm



11mm

82.9mm



· Specs & Features

Luster-Pod Specs & Features

- Tank Volume: 0.5ml / 1ml
- Plastic Housing
- Integrated Mouthpiece
- Magnetic Connection
- Dimensions:

36.3 x 11 x 20.9(mm) (0.5 ml)

0.5ml

36.3mm





20.9mm





1.0ml





20.9mm









OEM Capabilities

Luster

· Battery Housing


20.9mm

Material: Zinc Alloy

OEM Options: Electroplating + Silk-screening

Spray Painting + Silk-screening

OEM Dimensions: 11 x 20.9 x 82.9(mm)



11mm


· Luster-Pod (One Side)

Material: Plastic

OEM Options: Silk-screening

OEM Dimensions: 8.9~13 x 8.5(mm)

(Available in both .5ml and 1.0ml pods)



· Filling and Assembly Instructions





Тор сар



STEP ONE

Insert a filling needle into the space between the airway and the outer wall of the pod. With pod held upright fill both two sides next to airway with 0.5ml of oil (0.25ml for each side).

*Do not overfill or allow oil to enter the center airway

STEP TWO

Immediately after filling, insert and press the top cap piece vertically until it's fully seated.

*Failure to insert the top cap piece immediately may cause leakage.

STEP THREE

Push the filled pod into mouthpiece until you hear a click sound.











