



**FERRO
PRINT™**

Procedure Card for FPT-10

FerroPrint™

Trace Metal Detection Test



**Read
Before
Use**

Spray away from the face. Keep out of reach of children. Not for internal ingestion.
In case of accidental ingestion, seek medical treatment immediately.
Use only in a well ventilated area. Do not inhale spray.
In case of exposure to the eyes, flush with water.

Test Procedure

1

With **Bottle #1**, spray directly on the hands of the suspect.

Do not saturate.



**Do not spray
towards the
eyes or face.**

Spray about
10 cm (4 in)
from suspect.

2

Wait several seconds for the solvent to dry. A violet color may begin to appear.



Test Procedure

3

Lightly wet the hands of the suspect with the water in **Bottle #2**. This will enhance the color reaction.



4

Watch for dark violet marks on the suspect's hands, which indicate the presence iron traces.



End

5

For evidentiary purposes, photograph the results.



v4
07-19