



VIEW OUR RANGE OF DEHYDRATORS VIRTUALLY!

Not sure which dehydrator is right for your space? Follow these easy steps to view our complete range of Commercial Dehydrators in your warehouse using Augmented reality.

Locate and scan the QR code on any of our product pages to see a real sample of what our machine would look like in your warehouse or home.

1

Open your camera or QR scanner app on your Apple iPhone.



2

Align your camera over the QR code of the dehydrator you wish to view.

Tap on the Safari page, that pops up at the top of the screen, generated by the QR code.

3

Wait for the dehydrator to load. The loading icon will stop spinning once this has occurred.



4

Move your camera slowly back and forth across the floor or bench that you wish to place the dehydrator model on.



5


Continue to move your camera until your dehydrator appears in your room with you. See the tips below to assist with this step.



6

Move and rotate the dehydrator as necessary. Walk around to view all sides of the dehydrator in your own space.

**Once the unit appears, ensure it is completely level with the ground. If not, close and reload the model.*



TIPS

- > Ensure you are in a well-lit room
- > Move the Camera Slowly when searching for a surface
- > To move the unit, use one finger and slide across the screen
- > To rotate, place one finger on screen and use a second finger to rotate around
- > Compatible with Apple iPhone 7 models or newer.