Commander

Tel 800 668 9318 Tel 416 298 5700 Fax 416 298 9535 mail@ nienkämper.com www.nienkamper.com



CONFERENCE TABLE AND VOX FORUM° INSTALLATION GUIDE

THIS IS A GENERAL ASSEMBLY GUIDE, NOT ALL CONDITION MAY APPLY TO YOUR PARTICULAR INSTALLATION

HARDWARE PARTS LIST



Small 4 mm For hex socket assembly, to join rails together. For installing bases to rails. For installing mounting plate to top. Large 5 mm For hex socket assembly, to join rail together.



FLAT HEAD HEX SOCKET ASSEMBLY

4 mm and 5 mm - $2" \times 1/4"$ - 20 and threaded collar.



Joins rails together.



FLAT HEAD HEX SOCKET BOLT

4 mm - 5/8" x 1/4" - 20. Joins bases to rail.



FLAT HEAD HEX SOCKET BOLT

4 mm - 1" x ¹/₄" - 20. Joins mounting plate to top. Joins bases to top for tables up to 108".



TIG HT JOINT FA STENERS

3 piece assembly plus 1 tightening rod.



WOODEN SPLINE

1/8" x 7/8" x (24" - va ries). Inserts into the edge of multiple segment tops.



MOUNTING PLATE

1/4" x 3" x 4". Fixes rail to top.




WIRE MANAGEMENT "U" CLIPS Grey ABS plastic.

Used to secure wires to support rail.


ASSEMBLING SUPPORT RAILS

ATTACHING BASE TO RAILS



- Large conference tables incorporate support rails in multiple segments.
- Position and assemble connecting joints as shown.
- Matching joints are number coded (circular labels).
- Required hardware: $2" x ^{1/4}"$ 20 flat head hex socket assembly.
- Tighten joint, a ligning marks as shown.
- Certa in table shapes require rails to be assembled at different angles (as marked).

2



- Place bases on top of rails aligning the holes in the base with factory installed thread locations in the rails.
- Attach and tighten bases to rails.
- Required hardware: 9/16"x 1/4" 20 flat head hex socket bolt.

ATTACHING BASE DIRECTLY TO TOP

FINISHED BASE ASSEMBLY



• Flip assembly over to apply top.



• Feed sandbag into base.



JOINING MULTIPLE PIECE TOPS



- Position multiple section tops with matching identification numbers onto rails.
- Insert wooden spline into the groove at the seam.
- Insert ball fitting, a lign with tight joint bolt.
- Start the thread.




- Slide tops together, a lign the top.
- Insert tight joint collar.
- Tighten ball fitting, hand tight.

ATTACHING BASE TO TOP

INSTALLING VOX FORUMS°



- Insert the mounting plate into the top groove of the rail.
- Slide the plate to a lign threaded inserts of top with holes in mounting plate.
- Required hardware: 1" x $^{1}/_{4}$ " 20 flat head hex bolt.



- Unpack the Forum box and retrieve the swivel latches.
- Carefully thread plastic thumbscrews into inserts around the square hole in the top.
- Position Forum in opening and carefully ease up into the square hole.
- Rotate the swivel catches and tighten the thumb screw fasteners.

Note: detailed installation instructions are included with all Vox Forums.



WIRE MANAGEMENT - "U" CLIPS



- Begin by mounting adhesive wire management strip behind Forum position, or where required.
- Insert cables in 1 of 3 channels.


10



- Using wire management "U" clips, store and route cables to bases a long the rail.

WIRE MANAGEMENT - BASE

WIRE MANAGEMENT ACCESSORIES



- Route cabling down leg.
- Note the bottom of the base also has a through hole.



- To bring cabling from the under side of the top to the floor, wire management accessories can also be used.
- A variety of models are available.
- Instructions for installing wire management accessories are packaged with each accessory.



nienkämper International Inc.