

TERAJOINT

INSTALLATION INSTRUCTIONS

CANZAC TERAJOINT is supplied in 3metre lengths.

Step 1. Sub-base level

The sub-base must be made as accurate and level as possible to the requirements on the slab drawing. The tolerance of the level has to be taken into account when ordering joints. Typically the Joint height will be 5mm less than the slab depth.

Step 2. Joint location

The required layout, position and height of the joints will be specified on the floor slab drawing which must be followed closely. String lines are placed to identify the position of joints according to the slab layout dimensioned drawings.

Step 3. Joint Installation

You can install this system 2 ways, set the legs in concrete the day before the pour or use shims under the legs when pouring the same day.

Lay **TERAJOINT** out along string line with the plastic sleeves all on the same side. Subsequent joints are aligned, fixed at the overlap using dowel bushes, plastic bolts and nuts, adjusted and fixed in the same manner. The final joint in any run will usually require being cut to length. The gap between the column/wall and the last joint in series is measured taking account of suitable isolation material. The final joint is cut to length and installed in the same manner as previous joints.




CANZAC

PO Box 3181, 3 Parkhouse Road, Wigram, Christchurch, New Zealand
Phone: 03 343-4254 • Fax: 03 343-4237 • Freephone: 0800 422 692
info@canzac.com • www.canzac.com

TERAJOINT INSTRUCTIONS continued

Each 3metre length will have one 10x16mm slot for connecting the next 3 metre length. Please make sure you use the nylon bolts, steel provided. These will be attached to one end of each set (do not use steel bolts!). The joints should be fixed so that the ends of adjacent top strips are not touching but have a clearance gap of between 1 mm and 2 mm to allow for longitudinal movement.



Using a dumpy level, set the top of the **TERAJOINT** off to FF (finish floor) level. The best way to achieve this is to start from one end, set level from end-middle-end of the 3 metre length. The joint should be set vertical using a spirit level which can be placed across the top edges.



You have set **TERAJOINT** to a gridline and to FF (finish floor) and are now ready to pour.

IMPORTANT! Please ensure that your concrete placer understands that the concrete should finish at the top (FF) of the Armour Joint, not below and not above.



Please refer to the appended details for pegged foot, and intersection saw cut details.



TERAJOINT INSTRUCTIONS continued

Step 4. Pouring concrete

Once rails are correctly positioned pouring of concrete can commence. Concrete should be poured to the level of the rails with particular attention to consolidation around the dowels and sleeves. All plate type dowels require close attention to filling around the dowels to eliminate the possibility of air entrapment. This should be done with a suitable vibrating poker. Both sides of joints can be poured at the same time if so required.

STEP 1




STEP 2



STEP 3




STEP 4




CANZAC

PO Box 3181, 3 Parkhouse Road, Wigram, Christchurch, New Zealand
Phone: 03 343-4254 • Fax: 03 343-4237 • Freephone: 0800 422 692
info@canzac.com • www.canzac.com


TERAJOINT INSTRUCTIONS continued



THIS WAY



NOT BELOW





NOT ABOVE

- ★ Ensure any leftover concrete slurry is removed from the top of the Joint
- ★ Ensure all saw cuts cut right through the steel joint system
- ★ Ensure all intersections of the Joint are not continuous through the junction
- ★ Ensure steel Joint is set at FFL (finished floor level)

TERAJOINT INSTRUCTIONS continued

INTERSECTION SAWCUT DETAIL


For slabs **WITH** sawcuts



For slabs with **NO** sawcuts.


Cut completely through all Joint intersections the day after pouring.

For slabs with **NO** sawcuts



For slabs **WITH** sawcuts.


Cut completely through all Joint intersections and all saw cut intersections the day after pouring.



Ensure Joint is cut through at all intersections


(Above: Intersections circled in red

Below: plan view of cut joint)



TERAJOINT PEG & FOOT FIXING DETAIL

Plan View



Drive pin central to
outside of slot in feet

Isolate top of foot with smooth plastic shim then install bolt into site concrete.

FOR SITE SUPPORT PLEASE CALL 0800 422 692

CANZAC

PO Box 3181, 3 Parkhouse Road, Wigram, Christchurch, New Zealand

Phone: 03 343-4254 • Fax: 03 343-4237 • Freephone: 0800 422 692

info@canzac.com • www.canzac.com