## Top Down Measuring

Rose Mary LeBlanc and Amanda Deal Smith





Top Down Measuring is a very important option for window treatment measuring and fabrication. It should be done when the space that the drapery hardware will be installed in is a tight spot with no margin for error.


Yes, Top Down Measures does take a bit more time on the front end of the job, but it outweighs having to re do or alter the treatment after installation. In the long run it does save time, money, and homeowner disappointment.




When there is a lot of space between crown molding and door or window molding, hardware placement isn't as crucial because there is wiggle room for the hardware to go up or down a few inches.

Top Down Measures are also done for curved or arched windows when the window treatment will be mounted into a tight space. This works not only for drapery hardware but also for board mounted window treatments as well.

For a Top Down Measure, the drapery hardware is ordered and installed *first* before a finished length can be determined.



Once the hardware is installed, a measurement is taken from the bottom of the ring to the floor. Then the work order can be done and sent on to the workroom.



These traversing panels are a good example of when to do a Top Down Measure.

When the initial measure was done a deduction for the drapery hardware was not subtracted from the wall measurement before the panels were fabricated. Also the wrong deduction can be subtracted resulting in an incorrect finished length.

Install was one of those 'uh oh' moments when the panels were installed and were dragging on the floor. New brackets were ordered which, fortunately, did correct the problem, but that was extra time and expense that could have been avoided.



Thank you for viewing this presentation
© 2018 Seamless Workroom LLC
Rose Mary LeBlanc and Amanda Deal Smith
Visit us at

www.seamlessworkroom.com
Contact us at

seamlessworkroom@gmail.com

